


# Rackmount 3.5-kW Air Conditioning Unit

## User Manual

ACRMD4KI-1, ACRMD4KI-2, ACRMD4KI-3

990-6186-001

Release Date: 06/2019



# Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

---

# Table of Contents

<b>Safety</b> .....	5
Important Safety Instructions — SAVE THESE INSTRUCTIONS.....	5
Safety During Installation and Operation.....	6
Intended Use.....	8
<b>General Information</b> .....	9
Document Overview.....	9
Original Instructions.....	9
Save These Instructions.....	9
Manual Updates.....	9
Cross-Reference Symbol Used in This Manual.....	9
Abbreviations.....	9
Equipment Disposal.....	9
General Information.....	9
Please Recycle.....	10
Waste Electrical and Electronic Equipment (WEEE) Disposal.....	10
Receiving and Inspecting the Unit.....	10
Filing a Claim.....	10
Storing the Unit Before Installation.....	10
Unpacking the Unit.....	11
Moving the Unit.....	11
<b>Unit Overview</b> .....	12
Introduction.....	12
Equipment Guidelines.....	13
Working Conditions and Environmental Limits.....	13
Standard Features and Options.....	14
Standard Features.....	14
Optional Features.....	15
Technical Data.....	15
<b>Dimensions and Weights</b> .....	17
Indoor Unit.....	17
Outdoor Units.....	17
Weight.....	18
Service Clearance.....	18
Airflow Clearance.....	18
Access Locations.....	19
<b>Component Identification</b> .....	20
Inventory.....	20
External Components.....	20
Indoor Unit.....	20
Outdoor Unit.....	21
Internal Components.....	22
Indoor Unit.....	22
Outdoor Unit.....	23
<b>Installation</b> .....	24
Site Preparation.....	24
Incoming Power Supply Requirements.....	24
Before You Start.....	24

---

Positioning Units.....	25
Panel Removal.....	26
Indoor Unit .....	26
Outdoor Unit.....	27
Display Interface.....	28
Mechanical Connections .....	28
Installing the Indoor Unit in the Rack.....	28
Installing the Outdoor Unit .....	29
Piping Kit Application .....	30
Refrigerant Piping .....	31
Drain Connection .....	36
Electrical Connections .....	37
Wire Cross-Section Ratings.....	38
Connection Interface.....	39
Charging the Refrigeration System .....	42
Leak Detection .....	42
Vacuum Pumping.....	43
Calculating the Refrigerant Charge.....	44
Charging the Refrigerant .....	45
Commissioning.....	46
Start-Up Inspection Checklist .....	46
Electrical Inspection Checklist .....	47
Mechanical Inspection Checklist .....	48
Operation .....	49
Using the Display.....	49
Maintenance .....	56
Preventive Maintenance.....	56

# Safety

## Important Safety Instructions — SAVE THESE INSTRUCTIONS

Read these instructions carefully and look at the equipment to become familiar with it before trying to install, operate, service or maintain it. The following safety messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety message indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages with this symbol to avoid possible injury or death.

<b>⚠ DANGER</b>
<p><b>DANGER</b> indicates a hazardous situation which, if not avoided, <b>will result in death or serious injury</b>.</p> <p><b>Failure to follow these instructions will result in death or serious injury.</b></p>
<b>⚠ WARNING</b>
<p><b>WARNING</b> indicates a hazardous situation which, if not avoided, <b>could result in death or serious injury</b>.</p> <p><b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b></p>
<b>⚠ CAUTION</b>
<p><b>CAUTION</b> indicates a hazardous situation which, if not avoided, <b>could result in minor or moderate injury</b>.</p> <p><b>Failure to follow these instructions can result in injury or equipment damage.</b></p>
<b>NOTICE</b>
<p><b>NOTICE</b> is used to address practices not related to physical injury. The safety alert symbol shall not be used with this type of safety message.</p> <p><b>Failure to follow these instructions can result in equipment damage.</b></p>

### Please Note

Electrical equipment should only be installed, operated, serviced, and maintained by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

## Safety During Installation and Operation

### DANGER

#### HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- This equipment must be installed and serviced by qualified personnel only.
- Turn off all power supplying this equipment before working on or inside the equipment.
- Replace all devices, doors, and covers before turning on power to this equipment.
- Always use a properly rated voltage sensing device to confirm power is off.
- If the power supply cord is damaged, it must be replaced by an equivalent cord or assembly available from the manufacturer or its service agent.

**Failure to follow these instructions will result in death or serious injury.**

### WARNING

#### ELECTRICAL HAZARD

- Electrical service must conform to local and national electrical codes and regulations.
- The equipment must be grounded.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### WARNING

#### HAZARD FROM MOVING PARTS

Keep hands, clothing, and jewelry away from moving parts. Check the equipment for foreign objects before closing the doors and starting the equipment.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### WARNING

#### DAMAGE TO EQUIPMENT OR PERSONNEL

- The equipment is heavy. For safety purposes, adequate personnel must be present when moving this item.
- The load must always be solidly anchored to the bearing element of the lifting equipment and means of transport.
- No one should be near the suspended load, nor in the working area of the crane, forklift, truck, or any other lifting equipment or means of transport.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**⚠ WARNING**

**HAZARD TO EQUIPMENT OR PERSONNEL**

This equipment is not to be operated or installed by persons with reduced physical, sensory, or mental capabilities, or persons lacking experience or knowledge unless they have been given supervision or instruction. Children are not to operate or play on or around this equipment.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**⚠ CAUTION**

**HAZARD FROM UNPROTECTED OUTPUT**

Apply circuit protection to all outputs.

**Failure to follow these instructions can result in injury or equipment damage.**

**⚠ CAUTION**

**HAZARD TO EQUIPMENT OR PERSONNEL**

Do not operate your air conditioner in a wet room such as a bathroom or laundry room.

**Failure to follow these instructions can result in injury or equipment damage.**

***NOTICE***

**STATIC ELECTRICITY HAZARD**

Circuit boards contained within this unit are sensitive to static electricity. Use one or more electrostatic-discharge devices while handling the board.

**Failure to follow these instructions can result in equipment damage.**

***NOTICE***

**DAMAGE FROM EXPOSURE**

Leaving the equipment uncovered and exposed to possible damage from the environment will void the factory warranty.

**Failure to follow these instructions can result in equipment damage.**

***NOTICE***

**DAMAGE TO REFRIGERATION CIRCUIT**

- Make sure the compressor has been pre-heated for at least 24 hours in the event the system is not in operation for an extended period of time.

**Failure to follow these instructions can result in equipment damage.**

## **NOTICE**

### **DAMAGE TO EQUIPMENT**

- If the power supply cord is damaged, it must be replaced by the manufacturer.
- An all-pole disconnection device that has at least 3-mm clearances in all poles and has a leakage current that may exceed 10 mA, the residual current device (RCD) having a rated residual operating current not exceeding 30 mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- Type and rating of fuses: glass tube 250 V, 3.15 A

**Failure to follow these instructions can result in equipment damage.**

### **Intended Use**

The cooling units provide air conditioning within the limits and methods described in this manual. This equipment must be installed and applied in accordance with the instructions provided. No modifications may be made to the units or their parts without explicit written consent from Schneider Electric. Any mechanical or electrical modification voids factory warranty.



# General Information

## Document Overview

### Original Instructions

These are the original instructions provided by the manufacturer.

### Save These Instructions

This manual contains important instructions that must be followed during installation, operation, and maintenance of the cooling unit.

### Manual Updates

Schneider Electric™ policy is one of continuous technological innovation and the company reserves the right to amend any data herein without prior notice. The images shown in this manual are for descriptive purposes only and they may differ from specific models that are selected.

**NOTE:** Unit images and component identification information are examples only. The final configuration of the unit may change according to the different options.

Check for updates to this manual on the Schneider Electric Web site, [www.schneider-electric.com/support](http://www.schneider-electric.com/support). Select the **Download Documents and Software** link under the **Support** tab and enter the manual part number or SKU for your equipment in the search field. See the back cover of this manual for the part number.

### Cross-Reference Symbol Used in This Manual



See another section of this document or another document for more information on this subject.

### Abbreviations

The following abbreviations and terms are used in this manual:

- CFD: Computational fluid dynamics
- EXV: Electronic expansion valve
- PTC: Positive Temperature Coefficient

## Equipment Disposal

### General Information

- This air-conditioning unit contains fluorinated greenhouse gases.
- Installation, servicing, maintenance, and repair of this unit must be performed by qualified personnel.
- Un-installation and recycling of the product must be performed by qualified personnel.
- When the unit is checked for leaks, proper record keeping of all checks is strongly recommended.

## Please Recycle

The shipping materials are recyclable. Save them for later use, or dispose of them appropriately.

## Waste Electrical and Electronic Equipment (WEEE) Disposal



Schneider Electric products comply with international directives on the Restriction of Hazardous Substances (RoHS) in electronic and electrical equipment and the disposal of Waste Electrical and Electronic Equipment (WEEE). Dispose of any waste electronic or electrical equipment with the appropriate recycling center. Contact Schneider Electric for assistance.

## Receiving and Inspecting the Unit

The cooling unit is packaged in a wooden crate or anchored to a pallet and covered with transparent film.

Upon delivery, check that the unit is intact and immediately notify the carrier in writing of any damage that can be attributed to careless or improper transportation. Check for any damage on the area upon which the display interface is mounted.

In case of shipping damage, do not operate the cooling unit. Keep all packaging for inspection by the shipping company and contact Schneider Electric Corporation.

## Filing a Claim

If damage is identified on receipt of the equipment, note the damage on the bill of lading and file a damage claim with the shipping company. Contact Schneider Electric Worldwide Customer Support at one of the numbers listed on the Web page on the back page of this manual for information on how to file a claim with the shipping company. The shipping claim must be filed at the receiving end of the delivery.

**NOTE:** In case of shipping damage, do not operate the equipment. Keep all packaging for inspection by the shipping company and contact Schneider Electric.

## Storing the Unit Before Installation

### **NOTICE**

#### **DAMAGE FROM EXPOSURE**

Leaving the equipment uncovered and exposed to possible damage from the environment will void the factory warranty.

**Failure to follow these instructions can result in equipment damage.**

The storage environment for the series AC should comply with GB4798.1-2005.

Item	Requirements
Storage environment	Indoor, clean (without dust)
Ambient humidity	15–85%RH (without condensation)
Ambient temperature	–20 to 52°C (–4 to 129.2°F)

## Unpacking the Unit

Move the unit near its final position before unpacking it for inspection.

The unit is packed with corrugated paper. Remove all packing materials on site.

## Moving the Unit

<b>▲ WARNING</b>
<b>DAMAGE TO EQUIPMENT OR PERSONNEL</b>
<ul style="list-style-type: none"><li>• The equipment is heavy. For safety purposes, adequate personnel must be present when moving this item.</li><li>• The load must always be solidly anchored to the bearing element of the lifting equipment and means of transport.</li><li>• No one should be near the suspended load, nor in the working area of the crane, forklift, truck, or any other lifting equipment or means of transport.</li></ul>
<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>

Lifting and transporting the units must be carried out by qualified personnel as described in this manual.

Use all relevant safety standards to prevent any possible damage to people or objects.

### Indoor Unit

The cooling unit is packaged in a carton. The recommended tools for moving and installing the equipment include the following:

Forklift



Pallet Jack



### Outdoor Unit

The condensing unit is packaged in a carton. The recommended tools for moving and installing the equipment include the following:

Pallet Jack




Forklift



Crane



Keep the inclination of the outdoor unit within 75–105 degrees.



---

# Unit Overview

## Introduction

This AC unit series, an air conditioning system of precision environmental control in a server cabinet, provides precise temperature control, safety and reliability, high energy efficiency design, and remote monitoring.

This series also features efficient refrigeration, high reliability, high sensible-heat factor, intelligent monitoring, rapid installation, convenient maintenance, and compact structure. R410A refrigerant is used as required internationally for environmental protection.

## Precise Temperature Control

This series of air conditioners has a temperature control of up to  $\pm 2.0^{\circ}\text{C}$  ( $3.6^{\circ}\text{F}$ ). Intelligent microprocessing control monitors any change in the server cabinet and responds with control processing in advance rather than reacting to the change of the environment at that time.

## Safety and Reliability

Keep the unit running 24 hours a day to keep it reliable. The advanced microprocessing system of the units automatically adjusts machine operation and reduces faults. Automatic alarms and diagnostics aid in maintenance and servicing to help protect the unit and prolong the life of the unit.

## High Energy Efficiency Design

The DC brushless, axial flow, centrifugal fan features minimal vibration, low noise, and high reliability. The high-efficiency, finned-tube heat exchanger greatly improves the heat exchange efficiency. The loop developed and verified to a specific model ensures each loop is uniformly distributed and the heat exchanger is fully used.

## Remote Monitoring

Remote monitoring includes an RS485 interface and Modbus protocol.

- Telemetry Function: Remotely read the return and supply air temperature, humidity of return, and working state of the unit.
- Remote Function: Remotely read the open and close state, high or low temperature and return air humidity, and normal or failure fan state.

## Cooling Control

- Temperature Control Function
  - Indoor temperature controls system
- Cooling Regulation Function
  - Variable-speed compressor
  - Cooling output range of 25–100% (16–90Hz)
- Temperature
  - Regulated temperature range of  $19\text{--}30^{\circ}\text{C}$  ( $66.2\text{--}86.0^{\circ}\text{F}$ )
  - Adjustable temperature  $\pm 2.0^{\circ}\text{C}$  ( $3.6^{\circ}\text{F}$ )

## Equipment Guidelines

### Working Conditions and Environmental Limits

#### Indoor Unit

Limit Working Conditions	
<b>Power Supply</b>	200–240 V~, 1 Ph, 50 Hz
Room Conditions	
<b>Temperature</b>	16–43°C (60.8–109.4°F)
<b>Humidity</b>	15%–65% RH (without condensation)
<b>Maximum Altitude</b>	1000 m (3281 ft), de-rated for more than 1000 m (3281 ft)
Storage Conditions	
<b>Temperature</b>	–20 to 52°C (–4.0 to 129.2°F)

#### Outdoor Unit

Limit Working Conditions	
<b>Power Supply</b>	200–240 V~, 1 Ph, 50 Hz
Ambient Conditions	
<b>Temperature</b>	–35.0 to 45.0°C (–31.0 to 113.0°F)
<b>Maximum Altitude</b>	1000 m (3281 ft), de-rated for more than 1000 m (3281 ft)
Storage Conditions	
<b>Temperature</b>	–20 to 52°C (–4.0 to 129.2°F)

## Standard Features and Options

### Standard Features

#### Indoor Unit

Feature	Description
Evaporator	The finned tube heat exchanger with high-efficiency internal thread copper pipes, hydrophilic foil, CFD flow field analysis, and optimal matching improve the heat transfer efficiency.
EXV	The EXV improves the control precision and response speed for precision cooling while the system is stable to save energy.
Fan	The DC fan is continuously variable in speed and can quickly respond to heat loads. It features high airflow, high efficiency, long service life, and low noise.
Controller	The unit controller features power recovery and fault warning. It has a terminal block connection interface.
Filter	The aluminum air filter provides a clean air supply.

#### Outdoor Unit

Feature	Description
Compressor	The inverter-driven compressor adjusts the refrigerating capacity. The frequency conversion control technology of the compressor and the air supply temperature control of the unit enable the unit to flexibly adjust the refrigerating capacity under different heat loads, to provide a constant supply of air temperature, and reduce air temperature fluctuations. The running frequency of the compressor may be minimized under low thermal load conditions to ensure that the supply air temperature of the unit does not drop too low, and the compressor can be prevented from frequent start and stop to improve the efficiency and reliability of the unit and avoid condensation resulting from too low supply air temperature.
Fan	An axial flow, low-noise fan blade features wide voltage range and high reliability. The fan has multi-level air flow control, which improves the operation stability of the unit.
Condenser	Efficient finned-tube heat exchanger with hydrophilic fins does not retain dust and is easy to clean and maintain.

## Optional Features

Feature	Description
Tube	The copper tube includes threaded joints, bell nuts, and insulation material for the outer package. The tube is sturdy, does not corrode easily, and withstands high temperature and high pressure.
Condensate Drain Pump	The low noise DC brushless water pump has a lift that reaches 5 meters (16.4 ft).
Low Ambient Temperature Kit	The low ambient temperature kit provides the capability to operate in temperatures below $-15^{\circ}\text{C}$ ( $-5^{\circ}\text{F}$ ).
Positive Temperature Coefficient (PTC) Heater	The structure is compact and the heating is uniform. The PTC heater installed in the indoor unit is used for heat compensation when the IT load is low.

## Technical Data

### Indoor Unit

<b>Total Cooling Capacity</b>	3.6 kW (12,300 BTU/hr)
<b>Sensible Cooling Capacity*</b>	3.5 kW (11,900 BTU/hr)
<b>Rated Power Input</b>	200–240 V~, 1 Ph, 50 Hz
<b>Rated Air Volume</b>	700 m <sup>3</sup> /h (410 SCFM)
<b>Number of Fans</b>	1
<b>IDU Fan Input Power</b>	0.43 kW
<b>Size of Liquid Pipe/Air Pipe Connection</b>	9.52/12.7 mm (0.37/0.50 in.)
<b>Energy Efficiency Ratio (EER)</b>	2.5
<b>Sound Pressure Level</b>	62.5 dB(A)

\*Data at 35°C (95°F) RAT, 23%RH, outdoor air temperature 35°C (95°F)

### Outdoor Unit

<b>Heat Exchange</b>	6.3 kW
<b>Rated Air Volume</b>	1700 m <sup>3</sup> /h (1000 SCFM)
<b>Input Power</b>	1.00 kW
<b>Number of Fans</b>	1
<b>Number of Compressors</b>	1
<b>Sound Pressure Level</b>	51.5 dB(A)



## Refrigerant

<b>Refrigerant Type</b>	R410A
<b>Refrigerant Charge</b>	1.65 kg (58.2 oz)
<b>CO<sub>2</sub> Equivalent</b>	3.445 tonnes (7594.9 lb)
<b>GWP</b>	2088



# Dimensions and Weights



## Indoor Unit



na6186-02a

**NOTE:** Display interface is optional.

## Outdoor Units




na91282-31a


## Weight

Unit	Operating Weight – kg (lb)
Indoor unit	26 kg (57.3 lb)
Outdoor unit	48 kg (105.8 lb)

## Service Clearance





## Airflow Clearance



## Access Locations

### Indoor Unit




na91262-35a

Item	Description
①	Suction line valve
②	Liquid line valve
③	Condensate drain line

# Component Identification


## Inventory



Item	Description	Quantity
1	Indoor unit	1
2	Outdoor unit	1
3	Mounting bracket	2
4	M4x12 screw	2
5	Condensate drain hose	1
6	Hose clamp	1


## External Components

### Indoor Unit



Item	Description	Item	Description
1	Mounting flange	5	Mounting bracket (field installed)
2	Grille	6	Condensate drain line
3	Suction line valve	7	Handle
4	Liquid line valve	8	Display interface (field installed)

## Outdoor Unit




na91202-37a

Item	Description
①	Electrical panel access cover
②	Suction line valve
③	Liquid line valve
④	Mounting support
⑤	Fan protection grille


# Internal Components

## Indoor Unit



Item	Description	Item	Description
1	Supply air temperature sensor	7	Temperature and humidity sensor
2	Electronic expansion valve (EXV)	8	Air filter
3	Centrifugal fan	9	Isolated data repeater
4	Connection access box	10	Suction line temperature sensor
5	Condensate drain pan	11	Electrical box
6	Evaporative coil	12	Electric heater

Outdoor Unit



na91282-59a

Item	Description	Item	Description
1	Accumulator	7	High pressure sensor
2	Filter	8	Discharge temperature sensor
3	Suction temperature sensor	9	Low pressure sensor
4	Service port	10	Compressor
5	High pressure switch	11	Electronic expansion valve (EXV)
6	Electrical panel		

# Installation

## Site Preparation

Follow these guidelines to prepare the site for installation.

- Moisture proof and insulate the room to ensure the normal functioning of the environmental control system inside the room.
- Use polyethylene film for the moisture barrier on the ceilings and walls.
- Use moisture-proof paints on the concrete walls and floor.
- Minimize the entry of the outdoor air into the IT space as outdoor air may increase heating, cooling, and humidification and dehumidification loads of the system. Maintain intake of outdoor air below 5% of the circulating air.
- Fully enclose all doors and windows with minimized gaps.

## Incoming Power Supply Requirements

### **WARNING**

#### **ELECTRICAL HAZARD**

- Electrical service must conform to local and national electrical codes and regulations.
- The equipment must be grounded.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

- The main power requirement is 200–240 V/50 Hz.
- Ensure the electrical connection of the unit allows for the total load of the unit and its optional components. The difference between external static pressure of the unit and that of a standard unit may lead to changes in its input power and current. For the total input power and the total current, see the nameplate.
- The incoming power wire must have a circuit breaker of enough capacity with a contact opening distance of at least 3 mm (0.11 in.).
- Provide each unit with an independent power supply with power supply cut-off and over-current protection devices.
- Before wiring, ensure the power supply conforms to the specified value on the nameplate.
- Keep the wires away from the cooling line and the moving parts of the compressor, fan, and motor.

## Before You Start

The outdoor unit has been charged with refrigerant in the factory, and the indoor unit has been filled with a nitrogen holding charge. If you need to check the gas, do the following:

**NOTE:** Outdoor unit model ACRMD4KI-3 is not charged with refrigerant in the factory.

1. Open the shutoff valve.
2. Press the needle valve side of the service valve and check for gas ejection.
3. Connect a pressure gauge to get an accurate reading.



## Positioning Units

### Outdoor Unit

#### **⚠ CAUTION**

##### **HAZARD FROM SHARP EDGES**

Many metal parts have sharp edges. Be careful and wear protective gloves and clothing when working around and inside the equipment.

**Failure to follow these instructions can result in injury or equipment damage.**

#### **⚠ CAUTION**

##### **DAMAGE TO EQUIPMENT OR PERSONNEL**

Use concrete or a supporting frame to build a base for the unit. Allow for the floor strength, drainage treatment, duct, and wiring. Insufficient strength may cause the unit to drop resulting in injury or equipment damage.

**Failure to follow these instructions can result in injury or equipment damage.**

#### **NOTICE**

##### **EQUIPMENT DAMAGE RISK**

Install the unit in an area that is protected from adverse conditions such as an oil source (including engine oil), salt (in a marine region), and sulfide gases (near a hot spring or refinery).

**Failure to follow these instructions can result in equipment damage.**

Select a location for the installation that adheres to the following guidelines:

- Does not take in hot air from the unit or another unit.
- Allows enough clearance space for maintenance.
- Has no obstacles in the air exhaust and draft ducts of the outdoor unit to stop airflow.
- Provides good ventilation to help the unit exchange heat.
- Has sufficient strength to bear the weight of the unit and its vibration during operation.
- Does not have dirt, oil, salt, or sulfide gases.
- Is able to drain rainwater and defrost water.
- Is not susceptible to flammable gas. If any flammable gas leaks and accumulates around the unit, an explosion may occur.
- Is not subject to direct blow of a strong breeze or typhoon. Install rainproof, snowproof, and sunproof equipment if possible.


The floor and wall may cause vibration and noises depending on the installation conditions. Adopt anti-vibration measures such as anti-vibration pad or bumper bracket.

# Panel Removal


## Indoor Unit

### Electrical Box Access


1. Remove the filter.



2. Remove the electrical panel screws.




3. Slide the electrical box out of the unit.




## Outdoor Unit

### Electrical Panel Access



### External Panel



## Display Interface



See the installation sheet provided with the display interface for installation instructions.

## Mechanical Connections

### Installing the Indoor Unit in the Rack

The air conditioner is a cabinet refrigeration product that is installed in the standard cabinet of a machine room.


**NOTE:** Some components not shown for easier viewing.

1. Install the optional rail kit in the cabinet where the unit is to be installed.



See the installation instructions in the rail kit.

2. Slide the cooling unit into the rack on the rails.



3. Attach the front mounting flanges to the vertical mounting rails in the rack with the cage nuts and washers provided with the rack.
4. Attach the rear of the unit to the vertical mounting rails with the supplied mounting brackets and the cage nuts and washers provided with the rack.

**NOTE:** These may not be necessary to support the unit if the rail kit is installed.

## Installing the Outdoor Unit

### ⚠ CAUTION


#### SHARP EDGES

Do not touch the fins of the heat exchanger with bare hands.

**Failure to follow these instructions can result in injury or equipment damage.**

When installing the outdoor unit, follow these guidelines:


- Concrete or a supporting frame should be used to build a base for the unit. When building the base, allow for the floor strength, drainage treatment (drainage water will outflow from the unit when it is in operation), and duct and wiring. Insufficient strength may cause the unit to fall.
- The outdoor unit should be attached to the frame with M10 bolts at each corner of the mounting base of the outdoor unit.
- Vibrations and noise from the unit may be transmitted to the structure when it is in operation. Use anti-vibration pads or a similar measure to prevent transmission of vibrations and noise.



## Piping Kit Application

Three piping kits are available as options for use with the cooling unit:

- ACAC10042: Top piping
- ACAC10043: Bottom piping under the raised floor
- ACAC10044: Bottom piping under the rack



## Refrigerant Piping

### Piping Connection

The maximum equivalent piping length between the indoor and outdoor units is 20 m (65.6 ft). The maximum vertical difference for the outdoor unit above or below the indoor unit is 5 m (16.4 ft). The table below outlines pipe sizes for field piping.


Tube	Size
Liquid line	Ø9.52 mm (3/8 in.)
Gas line	Ø12.7 mm (1/2 in.)
Refrigerant R410A piping (minimum thickness)	0.8 mm (0.03 in.)

The minimum thickness of the piping specified in the instructions is based on drawn tube of copper and copper alloys (GB/T1527-2006). The thickness and material of pipes used must be able to withstand a pressure of 4.15 MPa (602 psi) in accordance with applicable laws.

If the unit is in an environment of severe corrosion, increase the thickness of the pipe by at least 0.2 mm (0.008 in.).


If the piping has a reduced thickness from bending and tensioning, increase its wall thickness accordingly.

Refer to the sizes in the table for processing the bell mouth of copper piping.



OD		OD Size
Metric	British	R410A
Ø6.35 mm	1/4 in.	9.1 mm (0.36 in.)
Ø9.52 mm	3/8 in.	13.2 mm (0.52 in.)
Ø12.70 mm	1/2 in.	16.6 mm (0.65 in.)
Ø15.88 mm	5/8 in.	19.7 mm (0.78 in.)
Ø19.05 mm	3/4 in.	24.0 mm (0.94 in.)

See the table for the corresponding flare nut specifications.




OD		OD Size
Metric	British	
Ø 6.35 mm	1/4 in.	17.0
Ø 9.52 mm	3/8 in.	22.0
Ø 12.70 mm	1/2 in.	24.0
Ø 15.88 mm	5/8 in.	27.0
Ø 19.05 mm	3/4 in.	36.0




## Copper Pipe Connection

1. Remove and keep the flare nuts and remove and discard the copper plugs from the liquid line and suction line connections.




2. Connect the pipes from the selected pipe kit (ACAC10042, ACAC10043, or ACAC10044) to the liquid and suction lines.

**NOTE:** Make sure the piping does not inhibit removal of the electrical box.




3. Use a flaring tool to connect the customer piping (field supplied) to the flare nut.

**NOTE:** Make sure the flare nut is on the piping before using the flaring tool on the customer piping.




4. Route the customer piping through the cabinet and connect the flare nuts to the customer-piping side of the pipe kit.

**NOTE:** Pipe kit ACAC10044 is shown.




5. Remove and keep the flare nuts and remove and discard the copper plugs from the liquid line and suction line connections.




6. Use a flaring tool to connect the customer piping (field supplied) to the flare nut.

**NOTE:** Make sure the flare nut is on the piping before using the flaring tool on the customer piping.



7. Connect the flare nuts to the suction and liquid lines of the outdoor unit.



OD	Tightening Torque	Tightening Angle
Ø6.35 mm (1/4 in.)	14–18 N·m (10.33–13.28 ft-lb)	60°–90°
Ø9.52 mm (3/8 in.)	35–42 N·m (25.81–30.98 ft-lb)	60°–90°
Ø12.7 mm (1/2 in.)	50–57.5 N·m (36.88–42.41 ft-lb)	30°–60°
Ø15.88 mm (5/8 in.)	75–80 N·m (55.32–59.00 ft-lb)	30°–60°
Ø19.05 mm (3/4 in.)	100–140 N·m (73.76–103.26 ft-lb)	20°–35°

### Brazing Copper Pipes


1. Use a neutral flame to braze and control the ratio of oxygen to acetylene ( $O_2: C_2H_2=1.0-1.2$ ). Heat the base metal 20–25 mm (0.78–0.98 in.) from the flame core given that the highest temperature is 2–3 mm (0.7–0.11 in.) from the flame core (for reference only).
2. Fill the copper pipe with nitrogen to eliminate air. An oxide film may lead to blockage of the expansion valve, filter, or other system components.
3. Maintain the flow of nitrogen at 10–20 l (2.64–5.28 gal) per minute with a pressure regulating valve.
4. Fill with nitrogen until the pipe is completely cooled down.

### Insulating Refrigerant Pipes

Insulate the refrigerant pipes with closed cell foam insulation of sufficient thickness to cover the liquid pipe and the suction line. Improper insulation materials or installation methods may cause condensation to drip from the refrigerant pipes.

## Drain Connection

1. Attach the condensate drain hose to the drain connection of the unit with the hose clamp.



2. Route the condensate drain hose out of the unit or connect it to the condensate drain pump.



See the condensate drain pump *Installation Sheet*.

## Electrical Connections

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- This equipment must be installed and serviced by qualified personnel only.
- Turn off all power supplying this equipment before working on or inside the equipment.
- Replace all devices, doors, and covers before turning on power to this equipment.

**Failure to follow these instructions will result in death or serious injury.**

### **DANGER**

#### **ELECTRICAL HAZARD**

Overcurrent protection for all incoming power feeds must be provided by the customer. See unit nameplate for equipment ratings.

**Failure to follow these instructions will result in death or serious injury.**

### **WARNING**

#### **ELECTRICAL HAZARD**

- Electrical service must conform to local and national electrical codes and regulations.
- The equipment must be grounded.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### **WARNING**

#### **ELECTRICAL FIRE HAZARD**

Use copper conductor wiring only.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The following electrical connections are required in the field:

- Power connection of the indoor unit (H05VV-F 3 x 1.0 mm<sup>2</sup> cable)
- Power connection of the outdoor unit (H05VV-F 3 x 1.5 mm<sup>2</sup> cable)
- Communication lines between the indoor and outdoor units (PLTC 2 x 0.5 mm<sup>2</sup> cable)

**NOTE:** A and B need to be distinguished when connecting.

- Remote monitoring line of the unit


Before connecting the circuit, determine the input power voltage with a voltmeter, and turn the power off. Use PVC insulated copper wires or rubber insulated copper wires for the connecting wires of the indoor and outdoor units. The cross-sectional area must meet the maximum requirements for load of the unit and its components. Secure all wiring: Connecting wires of the indoor and outdoor units must be fixed on clips.

## Wire Cross-Section Ratings

Wire Area	Maximum Current
1.0 mm <sup>2</sup>	8 A
1.5 mm <sup>2</sup>	11 A
2.5 mm <sup>2</sup>	15 A
4 mm <sup>2</sup>	20 A
6 mm <sup>2</sup>	25 A
10 mm <sup>2</sup>	35 A

Do not connect the same power terminal with two wires of different diameters.

When connecting to the terminal block, use a needle-shaped terminal with an insulation sleeve. Ensure the terminal connection to the wires is acceptable.



Item	Description
A	Wires (cross copper wires of over 0.5 mm <sup>2</sup> )
B	Insulating material
C	Shielding layer (requires more than 95% shielding effectiveness)
D	Outer layer protection (PVC)


## Connection Interface

Connection interfaces include the total power input interface and the remote communication interface of the unit.

### Indoor Unit




See the installation sheets provided with the accessories for more information.




Item	Description	Item	Description
1	Controller communication connections (RS485+, RS485-, RS485+, RS485-)	7	Ground (GND)
2	Fire/smoke alarm connection (F1, F2)	8	Power supply connection (L, N, GND)
3	Leak sensor connection (W1, W2)	9	Communication connection to the outdoor unit (A3, B3)
4	Condensate drain pump communication connection (P1, P2)	10	Display interface connection (A6, B6)
5	Condensate drain pump power supply connection (L3, N)	11	24-VDC power supply (V+, V-, PE)
6	Low temperature kit connection <ul style="list-style-type: none"> <li>Solenoid valve (SV)</li> <li>High pressure control and heater (L1)</li> </ul>		

1. Remove the cover from the connections box.




2. Remove the communication position connectors from the electrical box to make connections easier.



3. Route the power connections through the cable strain reliefs and make the connections in the unit.
4. Route the communication connections through the cable strain reliefs and make the connections to the position connectors.
5. Replace the communication position connectors.
6. Replace the cover.



## Outdoor Unit



Item	Description
①	Power supply connection (L, N, GND)
②	Communication connection to indoor unit (Ain, Bin)

1. Remove the electrical panel cover.



See *Panel Removal*, page 26.

2. Route cables through the cable strain reliefs and make the unit connections.
3. Replace the electrical panel cover.

## Charging the Refrigeration System

### **NOTICE**

#### **DAMAGE TO EQUIPMENT**

Follow the procedures and tables outlined in this manual to charge the refrigerant if the piping exceeds the standard length.

**Failure to follow these instructions can result in equipment damage.**

Indoor and outdoor units are all provided with service valves. Connect the service valves to pipes for immediate system leak detection, vacuum pumping, and refrigerant filling procedures.

**NOTE:** Indoor units and outdoor unit model ACRMD4KI-3 are not pre-charged with refrigerant in the factory.

## Leak Detection

### Method One


1. Fill the service valve with nitrogen to increase pressure to 2.8 MPa (406 psi) and 4.15 MPa (601 psi) for refrigerant R410A.
2. Apply soapy water at the connecting joints or welding joints of pipes for leak detection.
3. Repair leak sources and maintain the pressure for more than six hours to ensure that the pressure is not decreased.
4. The low side of the compound gauge cannot be connected to the system.

### Method Two

1. Fill with the refrigerant and stop when the pressure gauge indicates 0.3 MPa (43 psi).
2. Fill with nitrogen and stop when the pressure gauge indicates 2.8 MPa (406 psi) and 4.15 MPa (601 psi) for refrigerant R410A.
3. Use an HFC electronic leak detector to detect the leak. Use the bubble gas leak testing method.

## Vacuum Pumping

1. Exhaust the high pressure nitrogen in the system.
2. Connect the three flexible pipes of the compound pressure gauge to the corresponding joints of the service valve and the vacuum pump.
3. Start the vacuum pump and maintain the pressure inside the system below 650 Pa (0.09 psi). Do not start the unit until the pipeline for vacuum pumping is turned off.



Item	Description
1	Ball valve
2	Service port
3	Compound pressure gauge
4	Check valve
5	Vacuum pump

## Calculating the Refrigerant Charge

When leaving the factory, the outdoor units that have been filled with refrigerant in the factory have enough refrigerant required to cover 5 m (49 ft) of pipe. If the actual length of the pipe exceeds 5 m (49 ft), add more refrigerant for the additional length. Outdoor unit model ACRMD4KI-3 needs to be charged with 1.65 kg (3.64 lb) of R410A refrigerant for the initial 5 m (49 ft).

Liquid Pipe Specifications – mm	R410A Refrigerant – g/m (lb/ft)	Actual Pipe Length
Ø22.23	350 (0.24)	L1
Ø19.05	260 (0.17)	L2
Ø15.88	180 (0.12)	L3
Ø12.7	120 (0.08)	L4
Ø9.52	70 (0.05)	L5
Ø6.35	45 (0.03)	L6


The refrigerant to be added is calculated on the basis of the length and thickness of the lengthened pipe. The formula is: refrigerant to be added (kg) =  $0.35 \times L1 + 0.26 \times L2 + 0.18 \times L3 + 0.12 \times L4 + 0.07 \times L5 + 0.045 \times L6$ .

If the calculated result is less than 0.1 kg, round it to 0.1 kg. For example, if the calculated result is 28.62 kg, then add 28.7 kg as the charge amount.

## Charging the Refrigerant

1. Open the gas and liquid valves of the indoor and outdoor units.
2. If the filling tank for R410A does not have siphons, invert it.
3. Measure the filling amount with an electronic scale to prevent excessive filling.

Fill the gas pipe and the liquid pipe with liquid refrigerant at the same time. If the pressure is too large to fill the refrigerant, fill the refrigerant with a compressor during the test run.



Item	Description
❶	Cylinder with siphon
❷	Ball valve
❸	Service port
❹	Compound pressure gauge
❺	Refrigerant tank

# Commissioning

After installation, verify that all components are working properly and the equipment is ready to begin operation.

## Start-Up Inspection Checklist

The start-up inspection ensures that the equipment is operating properly after the initial start-up. This inspection verifies that all modes of operation are working correctly and the cooling unit is ready for normal operation.

### Ensure that

---

- The power core model of the outdoor and indoor units is correct.
- The fan and motor of the indoor unit are working normally.
- The fan and motor of the outdoor unit are working normally.
- Communication lines are correctly connected.
- The condensate pipe of the indoor unit is unblocked and the water seal installation is correct.
- The equipment is properly grounded and insulation is correct (10 megohm).
- The indoor and outdoor units have power supply in line with the nameplate, and the input voltage is not too high or too low.
- The system has no leaks.
- The main menu shows no fault after the unit is powered on.
- Parameters on the manual operator are correctly set.
- After the unit is started, the safety device does not trip.
- The air-out temperature of the unit is within its normal range.
- The air-out or air-return speed of the unit is within its normal range.
- The unit has no abnormal sound and its components have no abnormal vibration.
- The unit can operate normally by setting the switch mode and its components work accordingly.

## After a Long Shutdown

If the outdoor unit is restarted after a long shutdown, energize it for at least 8 hours before restarting the compressor.

## Electrical Inspection Checklist

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- This equipment must be installed and serviced by qualified personnel only.
- Turn off all power supplying this equipment before working on or inside the equipment.
- Replace all devices, doors, and covers before turning on power to this equipment.

**Failure to follow these instructions will result in death or serious injury.**

### **WARNING**

#### **ELECTRICAL HAZARD**

- Electrical service must conform to local and national electrical codes and regulations.
- The equipment must be grounded.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The electrical inspection verifies that all electrical connections are secure and correct and that the equipment is properly grounded.

#### **Ensure that**

- The power core model of the outdoor and indoor units is proper.
- Incoming voltages match the phase and voltage rating on the nameplate.
- Electrical wiring complies with local and national codes and regulations.
- The equipment is properly grounded and insulation is correct (10 megohm).
- Electrical connections are tight, including contactors, terminal blocks, controllers, switches, relays, auxiliary devices, and field connections.
- Circuit breakers are correct and securely attached to the DIN rail.
- Communication lines are correctly connected.

## Mechanical Inspection Checklist

### **▲ CAUTION**

#### **HAZARD TO EQUIPMENT OR PERSONNEL**

- The equipment is shipped from the factory with a nitrogen holding charge. Remove the nitrogen holding charge using the service ports located on the internal refrigerant piping.
- Improperly installed piping may result in improper operation and possible damage to the cooling unit or surrounding equipment.

**Failure to follow these instructions can result in injury or equipment damage.**

The mechanical inspection verifies that all mechanical components and connections are secure and tight and ready for start-up.

#### **Ensure that**

- Clearance space around the unit is appropriate.
- The fan and motor of the indoor unit are working normally.
- The fan and motor of the outdoor unit are working normally.
- The units are placed upright and fasteners used for installation are locked.
- Pipes connecting the indoor and outdoor units are installed.
- The drain pipe of the indoor unit is connected.
- The condensate pipe of the indoor unit is unblocked and the water seal installation is correct.
- All copper pipe joints are fastened.
- The system has no leaks.
- Fasteners for transport are removed.
- Transport materials, structure materials, and tools inside or around the equipment are removed.






























# Operation

## Using the Display

Main Interface	
Description	Screen
<p>Press the buttons on the <b>Main Interface</b> screen to access the following functions:</p> <ul style="list-style-type: none"> <li>• Alarm</li> <li>• ON/OFF</li> <li>• Input/Output (Operating Parameters)</li> <li>• Setpoint</li> <li>• User</li> <li>• Maintenance</li> <li>• Manufacturer</li> </ul>	<p>2019-03-20 16:11</p> <p>Air outlet temperature 0.0°C              Air return temperature 0.0°C              Air return humidity 0.0°C              Operating mode Refrigeration/cooling</p> <p>Buttons: ON/OFF, Input/Output, Setpoint, User, Maintenance, Manufacturer</p>

Turning the Unit ON/OFF	
Description	Screen
<p><b>Path: Main Interface &gt; ON/OFF</b></p>	<p>2019-03-20 16:11</p> <p>ON OFF</p> <p>U:01</p> <p>Press the appropriate button to turn the unit on or off.</p>

Operating Parameters—IDU Controller	
Description	Screen
<p><b>Path: Main Interface &gt; Input/Output &gt; IDU Controller Operating Parameters</b></p>	<p>2019-03-20 16:11</p> <p>IDU Controller Operating Parameters ODU Controller Operating Parameters</p> <p>Historical Data Historical Alarms</p>
<p>This screen provides information about the A01–EC fan and the IDU expansion valve steps.</p>	<p>2019-03-20 16:11</p> <p>A01-EC fan 0.0 V              IDU expansion valve steps 0</p>

Operating Parameters—IDU Controller																			
Description	Screen																		
Digital input: ON-No alarm OFF-Alarm	<div style="border: 1px solid black; padding: 5px;"> <div style="float: right; text-align: right;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Digital input</td> <td style="text-align: center;"></td> </tr> <tr> <td>Fire alarm / Remote ON/OFF</td> <td style="text-align: right;">ON</td> <td rowspan="3" style="text-align: center; vertical-align: middle;">I2</td> </tr> <tr> <td>High level switch of pump</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>Water on the floor</td> <td style="text-align: right;">ON</td> </tr> <tr> <td colspan="2"></td> <td style="text-align: center;">    </td> </tr> </table> <div style="text-align: right; font-size: small; margin-top: 5px;">m01202-4-4a</div> </div>	Digital input			Fire alarm / Remote ON/OFF	ON	I2	High level switch of pump	ON	Water on the floor	ON			 					
Digital input																			
Fire alarm / Remote ON/OFF	ON	I2																	
High level switch of pump	ON																		
Water on the floor	ON																		
		 																	
Temperature and humidity parameters	<div style="border: 1px solid black; padding: 5px;"> <div style="float: right; text-align: right;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Air out temperature °C</td> <td rowspan="5" style="text-align: center; vertical-align: middle;">I3</td> </tr> <tr> <td colspan="2">Coil Inlet temperature °C</td> </tr> <tr> <td colspan="2">Coil outlet temperature °C</td> </tr> <tr> <td colspan="2">Air return temperature °C</td> </tr> <tr> <td colspan="2">Air return humidity</td> </tr> <tr> <td colspan="2"></td> <td style="text-align: center;">    </td> </tr> </table> <div style="text-align: right; font-size: small; margin-top: 5px;">m01202-4-4a</div> </div>	Air out temperature °C		I3	Coil Inlet temperature °C		Coil outlet temperature °C		Air return temperature °C		Air return humidity				 				
Air out temperature °C		I3																	
Coil Inlet temperature °C																			
Coil outlet temperature °C																			
Air return temperature °C																			
Air return humidity																			
		 																	
Parameters for alarms, pump, heater, fan, and low temperature kit	<div style="border: 1px solid black; padding: 5px;"> <div style="float: right; text-align: right;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Digital input</td> <td rowspan="7" style="text-align: center; vertical-align: middle;">I4</td> </tr> <tr> <td>Serious alarm</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>Common alarm</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>Condensation pump</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>PTC heater</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>IDU fan</td> <td style="text-align: right;">ON</td> </tr> <tr> <td>SV of low temperature kit</td> <td style="text-align: right;">ON</td> </tr> <tr> <td colspan="2"></td> <td style="text-align: center;">    </td> </tr> </table> <div style="text-align: right; font-size: small; margin-top: 5px;">m01202-4-4a</div> </div>	Digital input		I4	Serious alarm	ON	Common alarm	ON	Condensation pump	ON	PTC heater	ON	IDU fan	ON	SV of low temperature kit	ON			 
Digital input		I4																	
Serious alarm	ON																		
Common alarm	ON																		
Condensation pump	ON																		
PTC heater	ON																		
IDU fan	ON																		
SV of low temperature kit	ON																		
		 																	
Fan and compressor run time	<div style="border: 1px solid black; padding: 5px;"> <div style="float: right; text-align: right;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>Main fan</td> <td style="text-align: right;">0.0 h</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">I5</td> </tr> <tr> <td>#1 Compressor runtimes</td> <td style="text-align: right;">0.0 h</td> </tr> <tr> <td colspan="2"></td> <td style="text-align: center;">    </td> </tr> </table> <div style="text-align: right; font-size: small; margin-top: 5px;">m01202-4-7a</div> </div>	Main fan	0.0 h	I5	#1 Compressor runtimes	0.0 h			 										
Main fan	0.0 h	I5																	
#1 Compressor runtimes	0.0 h																		
		 																	




























Operating Parameters–ODU Controller	
Description	Screen
<p><b>Path: Main Interface &gt; Input/Output &gt; ODU Controller Operating Parameters</b></p>	
<p>Temperature parameters</p>	



















Operating Parameters–Historical Data	
Description	Screen
<p><b>Path: Main Interface &gt; Input/Output &gt; Historical Data</b></p>	
<p>Historical Humidity Data</p>	

Operating Parameters–Historical Alarms	
Description	Screen
<p><b>Path: Main Interface &gt; Input/Output &gt; Historical Alarms</b></p>	
<p><b>Path: Main Interface &gt; Input/Output &gt; Historical Alarms &gt; Alarm</b> Press and hold <b>Clear Alarm</b> to clear alarms.</p>	

Setpoint											
Description	Screen										
<p><b>Path: Main Interface &gt; Setpoint</b> The password for the <b>Setpoint</b> screen is 1000.</p> <table border="1"> <thead> <tr> <th>Item</th> <th>Default</th> </tr> </thead> <tbody> <tr> <td>Air return temperature</td> <td>35°C</td> </tr> <tr> <td>Air outlet temperature</td> <td>22°C</td> </tr> <tr> <td>Minimum humidity</td> <td>15°C</td> </tr> <tr> <td>Maximum humidity</td> <td>80°C</td> </tr> </tbody> </table>	Item	Default	Air return temperature	35°C	Air outlet temperature	22°C	Minimum humidity	15°C	Maximum humidity	80°C	
Item	Default										
Air return temperature	35°C										
Air outlet temperature	22°C										
Minimum humidity	15°C										
Maximum humidity	80°C										

User																
Description	Screen															
<p><b>Path: Main &gt; User &gt; User Password</b> The default user password is 1000. <b>Password error</b> displays if a wrong password is entered. Enter the password within 5 seconds after the password error.</p>																
<table border="1"> <thead> <tr> <th>Item</th> <th>Default</th> <th>Option</th> </tr> </thead> <tbody> <tr> <td>Language</td> <td>Chinese</td> <td>English</td> </tr> <tr> <td>PTC Heater</td> <td>YES</td> <td>NO</td> </tr> <tr> <td>Condensation pump</td> <td>NO</td> <td>YES</td> </tr> <tr> <td>Condensation pump alarm</td> <td>UNIT OFF</td> <td>ALARM</td> </tr> </tbody> </table>	Item	Default	Option	Language	Chinese	English	PTC Heater	YES	NO	Condensation pump	NO	YES	Condensation pump alarm	UNIT OFF	ALARM	
Item	Default	Option														
Language	Chinese	English														
PTC Heater	YES	NO														
Condensation pump	NO	YES														
Condensation pump alarm	UNIT OFF	ALARM														

User																											
Description			Screen																								
<b>Item</b>	<b>Default</b>	<b>Range</b>	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; font-size: small;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Air outlet temperature limit</td> <td style="text-align: center;"></td> </tr> <tr> <td>Maximum</td> <td style="text-align: right;">27°C</td> <td></td> </tr> <tr> <td>Minimum</td> <td style="text-align: right;">13°C</td> <td style="text-align: center;"><b>P2</b></td> </tr> <tr> <td colspan="2">Air return temperature limit</td> <td style="text-align: center;"></td> </tr> <tr> <td>Maximum</td> <td style="text-align: right;">42°C</td> <td></td> </tr> <tr> <td>Minimum</td> <td style="text-align: right;">16°C</td> <td style="text-align: center;"></td> </tr> </table> </div>	Air outlet temperature limit			Maximum	27°C		Minimum	13°C	<b>P2</b>	Air return temperature limit			Maximum	42°C		Minimum	16°C							
Air outlet temperature limit																											
Maximum	27°C																										
Minimum	13°C	<b>P2</b>																									
Air return temperature limit																											
Maximum	42°C																										
Minimum	16°C																										
Air outlet temperature limit																											
Maximum	27°C	0–35°C																									
Minimum	13°C	0–20°C																									
Air return temperature limit																											
Maximum	42°C	0–50°C																									
Minimum	16°C	0–35°C																									
<b>Item</b>	<b>Default</b>	<b>Range</b>	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; font-size: small;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Air return temperature alarm</td> <td style="text-align: center;"></td> </tr> <tr> <td>High temperature</td> <td style="text-align: right;">45°C</td> <td></td> </tr> <tr> <td colspan="2">Return humidity alarm</td> <td style="text-align: center;"><b>P3</b></td> </tr> <tr> <td>Low humidity</td> <td style="text-align: right;">15%</td> <td></td> </tr> <tr> <td>High humidity</td> <td style="text-align: right;">95%</td> <td style="text-align: center;"></td> </tr> <tr> <td colspan="2">Air outlet temperature alarm</td> <td style="text-align: center;"></td> </tr> <tr> <td>Low temperature</td> <td style="text-align: right;">8°C</td> <td></td> </tr> <tr> <td>High temperature</td> <td style="text-align: right;">32°C</td> <td></td> </tr> </table> </div>	Air return temperature alarm			High temperature	45°C		Return humidity alarm		<b>P3</b>	Low humidity	15%		High humidity	95%		Air outlet temperature alarm			Low temperature	8°C		High temperature	32°C	
Air return temperature alarm																											
High temperature	45°C																										
Return humidity alarm		<b>P3</b>																									
Low humidity	15%																										
High humidity	95%																										
Air outlet temperature alarm																											
Low temperature	8°C																										
High temperature	32°C																										
Air outlet temperature limit																											
High temperature	45°C	0–50°C																									
Return humidity alarm																											
Low humidity	15%	0–95%																									
High humidity	95%	0–100%																									
Air outlet temperature alarm																											
Low temperature	8°C	0–13°C																									
High temperature	32°C	0–25°C																									
<b>Item</b>	<b>Default</b>	<b>Range</b>	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; font-size: small;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>BMS control</td> <td style="text-align: right;">YES</td> <td style="text-align: center;"></td> </tr> <tr> <td>Modbus address</td> <td style="text-align: right;">0</td> <td></td> </tr> <tr> <td>Communication speed</td> <td style="text-align: right;">9600</td> <td style="text-align: center;"><b>P4</b></td> </tr> <tr> <td>New user password</td> <td style="text-align: right;">0</td> <td></td> </tr> <tr> <td colspan="2" style="padding-top: 10px;"> <div style="display: flex; justify-content: space-between; font-size: x-small;"> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px;">Date Time</div> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px;">Touch Screen Sound ON/OFF</div> </div> </td> <td style="text-align: center;"></td> </tr> <tr> <td colspan="2"></td> <td style="text-align: center;"></td> </tr> </table> </div>	BMS control	YES		Modbus address	0		Communication speed	9600	<b>P4</b>	New user password	0		<div style="display: flex; justify-content: space-between; font-size: x-small;"> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px;">Date Time</div> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px;">Touch Screen Sound ON/OFF</div> </div>											
BMS control	YES																										
Modbus address	0																										
Communication speed	9600	<b>P4</b>																									
New user password	0																										
<div style="display: flex; justify-content: space-between; font-size: x-small;"> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px;">Date Time</div> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px;">Touch Screen Sound ON/OFF</div> </div>																											
																											
BMS control	YES	NO																									
Modbus address	0	0–255																									
Communication speed	9600	4800/9600/19200																									
New user password	1000	0–65535																									
<p>Press <b>Date Time</b> to show the date and time.</p> <p>Press <b>Touch Screen Sound</b> to turn the sound on or off.</p>																											

Maintenance																
Description	Screen															
<p><b>Path: Main &gt; Maintenance</b></p> <p>IDU board version: SE_IDC_EN1.3                      ODU board version: SE_ODC_EN1.3                      HMI version: SE_HMIC_EN 1.3</p> <table border="1"> <thead> <tr> <th>Item</th> <th>Default</th> <th>Range</th> </tr> </thead> <tbody> <tr> <td>Outlet temperature for unit off</td> <td>19°C</td> <td>14–24°C</td> </tr> </tbody> </table>	Item	Default	Range	Outlet temperature for unit off	19°C	14–24°C	<div style="text-align: right;">2019-03-20 16:11</div> <div style="display: flex; justify-content: space-between; align-items: center;"> <div style="display: flex; gap: 10px;"> <div style="border: 1px solid black; padding: 2px; font-size: 8px;">Touch Screen Sound ON/OFF</div> <div style="border: 1px solid black; padding: 2px; font-size: 8px;">Alarm Sound ON/OFF</div> <div style="border: 1px solid black; padding: 2px; font-size: 8px;">Restart Touch Screen</div> </div> <div style="text-align: center;">   <b>F1</b> </div> </div> <table border="1" style="width: 100%; font-size: 8px;"> <tbody> <tr> <td>Outlet temperature off</td> <td>19°C</td> </tr> <tr> <td>IDU board version</td> <td>SE_IDC_EN 1.3</td> </tr> <tr> <td>ODU board version</td> <td>SE_ODC_EN 1.3</td> </tr> <tr> <td>HMI version</td> <td>SE_HMIC_EN 1.3</td> </tr> </tbody> </table> <div style="text-align: center;">    </div> <div style="text-align: right; font-size: 8px;">HMI1202-2016</div>		Outlet temperature off	19°C	IDU board version	SE_IDC_EN 1.3	ODU board version	SE_ODC_EN 1.3	HMI version	SE_HMIC_EN 1.3
Item	Default	Range														
Outlet temperature for unit off	19°C	14–24°C														
Outlet temperature off	19°C															
IDU board version	SE_IDC_EN 1.3															
ODU board version	SE_ODC_EN 1.3															
HMI version	SE_HMIC_EN 1.3															
<p>Select <b>YES</b> for manual operation.                      Select <b>Manual</b> and <b>ON</b> from the drop-down lists.</p>	<div style="text-align: right;">2019-03-20 16:11</div> <table border="1" style="width: 100%; font-size: 8px;"> <tbody> <tr> <td>Manual operation</td> <td>NO</td> </tr> <tr> <td>Serious alarm</td> <td>Auto OFF</td> </tr> <tr> <td>Common alarm</td> <td>Auto OFF</td> </tr> <tr> <td>Condensation pump</td> <td>Auto OFF</td> </tr> <tr> <td>PTC heater</td> <td>Auto OFF</td> </tr> <tr> <td>IDU fan</td> <td>Auto OFF</td> </tr> <tr> <td>SV low temperature kit</td> <td>Auto OFF</td> </tr> </tbody> </table> <div style="text-align: center;">   <b>F2</b> </div> <div style="text-align: center;">    </div> <div style="text-align: right; font-size: 8px;">HMI1202-2016</div>		Manual operation	NO	Serious alarm	Auto OFF	Common alarm	Auto OFF	Condensation pump	Auto OFF	PTC heater	Auto OFF	IDU fan	Auto OFF	SV low temperature kit	Auto OFF
Manual operation	NO															
Serious alarm	Auto OFF															
Common alarm	Auto OFF															
Condensation pump	Auto OFF															
PTC heater	Auto OFF															
IDU fan	Auto OFF															
SV low temperature kit	Auto OFF															
IDU maintenance information	<div style="text-align: right;">2019-03-20 16:11</div> <table border="1" style="width: 100%; font-size: 8px;"> <tbody> <tr> <td>IDU fan speed</td> <td>Auto</td> <td>0.0V</td> </tr> <tr> <td>IDU EEV steps</td> <td>Auto</td> <td>0</td> </tr> </tbody> </table> <div style="text-align: center;">   <b>F3</b> </div> <div style="text-align: center;">    </div> <div style="text-align: right; font-size: 8px;">HMI1202-2016</div>		IDU fan speed	Auto	0.0V	IDU EEV steps	Auto	0								
IDU fan speed	Auto	0.0V														
IDU EEV steps	Auto	0														
IDU maintenance information	<div style="text-align: right;">2019-03-20 16:11</div> <table border="1" style="width: 100%; font-size: 8px;"> <tbody> <tr> <td>Modify run hours</td> <td></td> </tr> <tr> <td>IDU fan hours reset</td> <td>NO</td> </tr> <tr> <td>#1 Compressor hours reset</td> <td>NO</td> </tr> <tr> <td>Threshold running hours alarm</td> <td></td> </tr> <tr> <td>IDU fan</td> <td>0.0 h</td> </tr> </tbody> </table> <div style="text-align: center;">   <b>F4</b> </div> <div style="text-align: center;">    </div> <div style="text-align: right; font-size: 8px;">HMI1202-2016</div>		Modify run hours		IDU fan hours reset	NO	#1 Compressor hours reset	NO	Threshold running hours alarm		IDU fan	0.0 h				
Modify run hours																
IDU fan hours reset	NO															
#1 Compressor hours reset	NO															
Threshold running hours alarm																
IDU fan	0.0 h															
IDU maintenance information for temperature and humidity	<div style="text-align: right;">2019-03-20 16:11</div> <table border="1" style="width: 100%; font-size: 8px;"> <tbody> <tr> <td>Probe setting</td> <td></td> </tr> <tr> <td>Air outlet temperature</td> <td>0.0°C</td> </tr> <tr> <td>Coil inlet temperature</td> <td>0.0°C</td> </tr> <tr> <td>Coil outlet temperature</td> <td>0.0°C</td> </tr> <tr> <td>Air return temperature</td> <td>0.0°C</td> </tr> <tr> <td>Air return humidity</td> <td>0.0%</td> </tr> </tbody> </table> <div style="text-align: center;">   <b>F5</b> </div> <div style="text-align: center;">    </div> <div style="text-align: right; font-size: 8px;">HMI1202-2016</div>		Probe setting		Air outlet temperature	0.0°C	Coil inlet temperature	0.0°C	Coil outlet temperature	0.0°C	Air return temperature	0.0°C	Air return humidity	0.0%		
Probe setting																
Air outlet temperature	0.0°C															
Coil inlet temperature	0.0°C															
Coil outlet temperature	0.0°C															
Air return temperature	0.0°C															
Air return humidity	0.0%															
Press the appropriate buttons to clear and download alarm or date.	<div style="text-align: right;">2019-03-20 16:11</div> <table border="1" style="width: 100%; font-size: 8px;"> <tbody> <tr> <td>New maintenance password</td> <td>0</td> </tr> </tbody> </table> <div style="text-align: center;">   <b>F6</b> </div> <div style="text-align: center;">    </div> <div style="display: flex; justify-content: space-around; font-size: 8px; margin-top: 10px;"> <div style="border: 1px solid black; padding: 2px;">Clear History Alarm</div> <div style="border: 1px solid black; padding: 2px;">Clear History Date</div> <div style="border: 1px solid black; padding: 2px;">Download Alarm to U Disk</div> <div style="border: 1px solid black; padding: 2px;">Download Date to U Disk</div> </div> <div style="text-align: right; font-size: 8px;">HMI1202-2016</div>		New maintenance password	0												
New maintenance password	0															

Manufacturer																																	
Description	Screen																																
<p><b>Path: Main &gt; Manufacturer</b> Enter a new manufacturer password.</p>	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; border-bottom: 1px solid black; margin-bottom: 5px;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">Default value</td> <td style="width: 20%;">NO</td> <td rowspan="2" style="width: 20%; text-align: center; vertical-align: middle;"></td> </tr> <tr> <td>New manufacturer password</td> <td>0</td> </tr> </table> <div style="margin-top: 10px; text-align: center;"> <div style="display: flex; justify-content: space-around; gap: 10px;"> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px; font-size: 8px;">Configuration Management</div> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px; font-size: 8px;">Parameters</div> <div style="border: 1px solid black; border-radius: 5px; padding: 2px 5px; font-size: 8px;">Timing</div> </div> </div> </div>		Default value	NO		New manufacturer password	0																										
Default value	NO																																
New manufacturer password	0																																
<p><b>Path: Main &gt; Manufacturer &gt; Configuration Management</b></p> <table style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="text-align: left;">Item</th> <th style="text-align: left;">Default</th> <th style="text-align: left;">Option</th> </tr> </thead> <tbody> <tr> <td>BMS Network</td> <td>Standard</td> <td>Custom</td> </tr> <tr> <td>DI1 Function selection</td> <td>Fire/Smoke</td> <td>Remote</td> </tr> <tr> <td>Condensation pump alarm</td> <td>NO</td> <td>YES</td> </tr> <tr> <td>Water on floor</td> <td>NO</td> <td>YES</td> </tr> <tr> <td>Maintenance alarm</td> <td>YES</td> <td>NO</td> </tr> </tbody> </table>	Item	Default	Option	BMS Network	Standard	Custom	DI1 Function selection	Fire/Smoke	Remote	Condensation pump alarm	NO	YES	Water on floor	NO	YES	Maintenance alarm	YES	NO	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; border-bottom: 1px solid black; margin-bottom: 5px;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">BMS Network</td> <td style="width: 20%;">Standard</td> <td rowspan="6" style="width: 20%; text-align: center; vertical-align: middle;"></td> </tr> <tr> <td>DI1 Function selection</td> <td>Fire/Smoke</td> </tr> <tr> <td>Condensation pump alarm</td> <td>NO</td> </tr> <tr> <td>Water on floor</td> <td>NO</td> </tr> <tr> <td>Maintenance alarm</td> <td>YES</td> </tr> <tr> <td></td> <td></td> </tr> </table> </div>		BMS Network	Standard		DI1 Function selection	Fire/Smoke	Condensation pump alarm	NO	Water on floor	NO	Maintenance alarm	YES		
Item	Default	Option																															
BMS Network	Standard	Custom																															
DI1 Function selection	Fire/Smoke	Remote																															
Condensation pump alarm	NO	YES																															
Water on floor	NO	YES																															
Maintenance alarm	YES	NO																															
BMS Network	Standard																																
DI1 Function selection	Fire/Smoke																																
Condensation pump alarm	NO																																
Water on floor	NO																																
Maintenance alarm	YES																																
<p><b>Path: Main &gt; Manufacturer &gt; Parameters</b></p> <table style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="text-align: left;">Item</th> <th style="text-align: left;">Default</th> </tr> </thead> <tbody> <tr> <td>Maximum speed of EC/DC fan</td> <td>10</td> </tr> <tr> <td>Maximum speed of EC/DC fan</td> <td>10</td> </tr> <tr> <td>Failure speed of EC/DC fan</td> <td>10</td> </tr> <tr> <td>Dehumidifying speed of EC/DC fan</td> <td>5</td> </tr> </tbody> </table>	Item	Default	Maximum speed of EC/DC fan	10	Maximum speed of EC/DC fan	10	Failure speed of EC/DC fan	10	Dehumidifying speed of EC/DC fan	5	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; border-bottom: 1px solid black; margin-bottom: 5px;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">Maximum speed of EC/DC fan</td> <td style="width: 20%;">0.0 V</td> <td rowspan="4" style="width: 20%; text-align: center; vertical-align: middle;"></td> </tr> <tr> <td>Minimum speed of EC/DC fan</td> <td>0.0 V</td> </tr> <tr> <td>Failure speed of EC/DC fan</td> <td>0.0 V</td> </tr> <tr> <td>Dehumidifying speed EC/DC fan</td> <td>0.0 V</td> </tr> </table> </div>		Maximum speed of EC/DC fan	0.0 V		Minimum speed of EC/DC fan	0.0 V	Failure speed of EC/DC fan	0.0 V	Dehumidifying speed EC/DC fan	0.0 V												
Item	Default																																
Maximum speed of EC/DC fan	10																																
Maximum speed of EC/DC fan	10																																
Failure speed of EC/DC fan	10																																
Dehumidifying speed of EC/DC fan	5																																
Maximum speed of EC/DC fan	0.0 V																																
Minimum speed of EC/DC fan	0.0 V																																
Failure speed of EC/DC fan	0.0 V																																
Dehumidifying speed EC/DC fan	0.0 V																																
<p><b>Path: Main &gt; Manufacturer &gt; Timing</b></p> <table style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="text-align: left;">Item</th> <th style="text-align: left;">Default</th> </tr> </thead> <tbody> <tr> <td>Delay time to stop fan</td> <td>5 seconds</td> </tr> <tr> <td>Delay alarm low/high temperature</td> <td>30 seconds</td> </tr> <tr> <td>Delay alarm condensation pump</td> <td>5 seconds</td> </tr> <tr> <td>Delay alarm output</td> <td>10 seconds</td> </tr> </tbody> </table>	Item	Default	Delay time to stop fan	5 seconds	Delay alarm low/high temperature	30 seconds	Delay alarm condensation pump	5 seconds	Delay alarm output	10 seconds	<div style="border: 1px solid black; padding: 5px;"> <div style="text-align: right; border-bottom: 1px solid black; margin-bottom: 5px;">2019-03-20 16:11</div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 60%;">Delay time to stop fan</td> <td style="width: 20%;">5 seconds</td> <td rowspan="4" style="width: 20%; text-align: center; vertical-align: middle;"></td> </tr> <tr> <td>Delay alarm low/high temperature</td> <td>30 seconds</td> </tr> <tr> <td>Delay alarm condensation pump</td> <td>5 seconds</td> </tr> <tr> <td>Delay alarm output</td> <td>10 seconds</td> </tr> </table> </div>		Delay time to stop fan	5 seconds		Delay alarm low/high temperature	30 seconds	Delay alarm condensation pump	5 seconds	Delay alarm output	10 seconds												
Item	Default																																
Delay time to stop fan	5 seconds																																
Delay alarm low/high temperature	30 seconds																																
Delay alarm condensation pump	5 seconds																																
Delay alarm output	10 seconds																																
Delay time to stop fan	5 seconds																																
Delay alarm low/high temperature	30 seconds																																
Delay alarm condensation pump	5 seconds																																
Delay alarm output	10 seconds																																

# Maintenance

## Preventive Maintenance

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- This equipment must be installed and serviced by qualified personnel only.
- Turn off all power supplying this equipment before working on or inside the equipment.
- Replace all devices, doors, and covers before turning on power to this equipment.

**Failure to follow these instructions will result in death or serious injury.**

### **WARNING**

#### **HAZARD TO EQUIPMENT OR PERSONNEL**

All work must be performed by Schneider Electric qualified personnel.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

Perform the following maintenance check list.

Prepared By: \_\_\_\_\_

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Date: \_\_\_\_\_



## Electrical Maintenance

Perform visual inspection and processing of electrical connections.

- Perform a total electrical insulation test. Find the non-conforming contacts for processing. Disconnect the control switch or air switch during the test to avoid any damage to the control device from high voltage.
- Statically detect whether each contactor is pulled in flexibly without jamming.
- Remove dust from the electrical and control components with a brush or dry compressed air.
- Check for arcing or burn marks on the contacts. Replace the contactor if necessary.
- Fasten each electrical connection terminal.
- Check whether the quick connector is in good contact and replace the terminal if necessary.
- Check the appearance of the adapter and test its output voltage for the indoor and outdoor units.
- Check the output connection from the control interface board to each contactor and the input connection of the high and low voltage switches, and filter plug switch. Replace the plug terminal immediately if it is loose or has bad contacts.
- Replace the control fuse (or air switch), control board, and other electrical components if necessary.

## Control Maintenance

Perform visual inspection and simple function testing of the control segment for processing.

- Check for obvious aging on the surface of the control interface board and the display control board.
- Remove the dust and dirt on the control components and control boards with a brush and an electronic dedusting agent.
- Check and fasten the I/O plug interface of the control interface board, including the connection between the display control board and the control interface board and the connection between the control interface board and the temperature and humidity sensor board.
- Check the specifications and aging of the control wire and the power wire and replace if necessary.
- Check and calibrate the readings of the temperature and humidity sensor with an instrument of high measuring accuracy. Select relative humidity control as the humidity control mode.
- Clean the air filter net. Place on a hard surface and gently tap to remove heavy particles. If necessary, wash the filter with a neutral detergent in warm water and dry it before re-installation.
- Use a vacuum cleaner and a nylon brush to clean the dust and other debris on the surface of the heat exchanger. If a compressed air source is available, use the compressor to spray the dust off the surface.
- Regularly check the motor, impeller, and other components of the fan. If necessary, consult the manufacturer for more details.
- Before operating the unit, ensure the drainage pipe is not blocked.

# Worldwide Customer Support

Customer support for this or any other product is available at no charge in any of the following ways:

- Visit the Schneider Electric Web site to access documents in the Schneider Electric Knowledge Base and to submit customer support requests.
  - **[www.schneider-electric.com](http://www.schneider-electric.com)** (Corporate Headquarters)  
Connect to localized Schneider Electric Web sites for specific countries, each of which provides customer support information.
  - **[www.schneider-electric.com/support/](http://www.schneider-electric.com/support/)**  
Global support searching Schneider Electric Knowledge Base and using esupport.
- Contact the Schneider Electric Customer Support Center by telephone or e-mail.  
Local, country-specific centers: go to *[www.schneider-electric.com/support/contact](http://www.schneider-electric.com/support/contact)***[www.schneider-electric.com](http://www.schneider-electric.com)** > **Support** > **Operations around the world** for contact information.

For information on how to obtain local customer support, contact the representative or other distributors from whom you purchased your product.



Schneider Electric (China) Co., Ltd Shanghai Pu Dong Branch  
4F Building 9, No 3000 Long Dong Avenue, 201203  
Pu Dong, Shanghai  
People's Republic of China

[www.schneider-electric.com](http://www.schneider-electric.com)

As standards, specifications, and design change from time to time,  
please ask for confirmation of the information given in this publication.

© 2019 – 2019 Schneider Electric. All rights reserved.

990-6186-001