


# Server Technology

A brand of  legrand

stay powered. be supported. get ahead.



## PRO3X User Guide

### Features

1-800-835-1515  
sales@servertech.com  
www.servertech.com

**Instructions**

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**Dangerous Voltage**

This symbol is intended to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

**Protective Grounding Terminal**

This symbol indicates a terminal that must be connected to earth ground prior to making any other connections to the equipment.

**Life-Support Policy**

As a general policy, Server Technology® does not recommend the use of any of its products in the following situations:

- life-support applications where failure or malfunction of the Server Technology product can be reasonably expected to cause failure of the life-support device or to significantly affect its safety or effectiveness.
- direct patient care.

Server Technology will not knowingly sell its products for use in such applications unless it receives in writing assurances satisfactory to Server Technology that:

- the risks of injury or damage have been minimized,
- the customer assumes all such risks, and
- the liability of Server Technology is adequately protected under the circumstances.

The term life-support device includes but is not limited to neonatal oxygen analyzers, nerve stimulators (whether used for anesthesia, pain relief or other purposes), auto-transfusion devices, blood pumps, defibrillators, arrhythmia detectors and alarms, pacemakers, hemodialysis systems, peritoneal dialysis systems, neonatal ventilator incubators, ventilators (for adults or infants), anesthesia ventilators, infusion pumps, and any other devices designated as "critical" by the U.S. FDA.

**Notices**

301-9999-52 Rev A (041520)

Copyright © 2005-2020 Server Technology, Inc. All rights reserved.

1040 Sandhill Drive

Reno, Nevada 89521 USA

**All Rights Reserved**

This publication is protected by copyright and all rights are reserved. No part of it may be reproduced or transmitted by any means or in any form, without prior consent in writing from Server Technology.

The information in this document has been carefully checked and is believed to be accurate. However, changes are made periodically. These changes are incorporated in newer publication editions. Server Technology may improve and/or change products described in this publication at any time. Due to continuing system improvements, Server Technology is not responsible for inaccurate information which may appear in this manual. For the latest product updates, consult the Server Technology web site at [www.servertech.com](http://www.servertech.com). In no event will Server Technology be liable for direct, indirect, special, exemplary, incidental, or consequential damages resulting from any defect or omission in this document, even if advised of the possibility of such damages.

In the interest of continued product development, Server Technology reserves the right to make improvements in this document and the products it describes at any time, without notices or obligation.

The Globe logo is a trademark of Server Technology, Inc., registered in the US. Use of the logos for commercial purposes without the prior written consent of Server Technology may constitute trademark infringement and unfair competition in violation of federal and state laws.

Server Technology, the Globe logo, Sentry, Switched CDU, CDU, PRO2, PIPS, POPS, PDU Power Pivot, and StartUp Stick are trademarks of Server Technology, Inc., registered in the US. EZip is a trademark of Server Technology.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Server Technology, Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

**Please Recycle**

Shipping materials are recyclable. Please save them for later use, or dispose of them appropriately.

## About Your Features Guide

This Features guide was designed for data center staff and administrators who monitor power, control outlet actions, and direct equipment operations in the data center network using the PRO3X product group.

This guide introduces you to the key features of the PRO3X. Descriptions, photos, illustrations, screen examples, and step-by-step, task-based instructions provide a collection of the innovative and high-density operational features that make the PRO3X a unique and cost-effective PDU.



stay powered.



be supported.



get ahead.

## Contact Technical Support



be supported.

### **Experience Server Technology's FREE Technical Support**

Server Technology understands that there are often questions when installing and/or using a new product. Free Technical Support is provided from 8 a.m. to 5 p.m. Pacific Time, Monday through Friday.

Server Technology, Inc. (a brand of Legrand)

1040 Sandhill Road

Tel: 1-800-835-1515

Web: [www.servertech.com](http://www.servertech.com)












Reno, Nevada 89521 USA

Fax: 775-284-2065

Email: [support@servertech.com](mailto:support@servertech.com)

# Safety Precautions

This section contains important safety/regulatory information that must be reviewed before installing and using the PRO3X PDU.

|   |   |  |   |
|---|---|--|---|
|    | Only for installation and use in a Restricted Access Location in accordance with the following installation and use instructions.<br><br><b>This equipment should only be installed by trained personnel.</b>   | Destiné à l'installation et l'utilisation dans le cadre de Restricted Access Location selon les instructions d'installation et d'utilisation.<br><br><b>Cet équipement est uniquement destiné à être installé par personnel qualifié.</b>  | Nur für Installation und Gebrauch in eingeschränkten Betriebszonen gemäß der folgenden Installations- und Gebrauchsanweisungen.<br><br><b>Dieses Gerät ist nur für den Einbau durch Personal vorgesehen.</b>  |
|    | This equipment is designed to be installed on a dedicated circuit. The power supply cord shall be a minimum of 1.5m (4.9ft) and a maximum of 4.5m (15ft). If using an extension power cord, the total length shall also be no more than the maximum allowed. The plug is considered the disconnect device and must be easily accessible.  | Cet équipement a été conçu pour être installé que un circuit dédié. Le cordon d'alimentation doit être d'au moins 1,5M et un maximum de 4,5m. Si vous utilisez un cordon de rallonge, la longueur totale est également plus que le maximum autorise. La prise est considérée comme un dispositif de coupure et doit être facilement accessible.  | Die Geräte sind für eine Installation an einer fest zugeordneten Leitung ausgelegt. Die Stromzuleitung hat eine Mindestlänge von 1,5m, und höchstens 4,5m. Sollten Sie ein Verlängerungsnetz Kabel, der Gesamtlänge auch nicht mehr als die maximal zulässige sein. Der Stecker dient zur Trennung vom Netz und muss einfach erreichbar sein.   |
|    | The dedicated circuit must have circuit breaker or fuse protection. PDUs have been designed without a master circuit breaker or fuse to avoid becoming a single point of failure. It is the customer's responsibility to provide adequate protection for the dedicated power circuit. Protection of capacity equal to the current rating of the PDU must be provided and must meet all applicable codes and regulations. In North America, protection must have a 10,000A interrupt capacity. | Le circuit spécialisé doit avoir un disjoncteur ou une protection de fusible. PDUs ont été conçus sans disjoncteur général ni fusible pour éviter que cela devient un seul endroit de panne. C'est la responsabilité du client de fournir une protection adéquate pour le circuit-alimentation spécialisé. Protection de capacité équivalent à la puissance de l'équipement, et respectant tous les codes et normes applicables. Les disjoncteurs ou fusibles destinés à l'installation en Amérique du Nord doivent avoir une capacité d'interruption de 10.000 A. | Der feste Stromkreis muss mit einem Schutzschalter oder einem Sicherungsschutz versehen sein. PDUs verfügt über keinen Hauptschutzschalter bzw. über keine Sicherung, damit kein einzelner Fehlerpunkt entstehen kann. Der Kunde ist dafür verantwortlich, den Stromkreis sachgemäß zu schützen. Der Kapazitätsschutz entspricht der aktuellen Stromstärke der Geräte und muss alle relevanten Codes und Bestimmungen erfüllen. Für Installation in Nordamerika müssen Ausschalter bzw. Sicherung über 10.000 A Unterbrechungskapazität verfügen. |
|  | Models with unterminated power cords: Input connector must be installed by qualified service personnel. Input connector rating must meet all applicable codes and regulations.  | Modèles avec cordons d'alimentation non terminées: Le connecteur d'entrée doit être installé par un personnel qualifié. Entrée cote de raccordement doit respecter tous les codes et règlements électriques applicables.   | Modelle mit nicht abgeschlossenen Netzkabel: Der Eingangsstecker darf nur von qualifiziertem Wartungspersonal installiert werden. Eingangsanschluss Bewertung müssen alle geltenden und verbindlichen Normen und Vorschriften entsprechen.  |
|  | Do not block venting holes when installing this product. Allow for maximum airflow at all times.  | Ne bloquez pas les orifices d'aération lors de l'installation de ce produit. Permettre une circulation d'air maximale à tout moment.   | Achten Sie darauf, dass keine Belüftungslöcher bei der Installation dieses Produkts. Damit für maximalen Luftstrom zu allen Zeiten.   |
|  | Installation Orientation: Vertical units are designed to be installed in vertical orientation.  | Installation Orientation: Les unités vertical sont conçues pour être installées dans une orientation verticale.  | Installationsausrichtung: Vertical Einheiten sind zur vertikalen Installation vorgesehen.   |
|  | Always disconnect the power supply cord before servicing to avoid electrical shock. For products with two input power cords, both must be disconnected before servicing.  | Toujours débrancher le cordon d'alimentation avant de l'ouverture pour éviter un choc électrique. Pour les produits avec deux cordons d'alimentation d'entrée, les deux doivent être déconnectés avant l'entretien.  | Trennen Sie das Netzkabel, bevor Sie Wartungsarbeiten Öffnung einen elektrischen Schlag zu vermeiden. Für Produkte mit zwei Eingangsstromkabel, sowohl, müssen vor der Wartung abgeschaltet werden.   |
|  | WARNING! High leakage current! Earth connection is essential before connecting supply!  | ATTENTION! Haut fuite très possible! Une connection de masse est essentielle avant de connecter l'alimentation !   | ACHTUNG! Hoher Ableitstrom! Ein Erdungsanschluss ist vor dem Einschalten der Stromzufuhr erforderlich!  |
|  | WARNING! Cx-xxE-x units double pole/neutral fusing  | ATTENTION! Les unités Cx-xxE-x Double Pôle/Fusible sur le Neutre   | ACHTUNG!: Cx-xxE-x Zweipolige bzw. Neutraleiter-Sicherung   |
|  | ATTENTION! Observe precautions for handling Electrostatic Sensitive Devices.  | Attention ! Respecter les mesures de sécurité en manipulant des dispositifs sensibles aux décharges électrostatiques.  | Achtung! Vorsichtshinweise zur Handhabung elektrostatisch empfindlicher Geräte beachten.  |
|  | Products rated for 240/415VAC may be fitted with a plug that is rated for a higher voltage. Caution must be taken to assure that the rating of the unit and the supply voltage match.   | Les produits prévus pour 240/415VAC peut être équipé d'un bouchon qui est conçu pour une tension plus élevée. Des précautions doivent être prises pour assurer que la cote de l'unité et la tension d'alimentation correspond.   | Produkte die für 240/415VAC zugelassen sind können mit einem Stecker der für eine höhere Spannung ausgestattet sein. Vorsicht ist geboten, um sicherzustellen, dass die erlaubten Betriebswerte des Gerätes und der Versorgungsspannung zueinander passen.  |

---

## Attaching Safety Earth Ground Connection

Server Technology PDUs are supplied with an external safety ground connection to provide an alternate ground path for fault currents, and to maintain the same ground reference between it and the equipment rack.


**Note:** The auxiliary external ground location may vary. Most PDUs will have it located near the power cord entry located near the ⚠ symbol.

### User-Supplied Materials:

- One 5 mm internal (or external) tooth star washer;
- One 4.0 mm<sup>2</sup> (10 AWG) wire with 5 mm ring terminal;
- One metric M5 x 6 mm coarse pitch screw.

### Instructions:

1. Connect one end of the ground wire to the equipment cabinet or local ground.
2. Locate the PDU external ground near the ⚠ symbol.
3. Connect the other end with a ring terminal and a M5 screw to the PDU external ground. To ensure proper grounding to chassis, use a star washer between ring terminal and PDU.



## Chapter 1: Introducing the PRO3X

**PRO3X is Server Technology's unique HDOT Cx PDU**, the industry standard for hyperscale critical facilities, focusing on an innovative rack design to minimize network drops and to assist with load balancing. Further, the PRO3X provides the unmatched flexibility and density of **HDOT Cx outlet technology** – Server Technology's own leading-edge universal outlet that automatically increases outlet count.

The flexible, high-temperature PRO3X PDU contains PIPS and POPS technology, as well as Branch Current Metrics, similar to the PRO2 PDU.

The PRO3X is designed for roll-out in select SKUs, including Smart and Switched POPS models, to be followed by the Switched PRO3X PDU.




---

### What's Unique About the PRO3X?

**Note:** Although the PRO3X is an additional trusted PDU offering from Server Technology and retains primary Server Technology features, the PRO3X is a limited range PDU and does not replace Server Technology's flagship PRO2 PDU.

The PRO3X PDU is designed with first-time industry features:

- The unique combination of the latest **Server Technology-branded PDU platform and its innovative HDOT Cx outlet using the Raritan controller**. The HDOT Cx outlet is the advanced and flexible outlet design that allows a single PDU for many applications. The controller, or network card, is the **NIM8G Xerus**, which is the industry communication standard for many high-density data centers.
- **Raritan Xerus firmware stack and API, a new MIB, and Server Technology hardware mounting**. The Raritan firmware stack provides interface and communication (GUI and CLI functions) with the Server Technology.
- The added feature of the **Server Technology-style of PDU linking and outlet grouping** for all master units (link up to 8 units), with redundant backup power from the first link unit to keep the network card up should power fail on the master unit.
- A fixed 36-outlet design for all PRO3X models, as 36 outlets is the most common HDOT outlet count, with **RAMLock outlet retention mechanism**. The RAMLock outlets are spaced evenly across the length of the PDU for easy cable management. PRO3X outlets include a combination of the HDOT C13 and the innovated Server Technology HDOT Cx hybrid outlet that accepts either C14 or C20 plugs.
- Similar to Raritan PDUs, the PRO3X controller board has a central LCD display, while the PRO3X Switched and Switched POPS units have **easy to read LEDs where the Off LED is Off and the Green LED is On**, similar to other Server Technology PDUs.



**PRO3X Equipment View**

## Alternating Branch Metrics

Alternating phase technology is not available with the PRO3X. However, across the 36 locking outlets, **alternating branch-current metrics** are available on all PRO3X units, divided into 18 HDOT and 18 HDOT Cx outlets.

This means each branch carries a phase. An example of alternating branch in the PRO3X unit design is the following layout:

L1 > L2 > L3 > L1 > L2 > L3.



**PRO3X and Divided HDOT C13 and HDOT Cx Outlets**



---

## Product Specifications

The following items define the PRO3X design:

- 2.2" Wide x 2.5" Deep x 70" Tall
- RAMLock Locking Outlets – 36 evenly-spaced outlets (18 HDOT C13 and 18 HDOT Cx) over the length of the entire PDU using a self-latching, cam-style locking mechanism.
- Fixed Cord Length (Customizable)
- Central LCD Display with Auto-Flip
- Non-Latching relays
- Easy to Read Outlet LEDs (Off LED is Off and Green LED is On)
- Multiple Accessories: Cameras, Wi-Fi, Cabinet, Door Locks, Environmental Sensors

---

## Available Models

The initial phase of the PRO3X is available in 12 configurations with the following electrical circuits:

- Single Phase 30A
- 3PH Delta 30A
- 3PH Delta 60A
- 3PH Wye 32A



---

## PRO3X Direct KVM Remote Power Control

**Note:** Not available with Raritan Dominion Appliances.

### How Direct KVM Remote Power Control Works

- The D2CIM-PWR connects from the Dominion switches to PX PDU feature ports
- No feature port on the PRO3X network card NIM8G
- No PRO3X remote power control via the D2CIM-PWR to the DKX3-xxx, DSX2-xxx, and other products supporting that CIM
- DSX2-xxx products would also not support remote power control
- Remote power control will be available via Raritan CommandCenter via SMNP for PRO3X PDU's with outlet switching.



## Chapter 2: Outlet Locking (RAMLock)



The RAMLock mechanism provides maximum outlet retention, designed exclusively for the PRO3X with an innovative, easy-to-use design.



### RAMLock Retention Mechanism

RAMLock is an ergonomic locking arm, does not require tools or other locking cords, and allows single-hand removal of a cord with the quick press of the lever.



### RAMLock Outlets on the PRO3X

On the PRO3X PDU, the RAMLock locking outlets are 36 evenly-spaced outlets (18 HDOT C13 and 18 HDOT Cx) over the length of the entire unit using a self-latching, cam-style locking mechanism.


RAMLock works when the blade of the locking mechanism goes against the shell of the plug. With this mechanism, RAMLock provides enough retention for security but not so much retention to require tools or both hands to unplug the cable.

The benefit in the data center is the easy and convenient retaining of a cable using only one hand. In addition, RAMLock cords cannot be bumped or vibrated out.

## Chapter 3: NIM8G Controller Board

Server Technology's PRO3X PDU was designed with a new NIM controller board, the Raritan NIM8G Xerus, the industry communication standard for many high-density data centers.

The following graphics illustrate the NIM8G controller board, including port connections:



### Highlights of the NIM8G Controller Board:

- Hot-swappable (Contact Server Technology Technical Support to coordinate getting a new network card.)
- Redundant failover power through the first link PDU.
- V8-based controller designed for Server Technology's PRO3X form factor
- Color matrix LCD

---

## NIM8G Specifications

The definition of a V8-based controller is the micro-controller use of **ARM Cortex A5** (Atmel SAMA5D21) with **Xerus** open firmware architecture.

### CMA-NTWK-0024-01/PRG

- Micro-controller: ARM Cortex A5 500 MHz (Atmel SAMA5D21)
- Memory: 32M SPI Flash / 128M DDR2
- Interface (External):
  - 2x 10/100/1000 Ethernet
  - 1x USB 2.0 type B
  - 1x USB 2.0 type A
  - 1x Console/Modem
  - 1x PX Sensor
  - 1x STI Link Interface
- Interface (Internal):
  - 1x STI Internal I2C
- Display: TFT LCD
- No beeper

## Chapter 4: PRO3X Hardware Menu Options

The following displays are samples of the menu options you may see on your PRO3X unit for the PDU Linking feature. Each unit in a PDU Linking chain displays its own PDU data (inlets, outlets, sensors, alerts, etc.)

---

### Hardware Displays Examples for Master and Link Units

#### Master Unit:

From the following example of the master unit display, navigate the options for displaying Link PDU identification and status, and to confirm the master unit that is controlling the link unit in the chain.


- Can show alarms, which may be triggered by link units.
- PDU information shows a list of link units with host name/IP address, model, device name, serial number, firmware version, and communication status.

**Note:** These samples are generic and may not look exactly like the menu options and PRO3X product SKUs displayed on your PDU.



### Link Units:

- No display of alarms (no event engine on link units)
- PDU information shows the master IP address



## Chapter 5: PDU Linking on the PRO3X

### Overview

The PDU Linking feature allows the linking configuration of a single master PDU unit to multiple link units for faster and more efficient power management, as only one IP address is required to communicate with up to 8 linked units. Only one master unit is connected to the network in PDU Linking, which allows a cost-efficient PDU operation and networking infrastructure.

The master PDU is the first PDU in the chain. The user configures the PDU as the master during setup with up to seven link units connected in sequence in the chain. The master PDU has full knowledge of the location of the connected link units in the chain, as well as the power and environmental information of all link units.

When you create a master and link configuration in a chain, you log in to the master unit with visibility to control both the master unit and the connected link units from within the GUI, SNMP, and CLI.

The administrator privilege is required for all management actions (adding, configuring, releasing) of the PDU Linking feature. Each PDU in the chain can be monitored and managed from anywhere by the network protocols HTTP(S), SNMP, SSH, Telnet, and Modbus.

All units in the linked chain should be the same model PDU. All units must run the same firmware version, which can be upgraded respectively for each unit in the chain.

The first link unit can provide backup power to the master's network card to maintain connectivity in the event the master unit loses input power. This arrangement requires two cables between the master PDU and the first link unit. (See linking illustration on right.)



**PRO3X PDU Linking:** One master unit with up to seven link units. Two cables needed between the master and the first link unit – one for linking and the other for redundant back feed power.



---

## PDU Linking FAQs

### What's the difference between a "master unit" and a "link unit"?

Master and link units are the same model PDUs that are equal to each other, and each has its own IP address. You designate a PDU as the master unit by logging into the unit and then adding a link unit. The first unit becomes the master, and when the first link unit is added, the master unit is automatically assigned PDU ID "1", which is reserved to identify a master unit only, and the ID "1" cannot be edited. A connection between the master and the link unit has now occurred and the chain is formed.

As you continue to add link units to the chain as desired (up to seven link units), you select Link ID "2" through "8" for the Link ID numbers. (PDU ID "1" was reserved for the master). Notice that the Link ID "2-8" is the sequential number of each link unit that you select as you add the unit to the chain, and once selected, the Link ID cannot be edited.

When the chain is established with a single master unit, and one or more link units, communication occurs with the master unit through its IP address. The master unit, in turn, communicates to the other link units in the chain through their individual IP addresses, which optimizes power monitoring and PDU management.

### Which Server Technology PDUs can be linked?

With network connectivity, the PDU Linking feature supports PRO3X SKUs for Smart, Switched, and Switched POPS models. **Note:** All units in the linking chain should be the same PRO3X models.

### Can master units be linked together?

No. Once a unit is designated as the master unit in a chain, it cannot be linked to a master unit in another chain. A master unit can only be linked to one or more link units in a chain.

### How many units can be linked?

Including the master, a full chain can include a total of eight units. The first unit added is designated as the master unit with the ID "1". Each unit you then add to the chain is designated as a link unit, beginning with ID "2" and ending with ID "8".

### What is re-linking?

Re-linking is a required function when a link unit no longer recognizes or responds to the master unit, most likely caused if the link unit was reset to factory defaults. The status of the disassociated link unit will be displayed as "Access Denied". Selecting the link unit when in this status displays the Re-link button that allows reconnection of the link unit in the chain for regaining device control. **Note:** Re-linking uses the same Link Unit ID and hostname, but you will need to reauthenticate with your login credentials.

### What user privileges are required for managing the PDU Linking configuration?

Administrative privileges are required for both the master unit and link unit. To add a link, your administrative login account is required, but after that you only log in to the master to manage the chain, as all link units in the chain are visible in the user interface from the master unit view.

## What happens if the connection is lost between the master and link units?

If the network connection is lost, these link unit functions will still work:

- energy accumulation
- local display (regular metering values and alerts of raised thresholds)
- maintained outlet states

... and these link unit functions will stop working:

- event log entries are lost
- event engine rules/alarms
- remote access to the link unit
- synchronization of master settings and time when not using NTP

## Which system areas of the master and link units are automatically synchronized?

The master PDU periodically checks link unit reachability. You can define rules to be alerted when communication with a link unit fails, such as a system alarm. Some link unit settings are automatically synchronized with the master:

- Peripheral device settings
- Front panel privileges and default view
- USB host port lockdown
- Time and date settings
- General data logging settings

## How are firmware updates handled?

Uploaded firmware images in the GUI are automatically distributed to all link units at the same time. Starting a firmware update requires the same image to be uploaded to all units.

## Which network setup modes are supported by PDU Linking?

For the underlying network, the PDU Linking feature has multiple setup modes that can be used together with full-featured cascading:

*Independent PDU Setup:* All PDUs have their own regular IP address; they don't need to be in a physical chain to be logically chained; the user communicates only to the master using its normal IP address; the user configures networking of the units and then adds link unit via the Web GUI, CLI, or USB.

*Bridged Setup:* Same as Independent PDU Setup , but the PDUs are physically connected as a chain, either by ethernet or USB; the configuration steps are the same as with Independent PDU Setup.

*Port Forwarding Cascade:* The PDUs are physically connected as a chain, either by Ethernet or USB. Only the first PDU (which is the master) is connected to your network with the IP address you assigned; the other PDUs will get automatically-assigned private IP addresses which are not visible; you can configure both PDUs at one time with a USB stick, or configure the network first and then add link units.

**Note:** When referring to “cascading”, or the physical chaining of units, although the mixing of connection types (Ethernet and USB) is not recommended in the cascade, the mixing is possible with these restrictions:


- In Port Forwarding mode, you must build a single, linear chain where each unit has exactly one upstream device and optionally one downstream device.
- In Bridging mode, you must not build any loops; in other words, multiple paths between two units.

# PDU Linking in the Web GUI

## Designating the Master Unit

Log in to the PDU you want to designate as the master unit. When you add the first link unit, a chain is established between the master and the new link, and the master becomes ID “1”.

To view and manage a link chain, log in to the master unit, as displayed on the PDU page:



The PDU page displays the following information about the master PDU:

- Firmware Version
- Model
- Serial Number
- MAC Address
- Input Power Rating
- Data Log

**Note:** The ID of the master unit is automatically assigned the ID “1”, which cannot be edited.

## Adding a Link Unit

A link unit (up to seven units) can be added to a single master unit.

On the PDU page, the master unit is displayed as highlighted in the following screen example in red. Notice the following section “Link PDUs”, is designed for the PDU Linking feature, where multiple PDUs added to the chain are displayed as the link units. The Add Link PDU button, highlighted in green in the screen example, also displays in the Link PDUs section.

The screenshot displays the 'My PDU' management page. The left sidebar contains navigation options: Dashboard, PDU, Inlet, Outlets, Outlet Groups, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area is divided into several sections:

- Details:** A table with the following information:


|                  |                                      |
|------------------|--------------------------------------|
| Firmware version | 3.6.0.5-46586                        |
| Model            | PRO3X-SW-60A-Delta                   |
| Serial number    | 2BZ3700246                           |
| MAC address      | 00:0a:9c:25:00:f6                    |
| Rating           | 200-240V, 48A, 16.6-20.0kVA, 50/60Hz |
| Data log         | <a href="#">Export as CSV</a>        |
- Link PDUs:** A table with columns: # ▲, Host, Model, Status, Firmware. It shows 'No link PDUs configured.' and includes an [Add Link PDU](#) button (highlighted in green) and a [Release Link PDU](#) button.
- Settings:** A table with columns: Name, Value, and an [Edit Settings](#) link.

|   |                       |
|---|-----------------------|
| Name  | My PDU                |
| Outlet state on device startup                | last known            |
| Outlet initialization delay on device startup | 3 s                   |
| Power off period during power cycle           | 10 s                  |
| Inrush guard delay                            | 200 ms                |
| Reset all energy counters                     | <a href="#">Reset</a> |
- Sensors:** A table with columns: Sensor, Value, State.

|                      |  |    |
|----------------------|--|----|
| +12V Supply 1 Status |  | OK |
|----------------------|--|----|

**To add a link unit:**

1. Log in to the master PDU as shown displayed above in the PDU page.
2. Click Add Link PDU. The following add box displays:



3. The Link ID is populated as the next available ID number (2-8), assigned sequentially as each link unit is added to the chain to identify the link unit in the user interfaces. **Note:** From the drop-down, you can manually select the desired Link ID to order the link units in the chain as desired. Once associated with a link unit, the Link ID cannot be edited.
4. Provide the IP address of the link unit.
5. Provide the login credentials for the link unit. **Note:** If the link unit has factory settings, you will be prompted to set the new password.
6. Click Add.

The new link unit is added on the PDU page with the master unit, in a list in the Link PDUs section. All link units added to the chain in this way are now managed by the single master unit.

The screenshot shows the 'My PDU' management page. The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, Outlet Groups, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area is titled 'My PDU (1)' and is divided into several sections:

- Details:** A table showing device information:
 

|                  |                                      |
|------------------|--------------------------------------|
| Firmware version | 3.6.0.5-46586                        |
| Model            | PRO3X-SW-60A-Delta                   |
| Serial number    | 2BZ3700246                           |
| MAC address      | 00:0a:9c:25:00:f6                    |
| Rating           | 200-240V, 48A, 16.6-20.0kVA, 50/60Hz |
| Data log         | <a href="#">Export as CSV</a>        |
- Link PDUs:** A table listing connected link units:
 

| # ▲ | Host       | Model                   | Status | Firmware      |
|-----|------------|-------------------------|--------|---------------|
| 2   | 10.1.10.54 | PRO3X-C3S36RL-YCJE2MT3* | OK     | 3.6.0.5-46586 |

 Below the table are buttons for 'Add Link PDU' and 'Release Link PDU'.
- Settings:** A table of configuration parameters:
 

|   |                       |                               |
|---|-----------------------|-------------------------------|
| Name  | My PDU                | <a href="#">Edit Settings</a> |
| Outlet state on device startup                | last known            |                               |
| Outlet initialization delay on device startup | 3 s                   |                               |
| Power off period during power cycle           | 10 s                  |                               |
| Inrush guard delay                            | 200 ms                |                               |
| Reset all energy counters                     | <a href="#">Reset</a> |                               |
- Sensors:** A table showing sensor status:
 

| Sensor               | Value | State |
|----------------------|-------|-------|
| +12V Supply 1 Status |       | OK    |


The PDU page displays the following information about the link unit:

- Link ID
- Host/IP Address
- Model Number
- Operational Status
- Firmware Version

## About the Link ID

The PDU ID “1” is automated and reserved internally for the master unit. The master unit’s PDU ID “1” cannot be edited.

The Link ID “2-8” is available for you to select as the ID for each of the link units you add to chain. From the Link ID drop-down, you can select the desired Link ID to manage the link units in the chain. Once selected, the Link ID cannot be edited.



The screenshot shows a web form titled "Add Link PDU". It contains several input fields: "Link ID", "IP address/hostname", "Administrator login", and "Password". The "Link ID" field is currently open, displaying a dropdown menu with options 3, 4, 5, 6, 7, and 8. The number 3 is selected and highlighted in blue. At the bottom right of the form, there are two buttons: "Cancel" and "Add".

## What data does the master unit manage for the link units?

The master unit manages the following functions for the entire chain of linked units:

- User management and authentication – configured only on the master.
- Date and time – the master synchronizes its date and time settings to link units. If NTP is not used, then the synchronization interval is every 10 minutes.
- Device settings – only the master device settings are configurable, except for Network Settings. Some settings will be synced to link units. The serial port is configurable for the master only; link units use the console.
- Data model settings – such as outlet names, thresholds, peripherals, etc., are configured on the master and stored on link units.
- Lua scripts – Communication with link units in a Lua script is possible.

## Releasing a Link Unit

Releasing a link unit means the unit is separated from the chain and the unit then becomes standalone. The master unit no longer has access to the released link unit.

**Note:** If a release action is attempted on a link unit when the unit is an unreachable state, a warning message displays, and the master will not recognize the link unit. A factory reset will be required on the link unit.

The screenshot shows the 'My PDU' configuration page in the Server Technology web interface. The page is divided into several sections:

- Details:** A table showing device information: Firmware version (3.6.0.5-46586), Model (PRO3X-C3S36RL-EPJE2MT4\*), Serial number (2BZ3700090), MAC address (00:0a:9c:25:00:5a), Rating (200-240V, 26A, 5.2-6.2VA, 50/60Hz), and a Data log button labeled 'Export as CSV'.
- Link PDUs:** A table with columns: # ▲, Host, Model, Status, and Firmware. One row is selected (highlighted in blue): # 2, Host 10.1.10.54, Model PRO3X-C3S36RL-VCJE2MT3\*, Status OK, Firmware 3.6.0.5-46586. Below the table are buttons for 'Add Link PDU' and 'Release Link PDU' (highlighted with a red box).
- Settings:** A section for configuring the PDU, including a Name field (My PDU) with an 'Edit Settings' link, and a 'Reset all energy counters' button labeled 'Reset'.
- Sensors:** A section showing sensor data with columns: Sensor, Value, and State. One sensor is listed: '+12V Supply 1 Status' with a value of 'OK'.

### To release a link unit:

1. From the PDU page, in the Link PDUs section, click a link unit to select it.
2. Click **Release Link PDU**.
3. A confirmation prompts to cancel or release:

The dialog box is titled 'Release Link PDU'. It contains a warning icon and the text: 'Are you sure you want to release link PDU 10.1.10.54 (2)?'. At the bottom, there are two buttons: 'Cancel' (highlighted with a red dashed box) and 'Release'.


4. If released, the link unit is removed from the PDU page.



## Switching to a Different PDU

Switching PDUs is a control function noted by the Switch control in the in the upper left corner of the PDU, Outlet, Outlet Groups, OCPs, and Feature Ports pages, called out in the following screen example.

Displayed data in the GUI defaults to the master unit. The Switch control allows you to switch quickly from a master page, for My PDU (1) red in this example, to a link unit page, for My PDU (2) green in this example, and back again to the master.




The screenshot shows the Server Technology GUI for a PDU. The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, Outlet Groups, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area is titled 'My PDU' and features a dropdown menu at the top left with 'My PDU (1)' selected (highlighted in red) and 'My PDU (2)' highlighted in green. Below the dropdown, the 'Firmware version' is 3.6.0.5-46586. The main details section includes: Model (PRO3X-SW-60A-Delta), Serial number (2BZ3700246), MAC address (00:0a:9c:25:00:f6), and Rating (200-240V, 48A, 16.6-20.0kVA, 50/60Hz). A 'Data log' section has an 'Export as CSV' button. Below this is a 'Link PDUs' table with the following data:

| # ▲ | Host       | Model                   | Status | Firmware      |
|-----|------------|-------------------------|--------|---------------|
| 2   | 10.1.10.54 | PRO3X-C3S36RL-YCJE2MT3* | OK     | 3.6.0.5-46586 |

Buttons for 'Add Link PDU' and 'Release Link PDU' are located at the bottom right of the table.

### To switch to a different PDU:


1. Click the Switch  control.
2. Select one of the link PDUs “My PDU (2-8)” from the drop-down list.
3. The page displays data for the selected link PDU.
4. To return to the PDU page for the master, select the master PDU “My PDU (1)”.

**Note:** The Switch control is only available when there is at least one link unit in the chain; otherwise, the page defaults to displaying only the data of the master PDU.

## Re-linking a Link Unit

In PDU Linking, Re-link is a required function when a link unit no longer recognizes or responds to the master unit, most likely caused when the link unit has been reset to factory defaults. Resetting to factory defaults causes the linked unit in the chain to be unreachable, and it would have to be removed from the chain manually.


If reset to factory defaults, the status of the disassociated link unit will be displayed on the PDU page as “Access Denied”, shown below.



The screenshot shows the Server Technology PDU management interface. The top navigation bar includes the logo, 'My PDU', and user information (EN, Administrator, Logout). The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area displays details for 'My PDU (1)'. The 'Details' section lists: Firmware version (3.6.0.5-46586), Model (PRO3X-C3S36RL-EPJE2MT4\*), Serial number (2BZ3700090), MAC address (00:0a:9c:25:00:5a), Rating (200-240V, 26A, 5.2-6.2VA, 50/60Hz), and a 'Data log' button labeled 'Export as CSV'. Below this is a 'Link PDUs' table with columns: #, Host, Model, Status, and Firmware. A single row is shown with # 2, Host 192.168.6.29, Model <unknown>, Status Access Denied, and Firmware <unknown>. Below the table are buttons for 'Add Link PDU', 'Release Link PDU', and 'Re-link'. The 'Re-link' button is highlighted with a green box. Below the table is a 'Sensors' section with a table showing '+12V Supply 1 Status' with a value of 'OK'. The bottom of the interface includes 'Name: My PDU', 'Reset all energy counters' with a 'Reset' button, and 'Edit Settings'.

### To re-link a link unit:

1. When you select the link unit in the “Access Denied” status, the Re-link button displays, as noted above.
2. To reconnect the link unit in the chain, and to regain full control of the unit, click Re-link.
3. Although re-linking uses the same Link Unit ID and hostname of the unreachable unit, you will need to reauthenticate with your login credentials shown below.
4. Click the Re-link button.



The screenshot shows the 'Re-authenticate Link PDU' dialog box. It contains the following fields and values:

|                     |              |
|---------------------|--------------|
| Link ID             | 2            |
| IP address/hostname | 192.168.6.29 |
| Administrator login | admin        |
| Password            | *****        |

At the bottom right of the dialog box, there are two buttons: 'Cancel' and 'Re-link'. The 'Re-link' button is highlighted with a green box.

5. The status of the link unit changes to "OK".

The screenshot displays the Server Technology web interface for a PDU. The top navigation bar includes the logo, the title "My PDU", and user information (EN, Administrator, Logout). A left sidebar contains navigation options: Dashboard, PDU (selected), Inlets, Outlets, OCPs, Peripherals, User Management, Device Settings, and Maintenance. Below the sidebar, device information is listed: Model (PRO3X-C3S36RL-EPJE2MT4\*), Firmware Version (3.6.0.5-46586), Help (Server Technology Support), Last Login (1/17/2012, 4:01:04 PM UTC-0800), and Device Time (1/17/2012, 4:53:43 PM UTC-0800).

The main content area shows "My PDU (1)" with a "Details" section containing the following information:

|                  |                                   |
|------------------|-----------------------------------|
| Firmware version | 3.6.0.5-46586                     |
| Model            | PRO3X-C3S36RL-EPJE2MT4*           |
| Serial number    | 2BZ3700090                        |
| MAC address      | 00:0a:9c:25:00:5a                 |
| Rating           | 200-240V, 26A, 5.2-6.2VA, 50/60Hz |
| Data log         | <a href="#">Export as CSV</a>     |

Below the details is a "Link PDUs" section with a table:

| # ▲ | Host         | Model     | Status | Firmware      |
|-----|--------------|-----------|--------|---------------|
| 2   | 192.168.6.29 | PX3-5660V | OK     | 3.6.0.5-46238 |

Buttons for "Add Link PDU" and "Release Link PDU" are located below the table. Further down, there are sections for "Name" (My PDU), "Reset all energy counters" (Reset), and "Sensors" (containing a table with one entry: +12V Supply 1 Status, Value, State: OK).

## Viewing Link Unit Information

When a link unit is added to the chain, the master unit view (through the GUI) allows full access to the operational data of the link unit. For example, using the navigation tabs of the GUI, link unit data is displayed in several pages: the Dashboard, PDUs, Inlets, Outlets, Outlet Groups, and Peripherals.

### Dashboard

The Dashboard shows inlets, OCPs, alerted sensors, and inlet history for the entire linked chain.

In this example, data for the single inlet of the master “My PDU (1)” Inlet I1 (highlighted in red), and the inlet of the link unit “My PDU (2)” Inlet I1 (highlighted in green), are displayed together. The OCPs for the units are also available together on the Dashboard page.

Peripheral sensors are not shown on the dashboard by default. Only sensors (both PDU or peripheral) in warned or critical state are displayed in the Alerted Sensors section.

The screenshot displays the 'My PDU' dashboard interface. On the left is a navigation sidebar with options like Dashboard, PDU, Inlets, Outlets, etc. The main content area is divided into several sections:

- My PDU (1) Inlet I1:** Shows power consumption (0.0 W, 0.0 VA) and voltage levels for L1, L2, and L3. L1-L2 is 208.2 V, L2-L3 is 209.8 V, and L3-L1 is 207.6 V. Active energy is 279.54 kWh.
- My PDU (2) Inlet I1:** Shows power consumption (0.0 W, 0.0 VA) and voltage levels for L1, L2, and L3. L1-L2 is 207.9 V, L2-L3 is 209.7 V, and L3-L1 is 207.2 V. Active energy is 141.35 kWh.
- Overcurrent Protectors:** A table listing OCPs for both PDUs.
 

| Name                      | PDU        | Status | Current Drawn  | Protected Outlets | Lines |
|---------------------------|------------|--------|----------------|-------------------|-------|
| Overcurrent Protector BR1 | My PDU (1) | closed | 0.000 A / 20 A | 1-6               | L1-L2 |
| Overcurrent Protector BR2 | My PDU (1) | closed | 0.000 A / 20 A | 7-12              | L2-L3 |
| Overcurrent Protector BR3 | My PDU (1) | closed | 0.000 A / 20 A | 13-18             | L3-L1 |
| Overcurrent Protector BR4 | My PDU (1) | closed | 0.000 A / 20 A | 19-24             | L1-L2 |
| Overcurrent Protector BR5 | My PDU (1) | closed | 0.000 A / 20 A | 25-30             | L2-L3 |
| Overcurrent Protector BR6 | My PDU (1) | closed | 0.000 A / 20 A | 31-36             | L3-L1 |
| Overcurrent Protector BR1 | My PDU (2) | closed | 0.000 A / 20 A | 1-6 and 19-24     | L1-L2 |
| Overcurrent Protector BR2 | My PDU (2) | closed | 0.000 A / 20 A | 7-12 and 25-30    | L2-L3 |
| Overcurrent Protector BR3 | My PDU (2) | closed | 0.000 A / 20 A | 13-18 and 31-36   | L3-L1 |
- Alarmed Sensors:** Shows 'No Alarmed Sensors'.
- Alarms:** Shows 'No Alarms'.
- Inlet History:** A table showing power consumption over time, with values ranging from 0.4 W to 0.9 W.

## PDU Page

The PDU page displays the details and settings for the selected unit (master or link). The Link PDUs section is only shown when the master unit is selected. Master section is highlighted in red; link section is highlighted in green.

The screenshot shows the 'My PDU' interface. The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area is titled 'My PDU (1)' and is divided into several sections:

- Details (highlighted in red):** A table with the following information:

|                  |                                   |
|------------------|-----------------------------------|
| Firmware version | 3.6.0.5-46586                     |
| Model            | PRO3X-C3S36RL-EPJE2MT4*           |
| Serial number    | 2BZ3700090                        |
| MAC address      | 00:0a:9c:25:00:5a                 |
| Rating           | 200-240V, 26A, 5.2-6.2VA, 50/60Hz |
| Data log         | <a href="#">Export as CSV</a>     |
- Link PDUs (highlighted in green):** A table with the following information:

| # ▲ | Host       | Model                   | Status | Firmware      |
|-----|------------|-------------------------|--------|---------------|
| 2   | 10.1.10.54 | PRO3X-C3S36RL-YCJE2MT3* | OK     | 3.6.0.5-46586 |

Below the table are buttons for 'Add Link PDU' and 'Release Link PDU'.
- Settings:** A section with a name 'My PDU' and an 'Edit Settings' link. It also includes a 'Reset all energy counters' button with a 'Reset' sub-button.
- Sensors:** A section with a table showing sensor data:

| Sensor               | Value | State |
|----------------------|-------|-------|
| +12V Supply 1 Status |       | OK    |

The left sidebar also displays device information: Model PRO3X-C3S36RL-EPJE2MT4\*, Firmware Version 3.6.0.5-46586, and a 'Help' link to Server Technology Support. It also shows 'Last Login' and 'Device Time' for 1/17/2012.

## Inlets Page

On the Inlets page, the master unit and link units are displayed together on the same page.

In this example, data for the single inlet of the master “My PDU (1)” Inlet I1, and the inlet of the link unit “My PDU (2)” Inlet I1, are shown together on the Inlets page.

The screenshot displays the 'Inlets' page of a Server Technology interface. The page is titled 'My PDU' and includes a navigation sidebar on the left with options like Dashboard, PDU, Inlets, Outlets, etc. The main content area shows two PDU units, 'My PDU (1) Inlet I1' and 'My PDU (2) Inlet I1', each with a 'Show Details' link. Each unit's data is presented in a grid format with columns for L1, L2, and L3. The data for both units is currently at 0.0. The interface also shows active energy, power factor, line frequency, and unbalanced current for each unit.

| Unit                | Power (W) | Power (VA) | L1 (A / 60A) | L2 (A / 60A) | L3 (A / 60A) | Active Energy (kWh) | Power Factor | Line Frequency (Hz) | Unbalanced Current (%) |
|---------------------|-----------|------------|--------------|--------------|--------------|---------------------|--------------|---------------------|------------------------|
| My PDU (1) Inlet I1 | 0.0       | 0.0        | 0.0          | 0.0          | 0.0          | 279.54              | ---          | 60.0                | 0%                     |
| My PDU (2) Inlet I1 | 0.0       | 0.0        | 0.0          | 0.0          | 0.0          | 141.35              | ---          | 60.0                | 0%                     |

## Outlets Page

The Outlets page defaults to display only the outlets of the master unit. Note the 36-outlets that are characteristic of the PRO3X PDU.

Server Technology  
My PDU

EN | Administrator | Logout

Dashboard

PDU

Inlets

Outlets

Outlet Groups

OCPs

Peripherals

User Management

Device Settings

Maintenance

Model  
PRO3X-SW-60A-Delta

Firmware Version  
3.6.0.5-46586

Help  
Server Technology Support

Last Login  
1/17/2012, 12:33:44 PM UTC-0800

Device Time  
1/18/2012, 7:31:57 AM UTC-0800

My PDU (1) Outlets

On Off Cycle

| # ▲ | Name      | Status | Receptacle Type | Lines |
|-----|-----------|--------|-----------------|-------|
| 1   | Outlet 1  | on     | C13             | L1-L2 |
| 2   | Outlet 2  | on     | C13             | L1-L2 |
| 3   | Outlet 3  | on     | C13             | L1-L2 |
| 4   | Outlet 4  | on     | Cx              | L1-L2 |
| 5   | Outlet 5  | on     | Cx              | L1-L2 |
| 6   | Outlet 6  | on     | Cx              | L1-L2 |
| 7   | Outlet 7  | on     | C13             | L2-L3 |
| 8   | Outlet 8  | on     | C13             | L2-L3 |
| 9   | Outlet 9  | on     | C13             | L2-L3 |
| 10  | Outlet 10 | on     | Cx              | L2-L3 |
| 11  | Outlet 11 | on     | Cx              | L2-L3 |
| 12  | Outlet 12 | on     | Cx              | L2-L3 |
| 13  | Outlet 13 | on     | C13             | L3-L1 |
| 14  | Outlet 14 | on     | C13             | L3-L1 |
| 15  | Outlet 15 | on     | C13             | L3-L1 |
| 16  | Outlet 16 | on     | Cx              | L3-L1 |
| 17  | Outlet 17 | on     | Cx              | L3-L1 |
| 18  | Outlet 18 | on     | Cx              | L3-L1 |
| 19  | Outlet 19 | on     | C13             | L1-L2 |
| 20  | Outlet 20 | on     | C13             | L1-L2 |
| 21  | Outlet 21 | on     | C13             | L1-L2 |
| 22  | Outlet 22 | on     | Cx              | L1-L2 |
| 23  | Outlet 23 | on     | Cx              | L1-L2 |
| 24  | Outlet 24 | on     | Cx              | L1-L2 |
| 25  | Outlet 25 | on     | C13             | L2-L3 |
| 26  | Outlet 26 | on     | C13             | L2-L3 |
| 27  | Outlet 27 | on     | C13             | L2-L3 |
| 28  | Outlet 28 | on     | Cx              | L2-L3 |
| 29  | Outlet 29 | on     | Cx              | L2-L3 |
| 30  | Outlet 30 | on     | Cx              | L2-L3 |
| 31  | Outlet 31 | on     | C13             | L3-L1 |
| 32  | Outlet 32 | on     | C13             | L3-L1 |
| 33  | Outlet 33 | on     | C13             | L3-L1 |
| 34  | Outlet 34 | on     | Cx              | L3-L1 |
| 35  | Outlet 35 | on     | Cx              | L3-L1 |
| 36  | Outlet 36 | on     | Cx              | L3-L1 |

## Customizing the Outlets Page



Click the menu icon in the upper right corner of the screen to display a list of available data columns for the Outlets page. Check the preferred columns to customize how outlet data is displayed on the page.

The screenshot displays the 'My PDU (1) Outlets' page. The table below shows the current configuration of outlets:

| #  | Name      | Status | Receptacle Type | Lines |
|----|-----------|--------|-----------------|-------|
| 1  | Outlet 1  | on     | C13             |       |
| 2  | Outlet 2  | on     | C13             |       |
| 3  | Outlet 3  | on     | C13             |       |
| 4  | Outlet 4  | on     | Cx              |       |
| 5  | Outlet 5  | on     | Cx              |       |
| 6  | Outlet 6  | on     | Cx              |       |
| 7  | Outlet 7  | on     | C13             |       |
| 8  | Outlet 8  | on     | C13             |       |
| 9  | Outlet 9  | on     | C13             |       |
| 10 | Outlet 10 | on     | Cx              |       |
| 11 | Outlet 11 | on     | Cx              |       |
| 12 | Outlet 12 | on     | Cx              |       |
| 13 | Outlet 13 | on     | C13             |       |
| 14 | Outlet 14 | on     | C13             |       |
| 15 | Outlet 15 | on     | C13             |       |

The 'Lines' configuration menu is open, showing the following options:

- Status
- Non-Critical
- Sequence Order
- Sequence Delay
- Receptacle Type
- Lines



## Switching Between Master and Link Outlets

The Outlets page defaults to the master unit's outlets, but you can easily switch the master to the link and back again to view and access outlet information.

1. From the Outlets page drop-down, select the link unit “My PDU (2)” shown in this example. To view outlets for multiple link units, select the link unit by name.

The screenshot shows the Server Technology interface for 'My PDU'. The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, Outlet Groups, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area displays a table of outlets for 'My PDU (1)'. A dropdown menu is open, showing 'My PDU (1)' and 'My PDU (2)'. The table has columns for #, Name, Status, Receptacle Type, and Lines.

| #  | Name      | Status | Receptacle Type | Lines |
|----|-----------|--------|-----------------|-------|
| 1  | Outlet 1  | on     | C13             | L1-L2 |
| 2  | Outlet 2  | on     | C13             | L1-L2 |
| 3  | Outlet 3  | on     | C13             | L1-L2 |
| 4  | Outlet 4  | on     | Cx              | L1-L2 |
| 5  | Outlet 5  | on     | Cx              | L1-L2 |
| 6  | Outlet 6  | on     | Cx              | L1-L2 |
| 7  | Outlet 7  | on     | C13             | L2-L3 |
| 8  | Outlet 8  | on     | C13             | L2-L3 |
| 9  | Outlet 9  | on     | C13             | L2-L3 |
| 10 | Outlet 10 | on     | Cx              | L2-L3 |
| 11 | Outlet 11 | on     | Cx              | L2-L3 |
| 12 | Outlet 12 | on     | Cx              | L2-L3 |
| 13 | Outlet 13 | on     | C13             | L3-L1 |
| 14 | Outlet 14 | on     | C13             | L3-L1 |
| 15 | Outlet 15 | on     | C13             | L3-L1 |
| 16 | Outlet 16 | on     | Cx              | L3-L1 |

2. Sample of outlets page for Link PDUs, in this example “My PDU (2)”. All outlets of the link unit display for viewing and access exactly like the outlets of the master unit.

The screenshot shows the Server Technology interface for 'My PDU'. The left sidebar is the same as in the previous screenshot. The main content area displays a table of outlets for 'My PDU (2)'. A dropdown menu is open, showing 'My PDU (2) Outlets'. The table has columns for #, Name, Receptacle Type, and Lines.

| #  | Name      | Receptacle Type | Lines |
|----|-----------|-----------------|-------|
| 1  | Outlet 1  | C13             | L1-L2 |
| 2  | Outlet 2  | C13             | L1-L2 |
| 3  | Outlet 3  | C13             | L1-L2 |
| 4  | Outlet 4  | Cx              | L1-L2 |
| 5  | Outlet 5  | Cx              | L1-L2 |
| 6  | Outlet 6  | Cx              | L1-L2 |
| 7  | Outlet 7  | C13             | L2-L3 |
| 8  | Outlet 8  | C13             | L2-L3 |
| 9  | Outlet 9  | C13             | L2-L3 |
| 10 | Outlet 10 | Cx              | L2-L3 |
| 11 | Outlet 11 | Cx              | L2-L3 |
| 12 | Outlet 12 | Cx              | L2-L3 |

3. You can switch back to the master unit by selecting “My PDU (1)”.


**Note:** The Switch control is only available when there is at least one link unit in the chain; otherwise, the page defaults to the outlets of the master.

## Viewing Outlet Details

1. From the Outlets page (either master or link), click to select an outlet in the list. The Details page displays for viewing operational details for the selected outlet.




2. Click the Edit Settings link to configure outlet settings.



3. Edit name of outlet, if desired.
4. From the drop-down menu, select the “State on device startup”: on, off, last known, PDU defined (last known).
5. Determine power off period during power cycle, and provide the time period in seconds.
6. Check if off time is a non-critical power cycle.

## Controlling Outlet Power


1. Select a specific outlet on the Outlets page (showing On or Off in the Status column).



My PDU (1) Outlets

| # ▲ | Name      | Status | Non-Critical | Receptacle Type | Lines |
|-----|-----------|--------|--------------|-----------------|-------|
| 1   | Outlet 1  | on     | false        | C13             | L1-L2 |
| 2   | Outlet 2  | on     | false        | C13             | L1-L2 |
| 3   | Outlet 3  | on     | false        | C13             | L1-L2 |
| 4   | Outlet 4  | on     | false        | Cx              | L1-L2 |
| 5   | Outlet 5  | on     | false        | Cx              | L1-L2 |
| 6   | Outlet 6  | on     | false        | Cx              | L1-L2 |
| 7   | Outlet 7  | on     | false        | C13             | L2-L3 |
| 8   | Outlet 8  | on     | false        | C13             | L2-L3 |
| 9   | Outlet 9  | on     | false        | C13             | L2-L3 |
| 10  | Outlet 10 | on     | false        | Cx              | L2-L3 |


2. In the upper right corner, click On or Off to control the outlet's power. The following confirmation displays. Click Switch off (or switch on).



Switch off outlet 1?

Cancel Switch off

3. The outlet's power status is immediately updated:



My PDU (1) Outlets

| # ▲ | Name     | Status | Non-Critical | Receptacle Type | Lines |
|-----|----------|--------|--------------|-----------------|-------|
| 1   | Outlet 1 | off    | false        | C13             | L1-L2 |
| 2   | Outlet 2 | on     | false        | C13             | L1-L2 |
| 3   | Outlet 3 | on     | false        | C13             | L1-L2 |
| 4   | Outlet 4 | on     | false        | Cx              | L1-L2 |

## Additional Outlet Functions



On the Outlets page, click the menu icon in the upper right corner of the screen to display a drop-down list of additional options for outlets.

| # ▲ | Name      | Status | RMS Current | Active Power | Power Factor |                        |
|-----|-----------|--------|-------------|--------------|--------------|------------------------|
| 1   | Outlet 1  | on     | 0.000 A     | 0 W          | ---          | Reset Energy Counter   |
| 2   | Outlet 2  | on     | 0.000 A     | 0 W          | ---          | Threshold Bulk Setup   |
| 3   | Outlet 3  | on     | 0.000 A     | 0 W          | ---          | Sequence Setup         |
| 4   | Outlet 4  | on     | 0.000 A     | 0 W          | ---          | Load Shedding Setup    |
| 5   | Outlet 5  | on     | 0.000 A     | 0 W          | ---          | Activate Load Shedding |
| 6   | Outlet 6  | on     | 0.000 A     | 0 W          | ---          | false                  |
| 7   | Outlet 7  | on     | 0.000 A     | 0 W          | ---          | false                  |
| 8   | Outlet 8  | on     | 0.000 A     | 0 W          | ---          | false                  |
| 9   | Outlet 9  | on     | 0.000 A     | 0 W          | ---          | false                  |
| 10  | Outlet 10 | on     | 0.000 A     | 0 W          | ---          | false                  |
| 11  | Outlet 11 | on     | 0.000 A     | 0 W          | ---          | false                  |
| 12  | Outlet 12 | on     | 0.000 A     | 0 W          | ---          | false                  |

### Reset Energy Counter

An active energy reading (the total accumulated energy) is not automatically reset. You can reset the energy counter back to zero using the Reset Energy Counter option.

1. From the Outlets page, select an outlet in the list.
2. Select the Reset Energy Counter option.
3. Confirm or cancel the reset action.

Do you really want to reset the active energy counter for Outlet 1?

## Threshold Bulk Setup

The Threshold Bulk Setup option saves time by allowing you to define and manage threshold paRAMeters on multiple outlets at one time. Upper and lower thresholds can be updated quickly in bulk when selecting multiple outlets.

1. From the Outlets page, select the Threshold Bulk Setup option. The following Outlet Thresholds page displays:

Server Technology  
My PDU  
EN | Administrator | Logout

Dashboard  
PDU  
Inlet  
Outlets  
Outlet Groups  
OCPs  
Peripherals  
User Management  
Device Settings  
Maintenance  
Model: PRO3X-C3WG36RL-GPJE2MT2\*  
Firmware Version: 3.6.0.5-46586

Outlet Thresholds

Show outlet sensors of type:  
RMS Voltage

Edit Thresholds

| Outlet   | Lower Critical | Lower Warning | Upper Warning | Upper Critical |
|----------|----------------|---------------|---------------|----------------|
| Outlet 1 | ---            | ---           | ---           | ---            |
| Outlet 2 | ---            | ---           | ---           | ---            |
| Outlet 3 | ---            | ---           | ---           | ---            |
| Outlet 4 | ---            | ---           | ---           | ---            |
| Outlet 5 | ---            | ---           | ---           | ---            |
| Outlet 6 | ---            | ---           | ---           | ---            |
| Outlet 7 | ---            | ---           | ---           | ---            |
| Outlet 8 | ---            | ---           | ---           | ---            |
| Outlet 9 | ---            | ---           | ---           | ---            |

2. From the drop-down list, select the outlet sensor type. RMS Voltage is the default.

Show outlet sensors of type:

- RMS Voltage
- RMS Voltage
- RMS Current
- Active Power
- Apparent Power
- Power Factor
- Active Energy
- Line Frequency

3. Select an outlet in the list. Outlet 6 selected in the above page example.
4. Click the Edit Thresholds link. The Outlet Thresholds page displays where upper/lower thresholds can be updated.
5. Edit Deassertion Hysteresis to determine when a threshold condition is reset.
6. Edit Assertion Timeout to determine (in seconds) when a threshold condition exceeds a threshold for more than the assertion timeout period.
7. Click Save.

The screenshot shows the 'Outlet Thresholds' configuration page for 'Outlet 6' in the Server Technology interface. The page includes a sidebar with navigation options: Dashboard, PDU, Inlet, Outlets (selected), Outlet Groups, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area displays the following settings:

| Setting                | Value | Unit    |
|------------------------|-------|---------|
| Lower critical         | 206.2 | V       |
| Lower warning          | 212.8 | V       |
| Upper warning          | 246.8 | V       |
| Upper critical         | 254   | V       |
| Deassertion hysteresis | 2     | V       |
| Assertion timeout      | 0     | Samples |

At the bottom right of the configuration area, there are 'Cancel' and 'Save' buttons.

## Sequence Setup

You can use the power-on sequence option to define a sequence/order for powering on the PDU outlets. User-defined sequences can eliminate in-rush current when multiple PDUs are powered on at the same time.

1. From the Outlets page, select the Sequence Setup option. The Outlets Sequence page displays:

Server Technology My PDU EN Administrator Logout

Dashboard PDU Inlet Outlets Outlet Groups OCPs Peripherals User Management Device Settings Maintenance

Model: PRO3X-C3WG36RL-GPJE2MT2\*  
Firmware Version: 3.6.0.5-46586  
Help: Server Technology Support  
Last Login: 2/15/2012, 12:45:05 PM UTC-0800  
Device Time: 2/15/2012, 1:32:35 PM UTC-0800

Outlets Sequence

Outlet Sequence: 1-36

| Sequence Order | Delay |
|----------------|-------|
| Outlet 1       | 0 s   |
| Outlet 2       | 0 s   |
| Outlet 3       | 0 s   |
| Outlet 4       | 0 s   |
| Outlet 5       | 0 s   |
| Outlet 6       | 0 s   |
| Outlet 7       | 0 s   |
| Outlet 8       | 0 s   |
| Outlet 9       | 0 s   |
| Outlet 10      | 0 s   |
| Outlet 11      | 0 s   |
| Outlet 12      | 0 s   |
| Outlet 13      | 0 s   |
| Outlet 14      | 0 s   |
| Outlet 15      | 0 s   |
| Outlet 16      | 0 s   |
| Outlet 17      | 0 s   |
| Outlet 18      | 0 s   |
| Outlet 19      | 0 s   |


**Note:** The default outlet sequence is 1-n, as highlighted above for the 36 outlets in the PRO3X PDU. (Only outlets 1-19 are shown in this partial screen capture.)

2. Use the following controls to change the sequence of outlets.


| <b>Outlets Sequence - Controls</b> |  |
|------------------------------------|--|
|                                    | <b>Move to top of list.</b> Move a specific outlet to the top of the sequence list to power-on first.      |
|                                    | <b>Move up.</b> Move a specific outlet up in the power-on sequence list.                                   |
|                                    | <b>Move down.</b> Move a specific outlet down in the power-on sequence list.                               |
|                                    | <b>Move to bottom of list.</b> Move a specific outlet to the bottom of the sequence list to power-on last. |
|                                    | <b>Reset.</b> Reset the power-on outlet sequence back to the default 1-n.                                  |

- Note the updated Outlet Sequence heading at the top of the page that reflects your changes in the power-on sequence.


In this example, Outlet 3 was selected and moved to the top of the sequence list to be powered on first.



In this example, the Outlet Sequence heading shows the (moved up) new sequence of outlets 3-2, 11-10, and the original sequence of outlets 12-36.



- Click in the Delay field for a specific outlet in the list and type a delay time (in seconds) before the outlet powers on. The Delay default is 0.



- Click Save.



## Load Shedding Setup

Server Technology's Load Shedding option allows the systematic shutdown of outlet loads.

1. From the Outlets page, select the Load Shedding Setup option. The Load Shedding page displays:

The screenshot shows the 'Load Shedding' configuration page in the Server Technology web interface. The page title is 'My PDU' and the user is logged in as 'Administrator'. The sidebar on the left contains navigation links for various system components. The main content area is titled 'Load Shedding' and includes a 'Non-Critical' checkbox and a list of 32 outlets. Outlets 1, 2, and 3 are checked, while all other outlets are unchecked.


| Non-Critical                        | Outlets   |
|-------------------------------------|-----------|
| <input checked="" type="checkbox"/> | Outlet 1  |
| <input checked="" type="checkbox"/> | Outlet 2  |
| <input checked="" type="checkbox"/> | Outlet 3  |
| <input type="checkbox"/>            | Outlet 4  |
| <input type="checkbox"/>            | Outlet 5  |
| <input type="checkbox"/>            | Outlet 6  |
| <input type="checkbox"/>            | Outlet 7  |
| <input type="checkbox"/>            | Outlet 8  |
| <input type="checkbox"/>            | Outlet 9  |
| <input type="checkbox"/>            | Outlet 10 |
| <input type="checkbox"/>            | Outlet 11 |
| <input type="checkbox"/>            | Outlet 12 |
| <input type="checkbox"/>            | Outlet 13 |
| <input type="checkbox"/>            | Outlet 14 |
| <input type="checkbox"/>            | Outlet 15 |
| <input type="checkbox"/>            | Outlet 16 |
| <input type="checkbox"/>            | Outlet 17 |
| <input type="checkbox"/>            | Outlet 18 |
| <input type="checkbox"/>            | Outlet 19 |
| <input type="checkbox"/>            | Outlet 20 |
| <input type="checkbox"/>            | Outlet 21 |
| <input type="checkbox"/>            | Outlet 22 |
| <input type="checkbox"/>            | Outlet 23 |
| <input type="checkbox"/>            | Outlet 24 |
| <input type="checkbox"/>            | Outlet 25 |
| <input type="checkbox"/>            | Outlet 26 |
| <input type="checkbox"/>            | Outlet 27 |
| <input type="checkbox"/>            | Outlet 28 |
| <input type="checkbox"/>            | Outlet 29 |
| <input type="checkbox"/>            | Outlet 30 |
| <input type="checkbox"/>            | Outlet 31 |
| <input type="checkbox"/>            | Outlet 32 |

### Using the Non-Critical Checkbox:

With Load Shedding, you can sort all PRO3X outlets into two categories: critical outlets or non-critical outlets.


Note the Non-Critical checkbox highlighted in the Load Shedding screen sample below.

- When the Non-Critical checkbox is **checked**, the selected non-critical outlet(s) are **powered off** when Load Shedding is activated.
- When the Non-Critical checkbox is **not checked**, the selected critical outlet(s) are **not powered off** when Load Shedding is activated



### Notes:

- By default, all outlets are considered critical, and you must select one or multiple outlets and then check the Non-Critical checkbox to make the outlet(s) non-critical to be powered off when Load Shedding is activated.
- When Load Shedding is activated, all non-critical outlets are turned off and critical outlets stay on, if those outlets were on before Load Shedding was activated.
- You can also access the Non-Critical checkbox from the Outlets page (for an individual outlet) on the Edit Settings link, as follows:



## Activate/Deactive Load Shedding


### To activate load shedding:

1. From the Outlets page, select the Activate Load Shedding option.
2. Confirm or cancel the activation:

Load Shedding Mode

Activate the load shedding mode?

3. The Outlets page displays “Load shedding active”



The screenshot shows the 'My PDU' interface for a Server Technology PDU. The 'Outlets' page is active, and the heading 'Outlets Load shedding active' is highlighted with a red box. The table below shows 16 outlets, all with a status of 'on' and 0 W of active power.

| # ▲ | Name      | Status | RMS Current | Active Power | Power Factor | Non-Critical |
|-----|-----------|--------|-------------|--------------|--------------|--------------|
| 1   | Outlet 1  | on     | 0.000 A     | 0 W          | —            | false        |
| 2   | Outlet 2  | on     | 0.000 A     | 0 W          | —            | false        |
| 3   | Outlet 3  | on     | 0.000 A     | 0 W          | —            | false        |
| 4   | Outlet 4  | on     | 0.000 A     | 0 W          | —            | false        |
| 5   | Outlet 5  | on     | 0.000 A     | 0 W          | —            | false        |
| 6   | Outlet 6  | on     | 0.000 A     | 0 W          | —            | false        |
| 7   | Outlet 7  | on     | 0.000 A     | 0 W          | —            | false        |
| 8   | Outlet 8  | on     | 0.000 A     | 0 W          | —            | false        |
| 9   | Outlet 9  | on     | 0.000 A     | 0 W          | —            | false        |
| 10  | Outlet 10 | on     | 0.000 A     | 0 W          | —            | false        |
| 11  | Outlet 11 | on     | 0.000 A     | 0 W          | —            | false        |
| 12  | Outlet 12 | on     | 0.000 A     | 0 W          | —            | false        |
| 13  | Outlet 13 | on     | 0.000 A     | 0 W          | —            | false        |
| 14  | Outlet 14 | on     | 0.000 A     | 0 W          | —            | false        |
| 15  | Outlet 15 | on     | 0.000 A     | 0 W          | —            | false        |
| 16  | Outlet 16 | on     | 0.000 A     | 0 W          | —            | false        |


### To deactivate load shedding:

1. From the Outlets page, select the Deactivate Load Shedding option.
2. Confirm or cancel the deactivation:

Load Shedding Mode

Deactivate the load shedding mode?

3. The Outlets page displays with a blank heading to indicate Load Shedding is deactivated.



The screenshot shows the 'Outlets' page with a blank heading 'Outlets' highlighted by a red box. Below the heading is a table with 3 outlets.

| # ▲ | Name     |
|-----|----------|
| 1   | Outlet 1 |
| 2   | Outlet 2 |
| 3   | Outlet 3 |


## Outlet Groups


An outlet group is a named collection of selected outlets in a PDU. When user-defined, an outlet group can contain outlets from different PDUs, including both master and link units.

Outlet groups support fast and efficient outlet control actions (On, Off, Power Cycle) across multiple PDUs, and with PDU Linking, member outlets for the master and its link units can be collected in the same outlet group.

Outlet groups are managed by the master unit, and multiple outlet groups can be controlled simultaneously. Summary and power energy readings are available per outlet group.

The Outlet Groups page displays current user-defined outlet groups along with name, outlet state, active power reading, and the page also shows the outlet labels that were selected for the group. In the Outlets column in this example you see that outlets from both master and link units display together within a named group. This is an example of outlet “pairwise”, a function described in more detail later in this next section. **Note: Outlet groups can contain multiple pairs of outlets; the next screen example shows only two outlet pairs in the sample groups.**

Click the control arrow  to toggle the outlet group list in ascending or descending order by group number.



| # ▲ | Name                    | Outlet State | Outlets             |
|-----|-------------------------|--------------|---------------------|
| 1   | MASTER PDU OUTLET GROUP | 36 on        | PDU 1: 1-36         |
| 2   | LINK PDU OUTLET GROUP   | 36 on        | PDU 2: 1-36         |
| 3   | LINK PDU Outlets 1-10   | 9 on         | PDU 2: 1-7 and 9-10 |

## Viewing Outlet Group Details

Click an outlet group name in the list to display details for the outlet group.

The screenshot shows the 'My PDU' page in the Server Technology web interface. The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, Outlet Groups (selected), OCPs, Peripherals, User Management, Device Settings, and Maintenance. Below these are device details: Model PRO3X-SW-60A-Delta and Firmware Version 3.6.0.5-46586. The main content area is titled 'Outlet Group 3 - LINK PDU Outlets 1-10'. It features a table of outlets and a settings section.

| # ▲ | PDU        | Outlet    |
|-----|------------|-----------|
| 1   | My PDU (2) | Outlet 1  |
| 2   | My PDU (2) | Outlet 2  |
| 3   | My PDU (2) | Outlet 3  |
| 4   | My PDU (2) | Outlet 4  |
| 5   | My PDU (2) | Outlet 5  |
| 6   | My PDU (2) | Outlet 6  |
| 7   | My PDU (2) | Outlet 7  |
| 8   | My PDU (2) | Outlet 9  |
| 9   | My PDU (2) | Outlet 10 |

Settings section: Name: LINK PDU Outlets 1-10

The Details page shows the identification details of the outlet, settings, and sensors. From the Details page, click Edit Settings link.

The screenshot shows the 'My PDU (2)' details page in the Server Technology web interface. The left sidebar is the same as in the previous screenshot, with 'PDU' selected. The main content area is titled 'My PDU (2)' and contains details, settings, and sensors.

Details section:

|                  |                                     |
|------------------|-------------------------------------|
| Firmware version | 3.6.0.5-46586                       |
| Model            | PRO3X-C3S36RL-YCJE2MT3*             |
| Serial number    | 2BZ3700080                          |
| MAC address      | 00:0a:9c:25:00:50                   |
| Rating           | 200-240V, 24A, 8.3-10.0kVA, 50/60Hz |
| Data log         | <a href="#">Export as CSV</a>       |

Settings section:


|                           |                       |                               |
|---------------------------|-----------------------|-------------------------------|
| Name                      | My PDU                | <a href="#">Edit Settings</a> |
| Reset all energy counters | <a href="#">Reset</a> |                               |

Sensors section:

| Sensor               | Value | State |
|----------------------|-------|-------|
| +12V Supply 1 Status |       | OK    |


**To add an outlet group:**

1. On the Outlet Groups page, click **+ Add group**. The New Outlet Group page displays, defaulting to the outlets in the master unit.





2. Type a name for the new outlet group.
3. Select individual member outlets for the master as shown in the default page, or to select all outlets for the master, select My PDU (1).
4. To select individual member outlets for the link unit My PDU (2), click Add Outlets. To select all outlets for the link unit, select My PDU (2). **Note: Link units have to be selected by name to display their outlets.**
5. Click **Save**.

The following example shows the outlet group named “TEST 1” with all outlet members selected for the master unit and outlet members 1-6 selected for the link unit.




## Deleting an outlet group

1. From the Outlet Groups page, select the outlet group to delete.
2. From the drop-down menu  select Delete. The outlet group is removed from the Outlets Group page.



## Controlling outlets in an outlet group

1. From the Outlet Groups page, select an outlet group by name.
2. Click the desired control: On, Off, or Cycle. This example shows three outlets, two in status On and one in status Off. When Off is clicked, a prompt appears to confirm applying the action to all outlets in the group.
3. Click the Switch Off button.



4. In this example, the status of the outlets in the outlet group appears on the Outlets Group page as "3 off".



## About pairwise outlet groups

The PDU Linking feature offers the “pairwise” functionality for outlet grouping. Pairwise lets you create auto-named pairs of outlet groups than span multiple PDUs (master and link units) using the same outlet label. Pairwise simplifies powering up or down a server by automatically creating multiple outlet groups, each containing one pair of outlets between PDUs that can be controlled as a pair-related outlet group.

### Example: Chain with master and a single link unit

| PDU 1 (Master Unit) | Server Load | PDU 2 (Link Unit) |
|---------------------|-------------|-------------------|
| Outlet 1            | Server 1    | Outlet 1          |
| Outlet 2            | Server 2    | Outlet 2          |
| Outlet 3            | Server 3    | Outlet 3          |
| ...                 | ...         | ...               |
| Outlet 20           | Server 20   | Outlet 20         |


Using the above example, to power up or down a server, you would typically switch one outlet of PDU 1 and one outlet of PDU 2. With pairwise, you can auto-create an outlet group named “Outlet pair 3”, and the new group will automatically contain Outlet 3 from PDU 1 (master) and Outlet 3 from PDU 2 (link). Powering up or down the server only requires switching the “Outlet pair 3” outlet group, allowing for improved accuracy and speed over outlet control.

### To create an auto-pairwise outlet group:

1. From the Outlet Groups page, from the drop-down menu  select Automatic Creation.



2. Confirm the pairwise creation.





- Pairwise outlet groups are created and named automatically for all outlets on the master and link unit, such as “Outlet pair 1”, “Outlet pair 2”, “Outlet pair 3”, etc.

| # ▲ | Name                    | Outlet State  | Outlets              |
|-----|-------------------------|---------------|----------------------|
| 1   | MASTER PDU OUTLET GROUP | 33 on , 3 off | PDU 1: 1-36          |
| 2   | LINK PDU OUTLET GROUP   | 36 on         | PDU 2: 1-36          |
| 3   | LINK PDU Outlets 1-10   | 9 on          | PDU 2: 1-7 and 9-10  |
| 4   | Master Unit 1-3         | 3 off         | PDU 1: 1-3           |
| 5   | Outlet pair 1           | 1 on , 1 off  | PDU 1: 1<br>PDU 2: 1 |
| 6   | Outlet pair 2           | 1 on , 1 off  | PDU 1: 2<br>PDU 2: 2 |
| 7   | Outlet pair 3           | 1 on , 1 off  | PDU 1: 3<br>PDU 2: 3 |
| 8   | Outlet pair 4           | 2 on          | PDU 1: 4<br>PDU 2: 4 |
| 9   | Outlet pair 5           | 2 on          | PDU 1: 5<br>PDU 2: 5 |
| 10  | Outlet pair 6           | 2 on          | PDU 1: 6<br>PDU 2: 6 |
| 11  | Outlet pair 7           | 2 on          | PDU 1: 7<br>PDU 2: 7 |
| 12  | Outlet pair 8           | 2 on          | PDU 1: 8<br>PDU 2: 8 |

## OCPs Page

Overcurrent protectors from both master and link PDUs are displayed together on the same OCPs page.

| # ▲ | Name                      | PDU        | Status | Current Drawn  | Protected Outlets | Lines |
|-----|---------------------------|------------|--------|----------------|-------------------|-------|
| 1   | Overcurrent Protector BR1 | My PDU (1) | closed | 0.000 A / 20 A | 1-6               | L1-L2 |
| 2   | Overcurrent Protector BR2 | My PDU (1) | closed | 0.000 A / 20 A | 7-12              | L2-L3 |
| 3   | Overcurrent Protector BR3 | My PDU (1) | closed | 0.000 A / 20 A | 13-18             | L3-L1 |
| 4   | Overcurrent Protector BR4 | My PDU (1) | closed | 0.000 A / 20 A | 19-24             | L1-L2 |
| 5   | Overcurrent Protector BR5 | My PDU (1) | closed | 0.000 A / 20 A | 25-30             | L2-L3 |
| 6   | Overcurrent Protector BR6 | My PDU (1) | closed | 0.000 A / 20 A | 31-36             | L3-L1 |
| 7   | Overcurrent Protector BR1 | My PDU (2) | closed | 0.000 A / 20 A | 1-6 and 19-24     | L1-L2 |
| 8   | Overcurrent Protector BR2 | My PDU (2) | closed | 0.000 A / 20 A | 7-12 and 25-30    | L2-L3 |
| 9   | Overcurrent Protector BR3 | My PDU (2) | closed | 0.000 A / 20 A | 13-18 and 31-36   | L3-L1 |

## Peripherals Page

The Peripherals Page shows peripheral devices connected to the master or link unit.

The screenshot shows the 'My PDU' page in the Server Technology interface. The left sidebar contains navigation options: Dashboard, PDU, Inlets, Outlets, Outlet Groups, OCPs, Peripherals, User Management, Device Settings, and Maintenance. The main content area is titled 'My PDU (1) Peripheral Devices' and contains a table with the following data:

| # ▲ | Name                | Reading     | State       | Type        | Serial Number | Position | Actuator |
|-----|---------------------|-------------|-------------|-------------|---------------|----------|----------|
| 1   | Temperature 1       | unavailable | unavailable | Temperature | AEI8500012    |          |          |
| 2   | Relative Humidity 1 | unavailable | unavailable | Humidity    | AEI8500012    |          |          |

Click a peripheral device name for operational details, in this example “Temperature 1”. If sensors are present on any of the devices, sensor data for both master and link units will also appear on the page.

Click the Edit links to configure parameters for Sensors and Settings.

The screenshot shows the 'Temperature 1' details page in the Server Technology interface. The left sidebar is the same as in the previous screenshot. The main content area is titled 'Temperature 1' and contains the following sections:

- Details**
  - Peripheral device ID: 1
  - Serial number: AEI8500012
  - Type: Temperature
- Sensor**
  - Reading: unavailable
  - State: unavailable
  - Last time changed: 1/17/2012, 12:36:37 PM UTC-0800
  - [Edit Thresholds](#)
- Settings**
  - Name: Temperature 1
  - Description:
  - Location (X):
  - Location (Y):
  - Location (Z: Rack Units):
  - [Edit Settings](#)
- Sensor History**
  - Not enough data is present in data log.

---

## Displays for Master and Link Units

The following displays are samples of the menu options you may see on your PRO3X unit for the PDU Linking feature. Each unit in a PDU Linking chain displays its own PDU data (inlets, outlets, sensors, alerts, etc.)

### Hardware Display Examples:

*Master unit:*

From the following example of the master unit display, navigate the options for displaying Link PDU identification and status, and to confirm the master unit that is controlling the link unit in the chain.


- Can show alarms, which may be triggered by link units.
- PDU information shows a list of link units with host name/IP address, model, device name, serial number, firmware version, and communication status.

**Note:** These samples are generic and may not look exactly like the menu options and PRO3X product SKUs displayed on your PDU.



*Link units:*

- No display of alarms (no event engine on link units)
- PDU information shows the master IP address



---

## Using the Command Line Interface (CLI)

For each PDU in a chain, you can list the PDUs, switch a PDU, add a new link PDU, and release a link PDU. You can then use all regular PDU-related commands as usual to access and control individual units, as with any standalone PDU.

### *About PDU Linking CLI Commands:*

- The CLI is disabled on link units. Access to the link unit via the CLI is available only through the master CLI.
- If any link units are configured, the CLI prompt includes the currently selected PDU and Link ID, such as My Pdu (1) or My Pdu (2).
- Some commands are not available for link units:
  - Authentication settings
  - EnergyWise settings
  - Security settings (login, role-based access control, user blocking, and strong passwords.)
  - Server monitor
  - User management

## PDU List

The PDU List command displays the following information for each unit:

- Link ID
- Communication status (for link unit only)
- Device name
- Model name
- Serial number
- Firmware version

```
# Pdu list
```

## Switch PDU

The PDU Switch command lets you switch between the master and link units. The Link ID must be PDU 1 (master) or PDUs 2-8 (link units).

```
# pdu[id]
```

## Add a New Link PDU

The PDU Add command allows you to add a link unit to a master unit. The command is only available when PDU 1 (master) is selected. The command can be used to re-establish a connection to an existing link unit if the Link ID and host match exactly. The command requires admin privileges and prompts for the user's password.

```
# pdu link [id][host][login]
```

### Parameters:

- id: New link ID (PDUs 2-8)
- host: Host name or IP address
- login: Name of user with admin privileges

## Release a Link PDU

The PDU Release command lets you release (separate) a link unit from a chain until the unit becomes standalone. The master unit does not have access to a released link unit. The command is only available when PDU 1 (master) is selected. The command requires admin privileges, and prompts for confirmation unless the “/y” is specified.

```
# pdu release [id]{/y}
```

### Parameters:

- id: Link ID of the unit to be released (PDUs 2-8).

## Chapter 6: Meet the HDOT Cx Outlet


With Server Technology’s own leading-edge universal outlet, the **Cx**, the **PRO3X** rack PDU is a dramatic innovation in outlet technology. The PRO3X is a single PDU that offers limitless possibilities in providing power and flexibility to alternating-phase and High Density Outlet Technology (HDOT).

### Key Features of the HDOT Cx Outlet:

- The C19 outlets are replaced with the universal Cx outlet that accepts either a C14 or C20 connector, automatically increasing the PDU’s outlet count.
- Future-proofs your datacenter with fast and easy equipment cord swap-outs while the HDOT Cx stays in place for the lifetime of the PDU. The Cx outlet also eliminates the need to keep several types of cables in inventory for load-balancing.
- Ultimate flexibility for ever-changing rack needs during new hardware installation, as well as limitless possibilities for the power and growth demands of hyperdensity and hyperscale in your datacenter.



**PRO3X PDU with Cx Outlets**



**Side-by-side comparison of the PRO3X HDOT C13 outlet and the HDOT Cx universal outlet**



## A Closer Look at the Universal Cx Outlet

On the PRO3X PDU, the common C13 and C19 outlets have been combined into Server Technology's new Cx outlet design, a fully-rated hybrid C13/C19 outlet that accepts either a C14 or C20 plug.



Universal Design of the CX Outlet

The unique Cx outlet is the latest innovation in outlet technology that provides ultimate flexibility for the PDU and its outlet count, ensuring that PDUs do not run out of outlets. The new technology of the Cx outlet is designed to meet data center requirements for outlet power today and in the future.

### Notes:

- The Cx outlet is not an IEC connector.
- When plugging in a C14 or C20 connector into a Cx outlet, it is recommended to apply moderate force to ensure best cable retention.
- Not every outlet on the PRO3X PDU is a Cx outlet. The PRO3X has 36-fixed outlets, 18 C13 and 18 HDOT Cx, spread across the length of the PDU for easy access.
- All PRO3X outlets (C13 and Cx) are designed with the RAMLock retention mechanism, explained in the next chapter of this Features guide.

## HDOT Gets Better with Cx

Server Technology added the innovate and flexible design of the Cx outlet to gives the PRO3X higher performance by allowing you to plug in C14 and C20 cables into a single Cx outlet with no other parts needed, and no need to swap-out the PDU from the rack during equipment changes.

The increased outlet count provided by the universal Cx outlet allows the PRO3X PDU to have high-density benefits to continue uninterrupted because the PDU remains in the rack for its lifetime while you swap-out other data center equipment around it.

The Cx works as two outlets in one: a C13 and a C19 combined into one Cx outlet, allowing many different outlet swap-out configurations on demand. The universal design of the CX outlet results in a fast, easy, and flexible outlet arrangement on the same PDU exactly where and when outlets are needed. High-density solutions for power density, capacity planning, and uptime are enhanced by the ultimate flexibility of the Cx outlet.

## Appendix A: Regulatory Compliance

---

### Product Safety

Units have been safety tested and certified to the following standards:

- USA/Canada UL 60950-1:2007 R10.14 and CAN/CSA 22.2 No. 60950-1-07 +A1+A2
- European Union EN 60950-1:2006 + A11 +A1 + A12 + A2

This product is also designed for Norwegian IT power system with phase-to phase voltage 230V.

---

### Notifications

#### USA Notification

**Note:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's own expense.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

#### Canadian Notification

This Class A digital apparatus complies meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

#### European Union Notification

**WARNING: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.**

Products with CE Marking comply with the EMC Directive (2014/30/EU), Low Voltage Directive (2014/35/EU) and RoHS 2 Directive (2011/65/EU) issued by the Commission of the European Community.

Compliance with the following harmonized standards demonstrate conformity with the EMC and Low Voltage Directives.

- EN 55032
  - EN 55024
  - EN 60950-1
-

## Japanese Notification

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。  
本製品に同梱または付属しております電源コードは、本製品専用です。本製品以外の製品ならびに他の用途に使用しないで下さい。

## Chinese Notification

关于符合中国《电子信息产品污染控制管理办法》的声明

产品中有毒有害物质的名称及含量

| 部件名称<br>(Parts)             | 有毒有害物质或元素 (Hazardous Substance) |        |        |               |            |              |
|-----------------------------|---------------------------------|--------|--------|---------------|------------|--------------|
|                             | 铅 (Pb)                          | 汞 (Hg) | 镉 (Cd) | 六价铬 (Cr (VI)) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) |
| 机箱子组件 (Chassis Subassembly) | 0                               | 0      | 0      | 0             | 0          | 0            |
| 印刷板组件 (PCAs)                | X                               | 0      | 0      | 0             | 0          | 0            |

0 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。  
Indicates that this hazardous substance contained in all homogeneous materials of this part is below the limit requirement in SJ/T 11363-2006.

X 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。  
Indicates that this hazardous substance contained in at least one of the homogeneous materials of this part is above the limit requirement in SJ/T 11363-2006.

---

## Product Recycling

### Recycling



Server Technology Inc. encourages the recycling of its products. Disposal facilities, environmental conditions and regulations vary across local, state and country jurisdictions, so Server Technology encourages consultation with qualified professional and applicable regulations and authorities within your region to ensure proper disposal.

### Waste Electrical and Electronic Equipment (WEEE)



In the European Union, this label indicates that this product should not be disposed of with household waste. It should be deposited at an appropriate facility to enable recovery and recycling.

## Appendix B: Product Support

---

### Warranty

For Server Technology warranty information, visit our website [www.servertech.com](http://www.servertech.com)

---

### Contact Technical Support



be supported.

#### Experience Server Technology's FREE Technical Support

Server Technology understands that there are often questions when installing and/or using a new product. Free Technical Support is provided from 8 a.m. to 5 p.m. Pacific Time, Monday through Friday.

Server Technology, Inc. (a brand of Legrand)

|                        |      |                |        |  |
|------------------------|------|----------------|--------|--|
| 1040 Sandhill Road     | Tel: | 1-800-835-1515 | Web:   | <a href="http://www.servertech.com">www.servertech.com</a>         |
| Reno, Nevada 89521 USA | Fax: | 775-284-2065   | Email: | <a href="mailto:support@servertech.com">support@servertech.com</a> |

---

### Return Merchandise Authorization (RMA)

If you have a product that is not functioning properly and needs technical assistance or repair, see the Server Technology **Return Merchandise Authorization** process at: [www.servertech.com](http://www.servertech.com)

# About Server Technology®

Server Technology, a brand of Legrand, is leading the engineering and manufacturing of customer-driven, innovative and exceptionally reliable power, access and control solutions for monitoring and managing critical IT assets for continual availability.

Server Technology's power strategy experts are trusted to provide Rack PDU solutions for data centers worldwide ranging from small technology startups to Fortune 100 powerhouses. Because power is all we do, Server Technology can be found in the best cloud and colocation providers, forward thinking labs, and telecommunications operations.

Server Technology customers consistently rank us as providing the highest quality PDUs, the best customer support, and most valuable innovation. We have over 12,000 PDU configurations to fit every data center need and most of our PDUs are shipped within 10 days.



## Rack PDU Buying Guide

Find the best PDU for your data center

[servertech.com/rack-pdu-buying-guide](http://servertech.com/rack-pdu-buying-guide)



## Rack PDU Selector

Over 2000 standard configurations

[servertech.com/product-selector](http://servertech.com/product-selector)



## Build Your Own PDU

Build an HDOT or HDOT Cx PDU in 4 easy steps

[byopdu.servertech.com](http://byopdu.servertech.com)



## Speak to a Power Expert

Get free technical support

[servertech.com/support](http://servertech.com/support)



## How to Buy

Tools to simplify the PDU buying process

[servertech.com/how-to-buy](http://servertech.com/how-to-buy)



## About Us

Stay Powered, Be Supported, Get Ahead

[servertech.com/about-us](http://servertech.com/about-us)

1-800-835-1515  
[sales@servertech.com](mailto:sales@servertech.com)  
[www.servertech.com](http://www.servertech.com)

**Server  
Technology®**  
A brand of **legrand**