



HD77

Wireless speaker


User's Manual

Please read this
manual before
using the product

Thank you for choosing TREBLAB HD77!


This speaker provides superior sound quality and mobility, combined with rugged construction and the convenience of hands-free wireless operation.

WHAT'S IN THE BOX





HD77

1. TREBLAB HD77 speaker
2. User's manual
3. Insert card
4. Charging cable
5. Round TREBLAB logo sticker
6. Carrying strap
7. Carabiner
8. 3.5 mm audio cable



BUTTONS AND PARTS



Function

Operation

Power ON	Press and hold the POWER button for 3 seconds.
Power OFF	Press and hold the POWER button for 5 seconds.
Play / Pause	Press the PLAY / PAUSE button.
Volume +	Press the VOLUME + button.
Volume -	Press the VOLUME - button.
Answer a phone call	Press the PLAY / PAUSE button.
Reject a phone call	Press and hold the PLAY / PAUSE button for 2 seconds.
End a phone call (hang up)	Press the PLAY / PAUSE button.
Redial	Press and hold the PLAY / PAUSE button for 3 seconds.
Next track	Press and hold the VOLUME + button for 2 seconds.
Previous track	Press and hold the VOLUME - button for 2 seconds.
Switch between Wireless / 3.5 audio cable	Press the POWER button.
Factory reset	Press and hold the VOLUME + and the VOLUME - buttons simultaneously for 5 seconds.

SETTING UP YOUR HD77

Turn ON

Press and hold the **POWER** button for 3 seconds. You will hear the sound cue, and the BLUE LED light will start flashing.

Turn OFF

Press and hold the **POWER** button for 5 seconds. You will hear the sound cue, and the RED LED will light up and go OFF.

WIRELESS PAIRING

Make sure **TREBLAB HD77** is fully charged and that the AUX cable is not plugged in.

1. Turn ON your speaker by pressing and holding the **POWER** button for 3 seconds. You will hear the sound cue and the LED will start flashing BLUE, indicating that the speaker is in pairing mode.
2. Activate the Bluetooth mode on your device (smartphone, tablet, laptop).
3. Select **TREBLAB HD77** from the Bluetooth devices list. Keep it within 3 feet 1 meter of the speaker while pairing.
4. If necessary, enter passcode 0000.
5. Once **HD77** is successfully paired and connected, the LED will stop flashing and stay BLUE.

REPAIRING

After the initial pairing, the speaker will automatically connect to the previously paired device when turned ON again. If reconnection does not happen automatically, the speaker will start looking for any other previously paired device within the effective distance range. **TREBLAB HD77** can remember up to 8 recently paired devices.

TRUE WIRELESS STEREO (TWS) - PAIRING TWO SPEAKERS

The TWS technology allows you to use two speakers paired wirelessly to create a wireless dual-channel system, delivering a true stereo sound effect. While using this function, one speaker (Master, left channel) is paired with a smart device, the other (Slave, right channel) speaker is paired with the Master speaker.

- ✔ Select the Master speaker and pair it to the smart device following the steps from the WIRELESS PAIRING section. Then turn this speaker OFF.
- ✔ Turn OFF the Bluetooth on the smart device.
- ✔ Place the Master and Slave speakers near each other (the distance should not be over 3 feet /1 meter).
- ✔ Turn ON both speakers.
- ✔ Double click the **POWER** button on the Master speaker. The LED indicators

will start flashing BLUE and GREEN, indicating pairing with the Slave speaker.

- ✔ Turn On the Bluetooth on the smart device. The speakers will connect automatically.
- ✔ Once paired, the Master speaker's LED indicators will slowly flash BLUE.

To disable the TWS function and disconnect the Master and Slave speakers, press and hold the **VOLUME +** and **VOLUME -** buttons simultaneously on the Slave speaker for 5 seconds until the BLUE LED light flashes, indicating the connection is lost.

AUDIO PLAYBACK

To pause and resume playback when connected wirelessly, press the **PLAY** button.

To adjust the volume, press the **VOLUME +** or the **VOLUME -** button while listening to music.

To change the track on the **HD77**, press and hold the **VOLUME +** or the **VOLUME -** button for 2 seconds.

3.5 MM AUDIO CABLE CONNECTION

You can connect **TREBLAB HD77** to compatible devices using the supplied 3.5 mm audio cable.

Plug one end of the 3.5 mm audio cable into the 3.5 mm cable port on the side of the speaker (under the rubber cover). Plug the other end into the 3.5mm jack on your device.

Turn the speaker ON. You will hear the sound cue and the LED light will turn GREEN. Now you can play music and audio.

NOTE: On-device control is not supported for the NEXT, PREVIOUS and PAUSE functions when using the 3.5 mm audio cable. Phone calls management using the **PLAY / PAUSE** button is not supported as well. You will need to make adjustments using your smart device.

PHONE CALLS

TREBLAB HD77 can be used to make and receive phone calls when connected wirelessly. Audio playback will be paused during calls.

To answer / end a call:

Press the **PLAY / PAUSE** button.

To reject a call:

Press and hold the **PLAY / PAUSE** button for 2 seconds.

To redial:

Press and hold the **PLAY / PAUSE** button for 3 seconds.

NOTE: For better call quality, face the microphone when you speak.

TROUBLESHOOTING

Problem	Solution
Not powering on	<p>Make sure the speaker is fully charged. Charge for 2 hours, if necessary. Press and hold the POWER button for 3 seconds.</p>
Not pairing	<p>Make sure the 3.5 mm audio cable is not plugged in. Make sure the speaker is not paired with any other device, as it can only pair with one device at a time.</p> <p>Press the VOLUME + and VOLUME - buttons simultaneously and hold for 3-5 seconds. This will force the speaker to forget previously paired devices. Repeat the steps for pairing as previously described.</p> <p>Alternatively, disconnect the device from your speaker and remove HD77 from your device's pairing list. Try to pair again.</p>

**Not finding
a wireless driver
on your laptop**

Make sure your laptop supports wireless connections. If it doesn't, you will need an external wireless USB adapter compatible with your laptop. For further details, consult with your laptop manufacturer.

**Frequent
disconnection
and noise**

Ensure that the distance between your device and the speaker is less than 30 feet / 10 meters.

Ensure that nothing is blocking the signal between your device and the **HD77**.

Check if the speaker is running out of power.

CHARGING

One full battery charge provides up to 9 hours of playing time at maximum volume, and up to 12 hours at medium volume. When the battery is running low, you will hear a sound signal.

TREBLAB HD77 may be used while charging in both Wireless Mode and 3.5 mm audio cable modes.

To charge the speaker, plug one end of the supplied cable into the Micro USB charging port under the rubber cover at the side of the speaker. Plug the other end of the charging cable into a standard USB port. It takes up to 4 hours to fully charge.

If the speaker is turned OFF, the LED light will turn on RED. If the speaker is turned ON and connected to the device, the PURPLE LED will light up. The RED light will turn GREEN or the PURPLE light will go BLUE when the speaker is charged.

Be sure to use a 5V DC, 0.5-2 A adaptor or charger. Using the power source with lower power will increase the overall charging time. Maximize the battery lifespan by charging your speaker through a computer's USB port.

Unplug **HD77** from the charging cable and the cable itself from the power source when not in use.

If the speaker is left unused, even the fully charged battery will lose its charge over time.

We recommend fully charging the **HD77** speaker at least twice a month to maintain sufficient battery life.

SAFETY RULES

- ✔ Don't disassemble or modify your speaker for any reason. Doing this may cause the speaker to malfunction or become combustible. The damage to your device can void the manufacturer's warranty.
- ✔ Do not let your device get wet – liquids can cause serious damage. Water damage to your device can void the manufacturer's warranty.
- ✔ Make sure the speaker is completely dry before charging.
- ✔ Clean only with a dry cloth.
- ✔ Avoid exposing **TREBLAB HD77** to extreme temperatures (below 37°F / 3°C or above 112°F / 45°C). Extreme temperatures can cause the deformation of the **HD77** components and reduce the battery life and the lifespan of your new speaker.
- ✔ Don't put the device's LED lights close to humans' or animals' eyes.
- ✔ Do not use **HD77** during a thunderstorm. Thunderstorms can cause serious malfunction and increase the risk of electric shock.

SPECIFICATIONS

Battery:	Up to 20 hours playtime (35% volume) Up to 9 hours (100% volume) Rechargeable Li-Ion 5200mAh 3.7V Input 5V / 0.5A - 2A
Charging time:	4 hours
Bluetooth version:	4.2
Supported profiles:	HFP, A2DP, AVRCP, GAVDP, AVDTP, SPP, AVCTP
Frequency response:	100 Hz -16 KHz
Signal range:	33 ft / 10 m
Output power:	12.5W x 2
Water resistance:	IPX6
Charging port:	Micro USB
Audio port:	3.5 mm jack
Dimensions:	3 x 3 x 7.3 inches / 78 x 78 x 186 mm
Weight:	1.37 lbs / 620 g

RECYCLING

The speakers can be recycled, and they should be in order to keep our planet clean. Where should you bring them?

In the **US**, there are a couple of options:

1. Best Buy has a recycling program. Just take the broken speaker with you next time you visit a Best Buy store.

This link will help you find the best location: <https://www.bestbuy.com/site/store-locator/>

2. Check for other possible locations next to you on these websites (just enter your ZIP to find a location):

<https://www.call2recycle.org>

<https://search.earth911.com>

<https://recyclenation.com/find>

<https://www.cta.tech/Consumer-Resources/Greener-Gadgets>

In **Canada**, please visit the links below:

<https://thinkreuse.net>

<https://www.call2recycle.ca>

In the **UK**, please visit the links below:

<https://www.recycle-more.co.uk/>

<https://www.recyclenow.com/local-recycling>

THANK YOU

We truly appreciate that you chose **TREBLAB** as your trusted brand of wireless speakers and sincerely hope you enjoy the great sound and seamless usability **TREBLAB HD77** provides. We love making our customers happy by providing true value with our products. If for any reason you are not completely satisfied with your purchase or have any questions, please visit https://treblab.com/contact_us. We care about our customers most of all and are always here to help you.



TREBLAB

1 YEAR WARRANTY

Parts and Labor Warranty

Please visit www.treblab.com
to register YOUR product.

Manufactured by Productech

HD77

WIRELESS SPEAKER

Made in China

RoHS **CE** **FC**  



WARNING: Cancer and Reproductive
Harm - www.P65Warnings.ca.gov

