




TREBLAB

WX8

True wireless earbuds

User's Manual

Please read this manual
before using the product




IN THE BOX

1. Charging case
2. Earbuds
3. Round Treblab logo sticker
4. User's manual
5. Charging cable
6. Silicone L, M, S ear-tips

Thank you for choosing TREBLAB WX8!

Our earbuds provide superior sound quality and mobility combined with light-weight construction and the convenience of hands-free wireless operation. Before using this product, please read this manual.




EARBUDS FUNCTION

Function	Operation
Power On	Take the earbuds out of the case or tap on the Touch panels of both earbuds and hold for 2 sec.
Power Off	Put the earbuds back to the case or tap on the Touch panels of both earbuds and hold for 4 sec when no media is played.
Pause / Play	Tap on either earbud's Touch panel once.
Next track	Double-tap on the right earbud's Touch panel.
Previous track	Double-tap on the left earbud's Touch panel.
Volume +	Tap on the right earbud's Touch panel and hold until you reach the required volume level.

Volume -	Tap on the left earbud's Touch panel and hold until you reach the required volume level.
Answer a phone call	Tap on either earbud's Touch panel during the incoming call.
Reject a phone call	Tap on either earbud's Touch panel and hold for 1 sec during the incoming call.
Hang up	Tap on either earbud's Touch panel and hold for 1 sec when on a call.
Voice assistant activation	Tap on either earbud's Touch panel three times.
Disconnect	Tap on either earbud's Touch panel five times when the earbuds are connected to the source device.
Factory reset	Tap on either earbud's Touch panel five times when the earbuds are not connected to the source device.

WEARING METHOD




Using the correct size ear-tips is critical for the maximum external noise isolation and a snug secure fit. It is also common to have different sized ear canals so try one ear-tip on at a time to find the best fit for each side.


To get the best possible fit with your **WX8** earbuds, gently push the earbuds into your ears and adjust the headset until it fits comfortably. You should notice a drop in ambient noise when the ear-tip has been placed correctly. With a proper fit, you'll notice more range when listening to music.

To change the silicone ear-tips:

- 1.** Turn out the ear-tip upper cover.
- 2.** Rotate and firmly push the ear-tip tube to cover the ear-tip pillar.
- 3.** Turn the ear-tip upper cover back on the nozzle.



CHARGING



The WX8 model comes with a protective film on the charging contacts of both earbuds that is used for presale protection. Please remove the film carefully to charge the earbuds.

1. To charge the case

When the charging case runs out of power, the orange charging case indicator will start flashing. To charge the case connect it to a power source using the supplied Type-C cable or put it on a wireless charger. The orange charging case indicator will turn on and will go off when the case is fully charged. It takes up to 1.5 hours to fully charge the case either via cable or wirelessly.

Be sure to use a 5V DC, 0.5 - 1A adapter or charger. Using a power source with lower power will increase the overall charging time.

2. To charge the earbuds with the charging case

When the earbuds' battery is low, you'll hear the "Battery low" voice prompt.

To charge the earbuds, put both earbuds into the respective slots in the charging case. The earbuds will turn off automatically and start taking the charge. The earbuds' white LED indicators will turn on. It takes about 1.5 hours to charge the earbuds fully. When the earbuds are fully charged, the LED indicators will go off.

SETTING UP YOUR TREBLAB WX8

To turn the earbuds ON

- 1.** Take the earbuds out of the case, the earbuds will turn on automatically.
- 2.** Another option to turn them on is to tap on the **Touch panels** of both earbuds and hold for 2 sec. You will hear the "Power On" and "Pairing" voice prompts.

The white LEDs will light up on both earbuds and, a few seconds later, the white LED will start flashing on one of the earbuds.

3. You will hear the “Connected” voice prompt after connecting to the device.

To turn the earbuds OFF

1. Put both earbuds into the slots in the charging case.

2. Alternatively, tap on the **Touch panels** of both earbuds and hold for 4 sec **when there is no media played**. You will hear the “Power OFF” voice prompt. The white LEDs will light up for 1 sec and go off on both earbuds.

PAIRING

You can pair the **WX8** earbuds with your device either together or separately. Using only one earbud at a time will help you to extend the overall playtime. Please read the instructions below to make the pairing process smooth and easy.

To pair both earbuds

1. Open the case lid and take the earbuds out of the case. The white LEDs will light up on both earbuds and, a few seconds later, the white LED will start flashing on one of the earbuds.
2. Activate Bluetooth on the device, scan/search for **TREBLAB WX8**, and click **CONNECT**.
3. If prompted by your device to connect, select Yes.

4. You will hear the “Connected” voice prompt indicating that the earbuds are connected. The LED will start flashing every 5 seconds on both earbuds.

When you turn the earbuds on, they will try to reconnect to the recently connected device. If the reconnection does not happen automatically, the earbuds will try to find the next device in the pairing list. You can only connect and play audio from one device at a time. But you can save up to 6 connected devices in the pairing list.

NOTE:

The earbud, which LED is flashing white during the pairing, is the main one. For better performance, keep your smart device closer to the main earbud.

To pair one earbud only

1. Take one earbud out from the charging case. The earbud should start flashing white indicating that it is in the pairing mode.
2. Activate Bluetooth on the device, scan/search for **TREBLAB WX8**, and click CONNECT.
3. If prompted by your device to connect, select Yes.
4. You will hear the “Connected” voice prompt indicating that the earbuds are connected. The LED indicator will go off.

AUDIO PLAYBACK

To pause and resume the playback, tap on either earbud's **Touch panel** once.

To change tracks on **WX8**, double-tap on the right earbud's **Touch panel** to play the next track and double-tap on the left earbud's **Touch panel** to play the previous track.

To adjust the volume, tap on the right earbud's **Touch panel** and hold to increase the volume and tap on the left earbud's **Touch panel** and hold to decrease the volume.

PHONE CALLS MANAGEMENT

The **TREBLAB WX8** can be used to make and receive calls when connected via Bluetooth. Audio playback will be paused during the calls.

To answer a call:	Tap on either earbud's Touch panel once during the incoming call.
To reject a call:	Tap on either earbud's Touch panel and hold for 1 sec during the incoming call.
To end a call:	Tap on either earbud's Touch panel and hold for 1 seconds when on a call.

VOICE ASSISTANTS SUPPORT

TREBLAB WX8 earphones are compatible with Siri, Google Voice Assistant and others. To use the voice assistant, tap on either earbud's **Touch panel** three times.

RESET TO THE FACTORY SETTINGS

You can reset the **WX8** earbuds to the factory default settings by cleaning up the pairing list with the last 6 connected to **WX8** devices.

Make sure that the earbuds **are disconnected from** the source device. Tap five times on both earbuds' **Touch panel**. The white LEDs will light up on both earbuds and you will hear the "Power Off" voice prompt. The earbuds' memory is returned to the factory settings now.

TROUBLESHOOTING

Can't turn the earbuds ON

Please make sure the earbuds are charged, if not – charge them and try again.

Earbuds do not charge

Please check if there is a protective tape on the charging contacts of both earbuds. If yes, please remove it and try to charge the earbuds once again.

Clean the charging contacts on the earbuds with a slightly damp cotton swab when they are turned off (we recommend using water or a specially designed cleaning fluid sold for electronics).

Check if the earbud slots in the charging case are free of debris.

Try charging the case with another Type-C cable, power source, adaptor (if available).

Device doesn't find TREBLAB WX8

Make sure the **WX8** buds are not paired with any other device, as they can pair only with one device at a time.

If **WX8** are in pairing mode and one of the earbuds flashes white, but still is not found by your device, please restart your device and the headset.

Reset your earbuds to the factory settings by following the steps from the previous section. Try to pair again.

Frequent disconnection and noise

Make sure that the distance between your device and the earbuds is less than 33 feet / 10 meters.

Make sure that nothing is blocking the signal between your device and your **WX8** earbuds.

If the earbuds are on, but disconnected from the device for longer than 5 minutes, they will automatically turn off to save power.

Can't connect the earbuds to the device

Make sure the **WX8** earbuds are not paired with any other device, as they can pair only with one device at a time.

Make sure that the distance between your device and the headphones is less than 30 feet/10 meters.

Disconnect the device from your

earbuds and remove **WX8** from your device's pairing list. Reset your earbuds to the factory settings by following the steps from the previous section. Try to pair again.

I cannot find a wireless driver for on my laptop

Make sure your laptop supports wireless connection. If it doesn't, you will need an external wireless USB adapter compatible with your laptop. For further details, consult with your laptop manufacturer.

BATTERY INFORMATION

- Your device is powered by rechargeable batteries.
- Unplug the charging case from the electrical plug when not in use.
- If left unused, a fully charged battery will lose its charge over time.
- We recommend a full charging twice a month to ensure the battery integrity.
- Please do not leave the device (and the charging case) in hot or cold places, such as a closed car in summer or winter because this will reduce the capacity and lifetime of the batteries.
- Do not put the batteries in a fire as they may explode.
- Batteries may also explode if damaged.

SAFETY RULES

- Never disassemble or modify your **WX8** for any reason. Doing this may cause the device to malfunction or even become combustible. The damage to your device can void your manufacturer's warranty.
- Make sure the earbuds are dry before charging.
- Do not use corrosive liquids to clean the product.
- Avoid exposing **TREBLAB WX8** to extreme temperatures (below 37°F / 3°C or above 112°F / 45°C). Extreme temperatures can cause the deformation of the **WX8** components, reduce the battery life and the lifespan of your new earphones.
- Avoid putting the device's LED lights close to the eyes of children or animals.
- Do not use your **WX8** during a thunderstorm.

Thunderstorms can cause serious malfunction and increase the risk of electric shock.

NOTE:

Use only the provided USB / Type-C cable to charge.

RECYCLING

The earphones can be recycled, and they should be in order to keep our planet clean. Where should you bring them?

In the **US**, there are a couple of options:

1) Best Buy has a recycling program. Just take the broken earbuds with you next time you visit a Best Buy store.

This link will help you find the best location:
<https://www.bestbuy.com/site/store-locator/>

2) Check for other possible locations next to you on these websites (just enter your ZIP to find a location):

<https://www.call2recycle.org>

<https://search.earth911.com>

<https://recyclenation.com/find>

<https://www.cta.tech/Consumer-Resources/Greener-Gadgets>

In **Canada**, please visit the links below:

<https://thinkreuse.net>

<https://www.call2recycle.ca>

In the **UK**, please visit the links below:

<https://www.recycle-more.co.uk/>

<https://www.recyclenow.com/local-recycling>

SPECIFICATIONS

Battery:	Earbud (each): 40mAh Charging case: 420mAh
Charging time:	Up to 1.5 hours for the case and earbuds
Calling:	2 built-in microphones
Voice assistant activation:	Supported by tapping on either earbud's Touch panel three times
Bluetooth version:	BT5.0
Profiles:	A2DP, AVRCP, HFP, HSP

Audio playback support:	AAC, SBC
Signal Range:	33ft/10m
Driver size:	6 mm
Charging port:	Type-C
Dimensions:	Earbuds (each): 33.5 x 23 x 22 mm / 1.31 x 0.90 x 0.86 in Charging case: 56.7 x 45 x 28.2 mm / 2.23 x 1.77 x 1.11 in
Weight:	Earbuds (each): 4.4 g / 0.15 oz / 0.01 lb Charging case: 35.3 g / 1.24 oz / 0.08 lb

TREBLAB WX8 MEET IPX8 WATERPROOF STANDARD

SUITABLE:

Splashes

Light rain or snow

Sweating

Showering

Submerge up to 3 feet /
1 meter for 30 minutes

UNSUITABLE:

Swimming

Diving into water

Snorkeling or Scuba diving

Watersports

THANK YOU

We truly appreciate that you chose **TREBLAB** as your trusted brand of wireless earbuds and sincerely hope you enjoy the great sound and seamless usability **TREBLAB WX8** provide. We love making our customers happy by providing true value with our products. If for any reason you are not completely satisfied with your purchase or have any questions, please visit www.treblab.com/contact_us. We care about our customers most of all and are always here to serve you.

1 YEAR WARRANTY

Parts and Labor Warranty.

Please visit www.treblab.com
to register YOUR product.

Manufactured by Productech



TREBLAB

WX8

TRUE WIRELESS EARBUDS



Made in China