

































## Cleaning instructions

Only use water or window cleaning product. Do not use cleaning solvent with acetone, oil, white spirit or synthetic thinner as these will damage the tv stand.





## LIMITED WARRANTY

For three full years Salamander Designs Ltd will repair or replace, at our option, any product defective in materials or craftsmanship.

Salamander Designs Ltd. will not be responsible for any damage to or destruction of other equipment consequential to our equipment failure.

Defective product must be given Return Authorization and is to be returned to the factory prepaid, in the original carton and packing material.

Any damage incurred in a shipment not in original packaging shall be the responsibility of the owner. Warranty repairs will be returned prepaid, via UPS within the continental U.S.A. only.