

The Lenovo logo is displayed in white text on a pink rectangular background.


# Lenovo Tab M10 FHD Plus

## User Guide

Lenovo TB-X606F

Lenovo TB-X606X

All information labeled with \* in this guide refers only to the WLAN+LTE model (Lenovo TB-X606X).



# Basics

Before using this information and the products it supports, be sure to read the following:

- *Safety, Warranty & Quick Start Guide*
- *Regulatory Notice*
- "Important safety and handling information" in "Appendix".

The *Safety, Warranty & Quick Start Guide* and the *Regulatory Notice* are available on the website at <http://support.lenovo.com>.

**Note:** *All pictures and illustrations in this document are for your reference only and may differ from the final product.*

## Lenovo Help

Looking for help? The Lenovo Help app can offer you support for getting direct access to Lenovo's web assistance and forums\*, frequent Q&A\*, system upgrades\*, hardware function tests, warranty status checks\*, service requests\*\*, and repair status\*\*.

**Note:**

\* *requires data network access.*

\*\* *is not available in some countries.*

You have two ways to get this app:

- Search for and download the app from Google Play.



- Scan the following QR code with a Lenovo Android device.



## Technical specifications


<b>Model</b>	Lenovo TB-X606F	Lenovo TB-X606X
<b>CPU</b>	MediaTek Helio P22T Tab	MediaTek Helio P22T Tab
<b>Battery</b>	5000mAh	5000mAh
<b>Wireless communication</b>	Bluetooth 5; WLAN 802.11 a/b/g/n/ac; GPS/GLONASS/BDS	Bluetooth 5; WLAN 802.11 a/b/g/n/ac; GPS/A-GPS/GLONASS/BDS; FDD-LTE/TDD-LTE/WCDMA/GSM

**Note:** *Lenovo TB-X606X supports LTE Bands 1, 2, 3, 4, 5, 7, 8, 20, 38, 40, but in some countries LTE is not supported. To know if your device works with LTE networks in your country, contact your carrier.*

## Home screen

The home screen is the starting point for using your device. For your convenience, the home

screen is already set up with some useful apps and widgets.




**Note:** Your device's features and the home screen may be different depending on your location, language, carrier, and device model.

You can customize your home screen at any time.


- **Home screen**

On the default home screen, there is a **Google** Search bar and some useful apps.


- **Home settings**

Press and hold anywhere on the home screen except the icons. Tap , and then Modify Home settings.

- **Add a widget to a home screen**

Press and hold anywhere on the home screen except the icons. Tap , press and hold the widget you want to add, then drag it to where you want to place it, and then release it.

- **Change the wallpaper**

Press and hold anywhere on the home screen except the icons. Tap , and then choose your preferred wallpaper.

Go to **Settings > Display > Wallpaper** and choose your preferred wallpaper.

- **Move an app to another screen**

Press and hold an app that you want to move, drag it to where you want to place it, and then release it.

- **Uninstall an app**

1. Press and hold the app that you want to uninstall.

2. Drag to , then release and tap **OK**.

**Note:** Some of the system apps cannot be uninstalled.

- **Find apps**

On the home screen, swipe up from the bottom of your screen to the top.

- **View recent apps**



Swipe up from the bottom of screen. Then you can do the following:

- On the home screen swipe left or right to switch to the app you want to open.
- To close an app, swipe an app window up.
- To stop running all apps, tap **Clear all**.

On the bottom of the screen, swipe from left to right to open the recent app.


## Screen buttons

There is one button at the bottom of the screen.

- Tap  to return to the default home screen.
- Press and hold  to open Google Assistant.

## Notifications and Quick Settings

The Notifications panel informs you of new messages, USB connection, and activities in progress such as file downloading. The Quick Settings panel allows you to access frequently-used settings such as the WLAN switch.



You can do any of the following:

- To see notifications, swipe down from the top of the screen.
- To close the Notifications panel, swipe up from the bottom of the screen.
- To dismiss a notification, swipe left or right across the notification.
- To dismiss all notifications, tap **CLEAR ALL** at the bottom of the Notifications panel.
- To Manage notifications, tap **Manage notifications** at the bottom of the Notifications panel.
- To open the Quick Settings panel, swipe down from the top of the screen twice.
- To close the Quick Settings panel, swipe up from the bottom of the screen.

## Force shutdown/Force reboot


Press and hold the Power button for about 8 seconds until the device turns off or press and hold the Power button for about 12 seconds to reboot.



# Productivity mode

## Using Productivity mode

Go to **Settings > Display > Navigation bar > Productivity mode** to turn it on.






## Navigation bar

Recent app icons are displayed in the navigation bar, you can do any of the following:



- To open an app, tap its icon.
- When the app icons can not be completely displayed in the app list, **•••** will appear at the side of the navigation bar. To see the hidden icons, slide left or right.
- To adjust the order of the icons in the navigation bar, press and hold an app icon until it becomes slightly transparent, drag it to where you want to place it and then release it.
- To close an app, press and hold an app until its icon becomes slightly transparent, drag it upwards and then release it.

## Using split screen mode


### • Method 1

1. Open an app then tap .
2. Press and hold this app, drag it to " **Split screen**", and then release it. This app will be displayed in split screen mode.
3. Tap , choose the second app you want to open and the two apps will then be displayed in split screen mode.

### • Method 2

1. Open an app then press and hold . This app will be displayed in split screen mode.
2. Tap  and choose the second app you want to open. The two apps will then be displayed in

split screen mode.



**Note: Not all applications support split screen mode.**


## Split screen settings

In split screen mode you can do the following:

- **Adjust the split screen size**

Slide the "||" in the middle of the two screens to adjust the split screen size.

- **Replace the second app**


Tap  icon to choose another app.

- **Close the second app**

Press and hold the app icon in the navigation bar until it becomes slightly transparent, then drag it upwards and release.

## Exiting split screen mode

You can exit split screen mode by:

- Choosing an app that doesn't support split screen mode.
- Sliding the "||" to the edge of the screen.
- Pressing and holding  to enter full screen mode.

# Multi-User

## Multi-User Preferences

There are three user types:

- **Owner:** An owner has full control over all user permissions and manages all user accounts.
- **Guest:** The guest has restricted access to the device.
- **New User:** You can share this device with other people by creating additional users. Each user has their own space, which they can customize with apps, unique wallpaper, and so on.


## Creating new user accounts

Tap **Settings > Users & accounts > Multiple users > Add user or profile > User** to create user accounts.


Swipe down from the top of the screen, and then tap the users icon to create user accounts.

## Switching between user accounts


- On the home screen, swipe down from the top of the screen, and then tap the users icon to switch between different user accounts.



- On the lock screen interface, tap the user's icon and select the user icon you want to switch to, then tap to switch to the other account.



## Deleting a user account

Tap **Settings** > **Users & accounts** > **Multiple users**, and tap the  icon located beside the account you would like to delete and then tap **DELETE**.







# Pen Feature


To use the pen feature, go to **Settings** > **Screen Assistant** to turn on the Screen Assistant function.

## Turn the Pen Feature on and off


### Turn on Pen Feature

Swipe left from the right edge of the screen, tap below , press and hold the , drag to the right of the border and turn on the Pen Feature.







### Turn off Pen Feature

Press and hold the , drag to the right of the border and turn off the Pen Feature.

## Hide/show Pen Feature

- When the Pen Feature is turned on, tap  to display the Pen Feature.
- Tap outside the Pen Feature to hide the Pen Feature.

## Setting the Pen Feature

- : Set the thickness of the brush.
- : Return.
- : Advance.
- : Draw lines.
- : Draw rectangle.
- : Draw a circle.
- Clear all: Clear everything on the artboard.







# Camera

To open the **Camera** app, go to **Camera**.



## Taking photos and videos

You can take photos and record videos with your device's built-in camera.

- Tap  to keystone correct.
- Tap  to take a photo.
- Tap  to record a video.
- Tap  to switch between the front and the rear camera.
- Tap  to select a filter.
- Tap  to configure the other camera settings.

## Taking screenshots

Press and hold the **Power** and the **Volume down** buttons at the same time to take a screenshot.

## Viewing pictures and videos

Photos and videos are stored in your device's internal storage. You can view your photos and videos by using the following methods:

- Tap the thumbnail when using the **Camera** app.
- Go to **Photos**.
- Go to **Files**.

The screenshots are stored in your device's internal storage. You can view your screenshots by using the following methods:

- Go to **Photos**.
- Go to **Files**.



# Network

You need to set up a wireless network before connecting to the Internet.

- Set up a WLAN network.
- \*Set up a mobile network.
- Set up a VPN network.

You can also share your mobile network with others.

- \*Set up a hotspot.

## Setting up a WLAN network

Go to **Settings > Network & Internet > WLAN**. Turn on the WLAN switch and tap a WLAN hotspot in the list to connect to the Internet. When you are connecting to a secure hotspot, you need to enter your login name and password to connect.

## \*Setting up a mobile network

Go to **Settings > Network & Internet > Mobile network**.

**Note:** You need a valid SIM card with a data service. If you don't have a SIM card, contact your carrier.

## Setting up a VPN network

VPNs are used within organizations to allow you to communicate private information securely over a non-private network. You may need to configure a VPN, for example, to access your work email. Ask the network's administrator for the settings necessary to configure a VPN for your network.

1. Go to **Settings > Network & Internet > VPN**.
2. Tap **+** to edit the VPN profile, including the server name, type, and server address, and then tap **SAVE**.
3. Tap the VPN server name, enter the username and password, and then tap **CONNECT** to connect to the VPN network.
4. Tap **⚙️** to edit or forget the VPN.

**Note:** You need to set a lock screen Pattern, PIN or Password before using a VPN. Go to **Settings > Security & location > Screen lock** to select a screen lock option and set up the screen lock.

## \*Setting up a hotspot

You can use personal hotspots to share an Internet connection with a computer or other devices.

Go to **Settings > Network & Internet > Hotspot & tethering** and do the following:


Tap **WLAN hotspot** to configure the hotspot.

You can also use **Bluetooth tethering** or **USB tethering**.

**Note:** Tell your friends the Network name and password, and then they can connect to your personal hotspots.

# Internet

You can browse the web if your device is connected to a wireless network or a mobile network. To open the browser app, go to **Chrome**.



## Visiting websites

You can use the **Chrome** app to visit websites.

- **Type a web address**

You don't need to type the full web address of an "http://" website to access it.

To visit "http://www.lenovo.com", simply type "www.lenovo.com" into the address bar and tap →.

- **Search for keywords**

You can also type keywords into the address bar to search for webpages.

You can set a search engine in ⋮ > **Settings** > **Search engine**.

- **Add a new webpage**

Tap ⋮ > **New tab** to add a new webpage tab.

Tap ⋮ > **New incognito tab** to visit a website without leaving any traces of your visit.

- **Close a webpage**

Tap ✕ to close a webpage tab.

- **Refresh a webpage**

Tap ↻ to refresh a webpage.

Tap ← to return to the previous webpage.

Tap → to go forward to a recent webpage.

## Saving webpages

You can save images and webpages in your device's internal storage.

- **Save images**

Press and hold the image and then tap **Download image**.

- **Bookmark webpages**

Tap  to add a webpage to **Bookmarks**.

Tap  > **Bookmarks** to view bookmarks.

## Setting accessibility preferences


Tap  > **Settings** > **Accessibility** to set the text scaling and the webpage zoom.



You can send and receive emails if your device is connected to a wireless network. To access the **Gmail** app, go to **Gmail**.

## Setting up a Gmail account

You can sign into Gmail if you have a Gmail account. If you don't have an account, you will need to create a Gmail account. You can also sign in with email accounts provided by other email providers.



## Using Gmail

After setting up your Gmail account, you can use the **Gmail** app to send and receive emails.




You need to set the following settings before you can use **Maps**.

Go to **Settings > Security & location > Location** and enable location access for Google apps.

## Finding a location

Type the address that you want to find in **Search here**, then tap .



You can also tap  to say aloud the address you want to search for.

## Current location

Tap  to see your current location.

You can explore nearby to see what is around.

## Planning a route

Tap  and type in **Your location** and **Choose destination**, or just choose the starting point as **Your location**.

Choose the travel mode: car, bus, bicycle or foot.




10:00

Your location


Choose destination

Car, Walking, Cycling icons



**Take the shortcut**  
Save home and work for faster directions

[SIGN IN](#)



Batkhaan Mountain Bio Reserve  
Батхаан Уул БНБ

Erdenesant  
Эрдэнэсант

Delgerkhaan  
Дэлгэрхаан

Buren  
Бурэн

©2019 Google




You can transfer data such as music, photos, videos, documents, APK files and so on.

## Connecting your device to your computer

Connect your device and computer using a USB cable.

Slide down from the top of the screen. You will see "**Charging this device via USB**" in the notifications bar.

Tap **Charging this device via USB** to view other options.




## Selecting the computer connection mode

You can select one of the following options:

- **File transfer:** Select this mode if you want to transfer media files such as photos, videos, and ringtones between your device and computer.
- **MIDI:** Select this mode if you want MIDI-enabled apps on your device to work with MIDI software on the computer.
- **PTP:** Select this mode if you only want to transfer only photos and videos between your tablet and computer.
- **No data transfer:** Select this mode if you only want to charge your phone.



## Setting the language

1. Go to **Settings** > **System** > **Languages & input** > **Languages** > **Add a language**.
2. Select the language that you want to add.
3. Press and hold  option box to drag the added language to the first line.

## Setting screen lock

Go to **Settings** > **Security & location** > **Screen lock**, and select screen lock mode.

## Setting sound

Go to **Settings** > **Sound**. Here you can set the Default notification sound, Default alarm sound, and so on. You can also set the Media volume, Alarm volume, ringing volume, etc.

## Setting face recognition

Go to **Settings** > **Security & location** > **Face-recognition** and follow the on-screen instructions to set up your device.

## Battery protection mode

Battery protection mode prevents charging for extended periods, which exposes the battery to high temperatures and high voltage that may cause it to age faster. Once turned on, charging is paused when the battery level reaches 60%.

Go to **Settings** > **Battery** > **Battery protection mode** to turn on the Battery protection mode.

## Eye Protection and Safety Information

### 1. Eye protection

When Eye protection mode is enabled, the screen will have an amber tint, which reduces blue light. This allows you to read or view the screen more comfortably in dimly lit environments.

Go to **Settings** > **Display** > **Eye protection mode**, and tap **Status** to turn it on/off.

Color Temperature adjustment: Enter Eye protection Mode and slide the Color Temperature slider to adjust as needed.

### 2. Safety Information

Please use the device in a well-lit area, and when using the device, keep it at a suitable distance from your eyes. To avoid eyestrain, take a break from looking at the screen after a period of time.

## Factory reset

Factory reset will erase all data from your tablet's internal storage. Please back up important data on the device before resetting your tablet. Go to **Settings** > **System** > **Reset options** > **Erase all data (factory reset)**, then tap **RESET TABLET** > **ERASE EVERYTHING** to reset to the manufacturer's default settings.



# Appendix

## Important safety and handling information

To avoid personal injury, property damage, or accidental damage to the product, read all of the information in this section before using the product. For additional tips to help you operate your device safely, go to <http://www.lenovo.com/safety>.

### Handle your device with care

Do not drop, bend, or puncture your device; do not insert foreign objects into or place heavy objects on your device. Sensitive components inside might become damaged.

Your device screen is made of glass. The glass might break if the device is dropped on a hard surface, is subjected to a high impact, or is crushed by a heavy object. If the glass chips or cracks, do not touch the broken glass or attempt to remove it from the device. Stop using the device immediately and contact Lenovo technical support for repair, replacement, or disposal information. When using your device, keep it away from hot or high-voltage environments, such as electrical appliances, electrical heating equipment, or electrical cooking equipment. Use your device only in the temperature range of 0°C (32°F) to 40°C (104°F) (storage -20°C (-4°F) to 60°C (140°F)) to avoid damage.

Don't expose your device to water, rain, extreme humidity, sweat or other liquids.

### Do not disassemble or modify your device

Your device is a sealed unit. There are no end-user serviceable parts inside. All internal repairs must be done by a Lenovo-authorized repair facility or a Lenovo-authorized technician. Attempting to open or modify your device will void the warranty.

### Built-in rechargeable battery notice

Do not attempt to replace the internal rechargeable lithium ion battery. There is risk of explosion if the battery is replaced with an incorrect type. Contact Lenovo Support for replacement.

### Plastic bag notice

#### **DANGER:**

**Plastic bags can be dangerous. Keep plastic bags away from babies and children to avoid danger of suffocation.**

### Adapter information

- **Prevent your device and AC adapter from getting wet.**

Do not immerse your device in water or leave your device in a location where it can come into contact with water or other liquids.

- **Use approved charging methods only.**

Note: Please only use standard Lenovo power adapters. The use of third-party power adapters will affect the charging speed, resulting in abnormal charging and potential damage to the equipment.

- Connect a standard power adapter to a suitable power outlet.

- Use a standard data cable to connect the device to a PC or a device that complies with USB 2.0 or higher.

Charging devices might become warm during normal use. Ensure that you have adequate ventilation around the charging device. Unplug the charging device if any of the following occurs:

- The charging device has been exposed to rain, liquid, or excessive moisture.
- The charging device shows signs of physical damage.
- You want to clean the charging device.

**Warning:**

**Lenovo is not responsible for the performance or safety of products not manufactured or approved by Lenovo. Use only approved Lenovo ac adapters and batteries.**

**EU ErP (EcoDesign) Directive (2009/125/EC) - external power adapters (Regulation (EU) 2019/1782)**

Lenovo products are designed to work with a range of compatible power adapters. Access <https://www.lenovo.com/us/en/compliance/eu-doc> to view the compatible power adapters. For the detailed power adapter specifications for your device, go to <https://support.lenovo.com>.

**Caution about high volume usage**

Warning: exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the sound, the less time is required before your hearing could be affected. To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.



To prevent possible hearing damage, do not listen at high volume levels for long periods.

**Take care when using your device in a motor vehicle or on a bicycle**

Always prioritize your safety and the safety of others. Follow the law. Local laws and regulations might govern how you can use mobile electronic devices, such as your device, while you drive a motor vehicle or ride a bicycle.

**Dispose according to local laws and regulations**

When your device reaches the end of its useful life, do not crush, incinerate, immerse in water, or dispose of your device in any manner contrary to local laws and regulations. Some internal parts contain substances that can explode, leak, or have an adverse environmental effects if disposed of incorrectly.

See "Recycling and environmental information" for additional information.

**Keep your device and accessories away from small children**

Your device contains small parts that can be a choking hazard to small children. Additionally, the glass screen can break or crack if dropped on or thrown against a hard surface.

**Protect your data and software**

Do not delete unknown files or change the name of files or directories that were not created by you; otherwise, your device software might fail to work.

Be aware that accessing network resources can leave your device vulnerable to computer viruses,

hackers, spyware, and other malicious activities that might damage your device, software, or data. It is your responsibility to ensure that you have adequate protection in the form of firewalls, antivirus software, and anti-spyware software and keep such software up to date. Keep electrical appliances away from your device. These include electric fans, radios, high-powered speakers, air-conditioners, and microwave ovens. The strong magnetic fields generated by electrical appliances can damage the screen and the data on the device.

### Be aware of heat generated by your device

When your device is turned on or the battery is charging, some parts might become hot. The temperature that they reach depends on the amount of system activity and the battery charge level. Extended contact with your body, even through clothing, could cause discomfort or even a skin burn. Avoid keeping your hands, your lap, or any other part of your body in contact with a hot section of the device for any extended time.

## Electronic emission notices

### FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an authorized dealer or service representative for help.

Lenovo is not responsible for any radio or television interference caused by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

Lenovo (United States) Incorporated  
1009 Think Place - Building One  
Morrisville, NC 27560  
Telephone: 1-919-294-5900

### ISED Caution

This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### Japanese VCCI Class B statement

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。VCCI-B

### Japan compliance statement for products that connect to power mains rated at less than or equal to 20A per phase

日本の定格電流が 20A/相 以下の機器に対する高調波電流規制  
高調波電流規格 JIS C 61000-3-2 適合品

## Environmental, recycling, and disposal information

### General recycling statement

Lenovo encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. Lenovo offers a variety of programs and services to assist equipment owners in recycling their IT products. For information on recycling Lenovo products, go to <http://www.lenovo.com/recycling>.

### Important battery and WEEE information



Batteries and electrical and electronic equipment marked with the symbol of a crossed-out wheeled bin may not be disposed of as unsorted municipal waste. Batteries and waste of electrical and electronic equipment (WEEE) shall be treated separately using the collection framework available to customers for the return, recycling, and treatment of batteries and WEEE. When possible, remove and isolate batteries from WEEE prior to placing WEEE in the waste collection stream. Batteries are to be collected separately using the framework available for the return, recycling, and treatment of batteries and accumulators.

Country-specific information is available at <http://www.lenovo.com/recycling>.

### Battery recycling information for Brazil

#### Declarações de Reciclagem no Brasil

Descarte de um Produto Lenovo Fora de Uso Equipamentos elétricos e eletrônicos não devem ser descartados em lixo comum, mas enviados à pontos de coleta, autorizados pelo fabricante do produto para que sejam encaminhados e processados por empresas especializadas no manuseio de resíduos industriais, devidamente certificadas pelos órgãos ambientais, de acordo com a legislação local. A Lenovo possui um canal específico para auxiliá-lo no descarte desses produtos. Caso você possua um produto Lenovo em situação de descarte, ligue para o nosso SAC ou encaminhe um e-mail para: [reciclar@lenovo.com](mailto:reciclar@lenovo.com), informando o modelo, número de série e cidade, a fim de enviarmos as instruções para o correto descarte do seu produto Lenovo.

### Recycling information for Japan

Recycling and disposal information for Japan is available at <http://www.lenovo.com/recycling/japan>.

### Recycling information for India

Recycling and disposal information for India is available at [http://www.lenovo.com/social\\_responsibility/us/en/sustainability/ptb\\_india.html](http://www.lenovo.com/social_responsibility/us/en/sustainability/ptb_india.html).

### Battery recycling marks

- The battery recycling information of Taiwan



- Battery recycling information for the United States and Canada



**US & Canada Only**

- Battery recycling information for the European Union

**EU**



## ENERGY STAR model information



ENERGY STAR® is a joint program of the U.S. Environmental Protection Agency and the U.S. Department of Energy aimed at saving money and protecting the environment through energy efficient products and practices.

Lenovo is proud to offer our customers products with the ENERGY STAR qualified designation. You might find an ENERGY STAR mark affixed on the computer or displayed on the power settings interface. Lenovo tablets of the following model name, if carry an ENERGY STAR mark, have been designed and tested to conform to the ENERGY STAR program requirements for tablets.

Lenovo TB-X606F

By using ENERGY STAR qualified products and taking advantage of the power-management features of the tablet, you can help reduce the consumption of electricity. Reduced electrical consumption can contribute to potential financial savings, a cleaner environment, and the reduction of greenhouse gas emissions.

For more information about ENERGY STAR, go to <http://www.energystar.gov>.

## Export classification notice

This product is subject to the United States Export Administration Regulations (EAR) and has an Export Classification Control Number (ECCN) of 5A992.c. It can be re-exported except to any of the embargoed countries in the EAR E1 country list.

## Troubleshooting

### Insufficient memory prompt appears during app installation

Please free up some memory and try to install again.

### The touch screen does not work or is not sensitive



Please press and hold the power button for more than 8 seconds until the device turns off. Then switch it on again in normal way.

#### Device does not power on or system crashes

Please charge the battery for half an hour and then press and hold the power button for more than 8 seconds until the device turns off. Then switch it on again in normal way.

#### The device cannot access the internet via a wireless network

Restart the wireless router or go to Settings and restart WLAN.

#### The device cannot wake up from sleep mode

Please press and hold the power button for more than 8 seconds until the device turns off. Then switch it on again in normal way.